
ETSI TS 125 453 V7.7.0 (2007-06)

Technical Specification

Universal Mobile Telecommunications System (UMTS); UTRAN lupc interface Positioning Calculation Application Part (PCAP) signalling (3GPP TS 25.453 version 7.7.0 Release 7)



Reference
RTS/TSGR-0325453v770

Keywords
UMTS

ETSI

650 Route des Lucioles F-06921 Sophia Antipolis Cedex - FRANCE

Tel.: +33 4 92 94 42 00 Fax: +33 4 93 65 47 16

Siret N° 348 623 562 00017 - NAF 742 C Association à but non lucratif enregistrée à la Sous-Préfecture de Grasse (06) N° 7803/88

Important notice

Individual copies of the present document can be downloaded from: <u>http://www.etsi.org</u>

The present document may be made available in more than one electronic version or in print. In any case of existing or perceived difference in contents between such versions, the reference version is the Portable Document Format (PDF). In case of dispute, the reference shall be the printing on ETSI printers of the PDF version kept on a specific network drive within ETSI Secretariat.

Users of the present document should be aware that the document may be subject to revision or change of status.

Information on the current status of this and other ETSI documents is available at

http://portal.etsi.org/tb/status/status.asp

If you find errors in the present document, please send your comment to one of the following services: http://portal.etsi.org/chaircor/ETSI_support.asp

Copyright Notification

No part may be reproduced except as authorized by written permission. The copyright and the foregoing restriction extend to reproduction in all media.

© European Telecommunications Standards Institute 2007.
All rights reserved.

DECTTM, **PLUGTESTS**TM and **UMTS**TM are Trade Marks of ETSI registered for the benefit of its Members. **TIPHON**TM and the **TIPHON logo** are Trade Marks currently being registered by ETSI for the benefit of its Members. **3GPP**TM is a Trade Mark of ETSI registered for the benefit of its Members and of the 3GPP Organizational Partners.

Intellectual Property Rights

IPRs essential or potentially essential to the present document may have been declared to ETSI. The information pertaining to these essential IPRs, if any, is publicly available for **ETSI members and non-members**, and can be found in ETSI SR 000 314: "Intellectual Property Rights (IPRs); Essential, or potentially Essential, IPRs notified to ETSI in respect of ETSI standards", which is available from the ETSI Secretariat. Latest updates are available on the ETSI Web server (http://webapp.etsi.org/IPR/home.asp).

Pursuant to the ETSI IPR Policy, no investigation, including IPR searches, has been carried out by ETSI. No guarantee can be given as to the existence of other IPRs not referenced in ETSI SR 000 314 (or the updates on the ETSI Web server) which are, or may be, or may become, essential to the present document.

Foreword

This Technical Specification (TS) has been produced by ETSI 3rd Generation Partnership Project (3GPP).

The present document may refer to technical specifications or reports using their 3GPP identities, UMTS identities or GSM identities. These should be interpreted as being references to the corresponding ETSI deliverables.

The cross reference between GSM, UMTS, 3GPP and ETSI identities can be found under http://webapp.etsi.org/key/queryform.asp.

Contents

Intell	lectual Property Rights	2
Forev	word	2
Forev	word	8
1	Scope	9
2	References	9
3	Definitions and abbreviations	10
3.1	Definitions	
3.2	Abbreviations	11
4	General	11
4.1	Procedure Specification Principles	
4.2	Forwards and Backwards Compatibility	
4.3	Specification Notations	
5	PCAP Services	13
6	Services Expected from Signalling Transport	13
7	Functions of PCAP	
8	PCAP Procedures	14
8.1	Elementary Procedures	
8.2	Position Calculation	
8.2.1	General	
8.2.2	Successful Operation	15
8.2.3		
8.2.4		
8.3	Information Exchange Initiation	17
8.3.1	General	
8.3.2	1	
8.3.3	1	
8.3.4		
8.4	Information Reporting	
8.4.1	General	
8.4.2 8.4.3	1	
8.5	Adhormatic Conditions	
8.5.1	General	
8.5.2		
8.5.3		
8.6	Information Exchange Failure	
8.6.1	General	
8.6.2		
8.7	Error Indication	
8.7.1	General	25
8.7.2	1	
8.7.3	Abnormal Conditions	25
8.8	Position Initiation	
8.8.1	General	
8.8.2	1	
8.8.3	1	
8.8.4		
8.9	Position Activation	
8.9.1 8.9.2	General Successful Operation	
8.9.2	1	
0.7.3	Onouccostul Opelauon	∠>

8.9.4	Abnormal Conditions	30
8.10	Position Parameter Modification	30
8.10.1	General	
8.10.2	Successful Operation	30
8.10.3	Abnormal Conditions	30
8.11	Abort	31
8.11.1	General	31
8.11.2	Successful Operation	31
8.11.3	Abnormal Conditions	31
8.12	Position Periodic Report	31
8.12.1	General	
8.12.2		
8.12.3	1	
8.13	Position Periodic Result	
8.13.1	General	
8.13.2		
8.13.3	1	
8.14	Position Periodic Termination	
8.14.1	General	
8.14.2		
8.14.3	1	
	Elements for PCAP Communication	
9.1	Message Functional Definition and Content	
9.1.1	General	
9.1.2	Message Contents	35
9.1.2.1	Presence	35
9.1.2.2		
9.1.2.3	C	
9.1.2.4	<i>C</i> ,	
9.1.3	Position Calculation Request	36
9.1.4	Position Calculation Response	
9.1.5	POSITION CALCULATION FAILURE	37
9.1.6	Information Exchange Initiation Request	
9.1.7	Information Exchange Initiation Response	
9.1.8	Information Exchange Initiation Failure	39
9.1.9	Information Report	39
9.1.10	Information Exchange Termination Request	39
9.1.11	Information Exchange Failure Indication	40
9.1.12	Error Indication	40
9.1.13	POSITION INITIATION REQUEST	40
9.1.14	position INITIATION response	40
9.1.15	position INITIATION Failure	41
9.1.16	position activation request	42
9.1.17	position activation response	43
9.1.18	position ACTIVATION Failure	44
9.1.19	Position Parameter modification	44
9.1.20	ABORT	44
9.1.21	position Periodic Report	45
9.1.22	position Periodic Result	46
9.1.23	Position Periodic Termination	46
9.2	Information Element Functional Definitions and Contents	46
9.2.1	General	46
9.2.2	Radio Network Layer Related IEs	47
9.2.2.1	· · · · · · · · · · · · · · · · · · ·	
9.2.2.2		
9.2.2.3		
9.2.2.4		
9.2.2.5	, e	
9.2.2.6		
9.2.2.7	· ·	
9 2 2 8	<u> </u>	56

9.2.2.9	GPS Almanac and Satellite Health	58
9.2.2.10	GPS Clock and Ephemeris Parameters	58
9.2.2.11	GPS Ionospheric Model	60
9.2.2.12	GPS Measured Results	61
9.2.2.13	GPS Navigation Model	62
9.2.2.14	GPS Real Time Integrity	63
9.2.2.15	GPS Reference Time	
9.2.2.16	GPS Transmission TOW	64
9.2.2.17	GPS UTC Model	
9.2.2.18	GPS-UTRAN Time Relationship Uncertainty	65
9.2.2.19	Information Exchange ID	
9.2.2.20	Information Exchange Object Type	
9.2.2.21	Information Report Characteristics	
9.2.2.22	Information Type	
9.2.2.23	Message Structure	
9.2.2.24	Message Type	
9.2.2.25	Method Type	
9.2.2.26	Requested Data Value	
9.2.2.27	Requested Data Value Information	
9.2.2.28	Transaction ID	
9.2.2.29	Transmission TOW Indicator	
9.2.2.30	Uncertainty Ellipse	
9.2.2.31	Cell-ID Measured Results Info List	
9.2.2.32	OTDOA Measured Results Info List	
9.2.2.33	OTDOA Neighbour Cell Info	
9.2.2.34	OTDOA Reference Cell Info	
9.2.2.35	UE Positioning Measurement Quality	
9.2.2.36	UTRAN Access Point Position with Altitude	
9.2.2.37	UTRAN Cell Identifier (UC-ID)	
9.2.2.37A	Extended RNC-ID	
9.2.2.38	Horizontal Accuracy Code	
9.2.2.39	Vertical Accuracy Code	
9.2.2.40	Accuracy Fulfilment Indicator	
9.2.2.41	Uplink DPCH information	
9.2.2.42	Frequency information	
9.2.2.43	PRACH parameters	
9.2.2.44	Compressed Mode Assistance Data	
9.2.2.45	C-RNTI	
9.2.2.46	Primary Scrambling Code	
9.2.2.47	PRACH information	
9.2.2.48	TFS	
9.2.2.49	CTFC	
9.2.2.50	Request Type	
9.2.2.51	UE Positioning Capability	
9.2.2.52	Response Time	
9.2.2.53	Positioning Priority	
9.2.2.54	Client Type	
9.2.2.55	Positioning Method	
9.2.2.56	U-TDOA Bit Count	
9.2.2.57	U-TDOA Time Interval	
9.2.2.58	Additional Method Type	
9.2.2.59	UE Positioning OTDOA Assistance Data	
9.2.2.60	UL TrCH information	
9.2.2.61	Semi-static Transport Format Information	
9.2.2.62	Environment Characterisation	
9.2.2.63	Chip Offset	
9.2.2.64	Frame Offset	
9.2.2.65	Position Data	
9.2.2.66	Transmission Gap Pattern Sequence Information	
9.2.2.67	Active Pattern Sequence Information	
9.2.2.68	CFN	
9.2.2.69	Positioning Response Time	
	<i>-</i> 1	

9.2.2.70	Reference Cell Position	103
9.2.2.71	UE Positioning IPDL Parameters	
9.2.2.72	Burst Mode Parameters	
9.2.2.73	SFN-SFN Relative Time Difference1	
9.2.2.74	UTDOA Group	
9.2.2.75	Maximum Set of E-DPDCHs	
9.2.2.76	Puncture Limit.	
9.2.2.77	E-DCH Transport Format Combination Set Information (E-TFCS Information)	
9.2.2.78	Reference E-TFCI Power Offset	
9.2.2.79	E-TTI	
9.2.2.80	E-DPCCH Power Offset	
9.2.2.81	Cell Parameter ID.	
9.2.2.82	TFCI Coding	
9.2.2.83	Repetition Length	
9.2.2.84	Repetition Period	
9.2.2.85	TDD DPCH Offset	
9.2.2.86	UL Timeslot Information	
9.2.2.87	Time Slot	
9.2.2.88	Midamble Shift And Burst Type	
9.2.2.89	TFCI Presence	
9.2.2.90	TDD UL Code Information	
9.2.2.91	TDD Channelisation Code	
9.2.2.92	Special Burst Scheduling	
9.2.2.93	Max PRACH Midamble Shift	
9.2.2.94	PRACH Midamble	
9.2.2.95	USCH Parameters	
9.2.2.96	USCH Scheduling Offset	
9.2.2.97	Include Velocity	
9.2.2.98	Velocity Estimate	
9.2.2.99	Horizontal Speed and Bearing	
9.2.2.100	Vertical Velocity	
9.2.2.101	GPS Positioning Instructions	
9.2.2.101	UE Position Estimate Info	
9.2.2.102	UTRAN-GPS Reference Time	
9.2.2.104	UTRAN-GPS Reference Time Result.	
9.2.2.104	T _{UTRAN-GPS} Drift Rate	
9.2.2.105	Periodic Position Calculation Info	
9.2.2.107	Periodic Location Info.	
9.2.2.107	Amount of Reporting	
9.2.2.108	Measurement Instructions Used	
9.2.2.110	RRC State Change	
9.2.2.110	Periodic Position Termination Cause	
9.2.2.111	Requested Cell-ID Measurements	
9.2.2.112	DGANSS Corrections	
9.2.2.113	GANSS Almanac and Satellite Health	
9.2.2.114	GANSS Clock Model	
9.2.2.113	GANSS Lock Model	
9.2.2.117	GANSS Measured Results	
9.2.2.117	GANSS Navigation Model	
9.2.2.119	GANSS Orbit Model	
9.2.2.119	GANSS Positioning Instructions	
9.2.2.121 9.2.2.122	GANSS-UTRAN Time Relationship Uncertainty	
9.2.2.122	GANSS Reference Measurement Information	
9.2.2.123		
	GANSS Reference Time	
9.2.2.125	GANSS Time Model	
9.2.2.126	GANSS UTC Model	
9.2.2.127	GANSS Time Indicator	
9.3	Message and Information Element Abstract Syntax (with ASN.1)	
9.3.0	GeneralUsage of private message mechanism for non-standard use	
9.3.1	Usage of private message mechanism for non-standard use	131 131

9.3.3	PDU Definitions	135
9.3.4	Information Element Definitions	146
9.3.5	Common Definitions.	196
9.3.6	Constant Definitions	196
9.3.7	Container Definitions.	199
9.4	Message Transfer Syntax	
10 H	landling of Unknown, Unforeseen and Erroneous Protocol Data	201
10.1	General	
10.2	Transfer Syntax Error	
10.3	Abstract Syntax Error	
10.3.1	General	
10.3.2	Criticality Information	202
10.3.3	Presence Information	
10.3.4	Not comprehended IE/IE group	203
10.3.4.1	Procedure Code	203
10.3.4.1	A Type of Message	203
10.3.4.2	IEs other than the Procedure Code and Type of Message	203
10.3.5	Missing IE or IE group	204
10.3.6	IEs or IE groups received in wrong order or with too many occurrences or erroneously present	205
10.4	Logical Error	206
10.5	Exceptions	206
Annex A	A (informative): Guidelines for Usage of the Criticality Diagnostics IE	207
A.1 E	XAMPLE MESSAGE Layout	207
A.2 E	xample on a Received EXAMPLE MESSAGE	207
A.3 C	ontent of Criticality Diagnostics	209
A.3.1	Example 1	
A.3.2	Example 2	210
A.3.3	Example 3	211
A.3.4	Example 4	212
A.3.5	Example 5	213
A.4 A	SN.1 of EXAMPLE MESSAGE	214
Annex 1	B (informative): Change history	216
History		218

Foreword

This Technical Specification has been produced by the 3rd Generation Partnership Project (3GPP).

The contents of the present document are subject to continuing work within the TSG and may change following formal TSG approval. Should the TSG modify the contents of the present document, it will be re-released by the TSG with an identifying change of release date and an increase in version number as follows:

Version x.y.z

where:

- x the first digit:
 - 1 presented to TSG for information;
 - 2 presented to TSG for approval;
 - 3 or greater indicates TSG approved document under change control.
- y the second digit is incremented for all changes of substance, i.e. technical enhancements, corrections, updates, etc.
- z the third digit is incremented when editorial only changes have been incorporated in the document.

1 Scope

The present document specifies the *Positioning Calculation Application Part (PCAP)* between the Radio Network Controller (RNC) and the Stand-Alone SMLC (SAS). It fulfills the RNC-SAS communication requirements specified in [6] and thus defines the Iupc interface and its associated signaling procedures.

2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies. In the case of a reference to a 3GPP document (including a GSM document), a non-specific reference implicitly refers to the latest version of that document *in the same Release as the present document*.

[1]	3GPP TS 25.450: "UTRAN Iupc interface general aspects and principles".
[2]	3GPP TS 25.451: "UTRAN Iupc interface layer 1".
[3]	3GPP TS 25.452: "UTRAN Iupc interface signalling transport".
[4]	3GPP TS 25.331: "Radio Resource Control (RRC) Protocol Specification".
[5]	3GPP TS 25.401: "UTRAN Overall Description".
[6]	3GPP TS 25.305: "Stage 2 functional specification of UE positioning in UTRAN".
[7]	$ITU-T\ Recommendation\ X.680\ (07/2002): "Information\ technology\ -\ Abstract\ Syntax\ Notation\ One\ (ASN.1): Specification\ of\ basic\ notation".$
[8]	ITU-T Recommendation X.681 07/2002): "Information technology - Abstract Syntax Notation One (ASN.1): Information object specification".
[9]	ITU-T Recommendation X.691 (07/2002): "Information technology - ASN.1 encoding rules: Specification of Packed Encoding Rules (PER)".
[10]	ICD-GPS-200: (12 April 2000) "Navstar GPS Space Segment/Navigation User Interface".
[11]	3GPP TS 23.032: "Universal Geographical Area Description (GAD)".
[12]	3GPP TR 25.921: "Guidelines and principles for protocol description and error handling".
[13]	3GPP TS 25.133: "Requirements for support of Radio Resource management (FDD)".
[14]	3GPP TS 25.123: "Requirements for support of Radio Resource management (TDD)".
[15]	3GPP TS 22.071: "Location Services (LCS); Service Description; Stage1".
[16]	3GPP TS 25.212: "Multiplexing and Channel Coding (FDD)".
[17]	3GPP TS 25.213: "Spreading and Modulation (FDD)".
[18]	3GPP TS 25.223: "Spreading and Modulation (TDD)".
[19]	3GPP TS 25.221: "Physical channels and mapping of transport channels onto physical channels (TDD)".
[20]	3GPP TS 25.101: "User Equipment (UE) radio transmission and reception (FDD)".

- [21] 3GPP TS 25.102: "UE radio transmission and reception (TDD)".
- [22] Galileo OS Signal in Space ICD (OS SIS ICD), Draft 0, Galileo Joint Undertaking, May 23rd, 2006.

3 Definitions and abbreviations

3.1 Definitions

For the purposes of the present document, the following terms and definitions apply:

Stand-Alone SMLC (SAS): logical node that interconnects to the RNC over the Iupc interface via the PCAP protocol An SAS performs the following procedures:

- provide GNSS (i.e. GPS or GANSS (e.g. Galileo)) related data to the RNC;
- performs the position calculation function based upon UE Positioning measurement data.
- in SAS centric mode, selects the positioning method and controls the positioning procedure.

Elementary Procedure: PCAP consists of Elementary Procedures (EPs)

An Elementary Procedure is a unit of interaction between the RNC and the SAS. An EP consists of an initiating message and possibly a response message. Two kinds of EPs are used:

- Class 1: Elementary Procedures with response (success or failure).
- Class 2: Elementary Procedures without response.

For Class 1 EPs, the types of responses can be as follows:

Successful:

 A signalling message explicitly indicates that the elementary procedure successfully completed with the receipt of the response.

Unsuccessful:

- A signalling message explicitly indicates that the EP failed.

Class 2 EPs are considered always successful.

Information Exchange Context: Information Exchange Context is created by the first Information Exchange Initiation Procedure initiated by the RNC and requested from the SAS.

The Information Exchange Context is deleted after the Information Exchange Termination or the Information Exchange Failure procedure when there is no more Information Exchange to be provided by the RNC to the SAS. The Information Exchange Context is identified by an SCCP connection as, for Information Exchanges, only the connection oriented mode of the signalling bearer is used.

Positioning Initiation Context: In the SAS centric mode of operation each positioning request is assigned a unique logical connection identity, i.e., SCCP Source and Destination Local Reference numbers.

RNC Centric Mode of Operation: The RNC determines, initiates and controls the positioning method to be used for each positioning request.

SAS Centric Mode of Operation: The SAS determines, initiates and controls the positioning method to be used for each positioning request.

Positioning Event: The activity associated with the positioning of a UE resulting from the reception of UE positioning request from the CN.

3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

A-GPS Assisted GPS

ASN.1 Abstract Syntax Notation One

CN Core Network
CRNC Controlling RNC
DGPS Differential GPS
EP Elementary Procedure
FDD Frequency Division Duplex

GANSS Galileo and Additional Navigation Satellite Systems

GNSS Global Navigation Satellite System

GPS Global Positioning System
MSC Mobile services Switching Center
OTDOA Observed Time Difference Of Arrival
PCAP Positioning Calculation Application Part

PRC Pseudorange Correction
RNC Radio Network Controller
RNS Radio Network Subsystem
RRC Radio Resource Control
SAS Stand-Alone SMLC

SCCP Signalling Connection Control Part

SIB System Information Block SMLC Serving Mobile Location Center

SRNC Serving RNC SRNS Serving RNS

TDD Time Division Duplex

TOW Time of Week UE User Equipment

U-TDOA Uplink Time Difference Of Arrival

UTRAN Universal Terrestrial Radio Access Network

4 General

4.1 Procedure Specification Principles

The principle for specifying the procedure logic is to specify the functional behaviour of the SAS exactly and completely. The RNC functional behaviour is left unspecified.

The following specification principles have been applied for the procedure text in clause 8:

- The procedure text discriminates between:
 - 1) Functionality which "shall" be executed:
 - The procedure text indicates that the receiving node "shall" perform a certain function Y under a certain condition. If the receiving node supports procedure X but cannot perform functionality Y requested in the REQUEST message of a Class 1 EP, the receiving node shall respond with the message used to report unsuccessful outcome for this procedure, containing an appropriate cause value.
 - 2) Functionality which "shall, if supported" be executed:
 - The procedure text indicates that the receiving node "shall, if supported," perform a certain function Y under a certain condition. If the receiving node supports procedure X, but does not support functionality Y, the receiving node shall proceed with the execution of the EP, possibly informing the requesting node about the not supported functionality.
- Any required inclusion of an optional IE in a response message is explicitly indicated in the procedure text. If the
 procedure text does not explicitly indicate that an optional IE shall be included in a response message, the
 optional IE shall not be included.

4.2 Forwards and Backwards Compatibility

The forwards and backwards compatibility of the protocol is assured by mechanism where all current and future messages, and IEs or groups of related IEs, include Id and criticality fields that are coded in a standard format that will not be changed in the future. These parts can always be decoded regardless of the standard version.

4.3 Specification Notations

For the purposes of the present document, the following notations apply:

- [FDD] This tagging of a word indicates that the word preceding the tag "[FDD]" applies only to FDD. This tagging of a heading indicates that the heading preceding the tag "[FDD]" and the section following the heading applies only to FDD.
- [TDD] This tagging of a word indicates that the word preceding the tag "[TDD]" applies only to TDD, including 3.84Mcps TDD, 7.68Mcps TDD and 1.28Mcps TDD. This tagging of a heading indicates that the heading preceding the tag "[TDD]" and the section following the heading applies only to TDD, including 3.84Mcps TDD, 7.68Mcps TDD and 1.28Mcps TDD.
- [3.84Mcps TDD] This tagging of a word indicates that the word preceding the tag "[3.84Mcps TDD]" applies only to 3.84Mcps TDD. This tagging of a heading indicates that the heading preceding the tag "[3.84Mcps TDD]" and the section following the heading applies only to 3.84Mcps TDD.
- [1.28Mcps TDD] This tagging of a word indicates that the word preceding the tag "[1.28Mcps TDD]" applies only to 1.28Mcps TDD. This tagging of a heading indicates that the heading preceding the tag "[1.28Mcps TDD]" and the section following the heading applies only to 1.28Mcps TDD.
- [7.68Mcps TDD] This tagging of a word indicates that the word preceding the tag "[7.68Mcps TDD]" applies only to 7.68Mcps TDD. This tagging of a heading indicates that the heading preceding the tag "[7.68Mcps TDD]" and the section following the heading applies only to 7.68Mcps TDD.
- [FDD ...] This tagging indicates that the enclosed text following the "[FDD " applies only to FDD.

 Multiple sequential paragraphs applying only to FDD are enclosed separately to enable insertion of TDD specific (or common) paragraphs between the FDD specific paragraphs.
- [TDD ...] This tagging indicates that the enclosed text following the "[TDD " applies only to TDD, including 7.68 Mcps TDD, 3.84Mcps TDD, 7.68Mcps TDD and 1.28Mcps TDD. Multiple sequential paragraphs applying only to TDD are enclosed separately to enable insertion of FDD specific (or common) paragraphs between the TDD specific paragraphs.
- [3.84Mcps TDD ...] This tagging indicates that the enclosed text following the "[3.84Mcps TDD " applies only to 3.84Mcps TDD. Multiple sequential paragraphs applying only to 3.84Mcps TDD are enclosed separately to enable insertion of FDD and TDD specific (or common) paragraphs between the 3.84Mcps TDD specific paragraphs.
- [1.28Mcps TDD ...] This tagging indicates that the enclosed text following the "[1.28Mcps TDD " applies only to 1.28Mcps TDD. Multiple sequential paragraphs applying only to 1.28Mcps TDD are enclosed separately to enable insertion of FDD and TDD specific (or common) paragraphs between the 1.28Mcps TDD specific paragraphs.
- [7.68Mcps TDD ...] This tagging indicates that the enclosed text following the "[7.68Mcps TDD " applies only to 7.68Mcps TDD. Multiple sequential paragraphs applying only to 7.68Mcps TDD are enclosed separately to enable insertion of FDD and TDD specific (or common) paragraphs between the 7.68Mcps TDD specific paragraphs.
- Procedure When referring to an elementary procedure in the specification the Procedure Name is written with the first letters in each word in upper case characters followed by the word "procedure", e.g. Position Calculation procedure.
- Message When referring to a message in the specification the MESSAGE NAME is written with all letters in upper case characters followed by the word "message", e.g. POSITION CALCULATION REQUEST message.

IE When referring to an information element (IE) in the specification the *Information Element Name* is written with the first letters in each word in upper case characters and all letters in Italic font followed by the abbreviation "IE", e.g. *Request Type* IE.

Value of an IE When referring to the value of an information element (IE) in the specification the "Value" is written as it is specified in clause 9.2 enclosed by quotation marks, e.g. "Abstract Syntax Error (Reject)" or "Geographical Coordinates".

5 PCAP Services

PCAP provides the signalling services between RNC and SAS that are required to fulfill the PCAP functions described in clause 7. PCAP services are categorized as follows:

- 1. Position Calculation Service: They are related to a single UE and involve the transfer of UE Positioning measurement data and UE position estimate data over the Iupc interface between the SRNC and the SAS. They utilise connectionless signalling transport provided by the Iupc signalling bearer.
- 2. Information Exchange Service: They involve the transfer of GPS or GANSS related data over the Iupc interface between the RNC and the SAS on demand, on modification, or at regular intervals. They utilise connection-oriented signalling transport provided by the Iupc signalling bearer.
- 3. SAS Centric Position Service: They are related to the capability of the SAS to determine the positioning method used for individual positioning events. In this case the SRNC may allow A-GPS, A-GANSS, OTDOA, Cell ID and U-TDOA positioning events for a single UE to be originated by the SAS via PCAP messages. They utilise connection-oriented signalling transport provided by the Iupc signalling bearer.

6 Services Expected from Signalling Transport

Signalling transport [3] shall provide the following service for the PCAP.

- Connection oriented data transfer service. This service is supported by a signalling connection between the RNC and the SAS. It shall be possible to dynamically establish and release signalling connections based on the need. Each point-to-point operation shall have its own signalling connection. The signalling connection shall provide in sequence delivery of PCAP messages. PCAP shall be notified if the signalling connection breaks.
- 2. Connectionless data transfer service. PCAP shall be notified in case a PCAP message did not reach the intended peer PCAP entity.

7 Functions of PCAP

PCAP has the following functions:

- Position Calculation. This function enables the SRNC to interact with an SAS in the process of performing a position estimate of a UE.
- Information Exchange. This function enables the RNC to obtain GPS or GANSS related data from an SAS.
- Reporting of General Error Situations. This function allows reporting of general error situations for which function specific error messages have not been defined.
- SAS Centric Position. This function enables the SRNC to interact with an SAS in the process of performing a position estimate of a UE.

The mapping between the above functions and PCAP elementary procedures is shown in the table 1.

Table 1: Mapping between functions and PCAP elementary procedures

Function	Elementary Procedure(s)
Position Calculation	a) Position Calculation
	b) Position Parameter Modification
	c) Abort
Information Exchange	a) Information Exchange Initiation
	b) Information Reporting
	c) Information Exchange Termination
	d) Information Exchange Failure
Reporting of General Error Situations	a) Error Indication
SAS Centric Position	a) Position Initiation
	b) Position Activation
	c) Position Parameter Modification
	d) Abort
	e) Position Periodic Report
	f) Position Periodic Result
	g) Position Periodic Termination

8 PCAP Procedures

8.1 Elementary Procedures

In the following tables, all EPs are divided into class 1 and class 2 EPs (see clause 3.1 for explanation of the different classes).

Table 2: Class 1

Elementary	Initiating	Successful Outcome	Unsuccessful Outcome
Procedure	Message	Response message	Response message
Position Calculation	POSITION CALCULATION REQUEST	POSITION CALCULATION RESPONSE	POSITION CALCULATION FAILURE
Information Exchange Initiation	IINFORMATION EXCHANGE INITIATION REQUEST	INFORMATION EXCHANGE INITIATION RESPONSE	INFORMATION EXCHANGE INITIATION FAILURE
Position Initiation	POSITION INITIATION REQUEST	POSITION INITIATION RESPONSE	POSITION INITIATION FAILURE
Position Activation	POSITION ACTIVATION REQUEST	POSITION ACTIVATION RESPONSE	POSITION ACTIVATION FAILURE

Elementary Procedure Message Information Reporting INFORMATION REPORT Information Exchange Termination INFORMATION EXCHANGE TERMINATION REQUEST Information Exchange Failure INFORMATION EXCHANGE **FAILURE INDICATION Error Indication ERROR INDICATION** Position Parameter Modification **POSITION PARAMETER MODIFICATION** Abort **ABORT** Position Periodic Report POSITION PERIODIC REPORT Position Periodic Result POSITION PERIODIC RESULT Position Periodic Termination **POSITION PERIODIC TERMINATION**

Table 3: Class 2

8.2 Position Calculation

8.2.1 General

The purpose of the Position Calculation procedure is to enable an SRNC to query an SAS for a position estimate of a UE. The procedure uses connectionless signalling.

8.2.2 Successful Operation




Figure 1: Position Calculation procedure, Successful Operation

The procedure is initiated with a POSITION CALCULATION REQUEST message sent from the SRNC to the SAS. When the SAS receives the POSITION CALCULATION REQUEST message, it shall calculate the UE position and, if supported and requested, velocity based on the provided measurement data. This procedure may be repeated by the SRNC as needed for periodic location. If the POSITION CALCULATION REQUEST message is part of periodic location, this message may include the *Periodic Position Calculation Info* IE to enable the SAS to better fulfill future such requests.

If the *Initial UE Position Estimate* IE is included in the POSITION CALCULATION REQUEST message, the SAS shall use this value for the calculation of the UE Position Estimate in case of A-GPS positioning methods are used. The SAS may use this value for the calculation of the UE Position when any other methods are used.

If the *Cell-ID Measured Results Sets* IE is included in the POSITION CALCULATION REQUEST message and both of the *Round Trip Time Info* IE and the *Round Trip Time Info With Type 1* IE are included in the *Cell-ID Measured Results Info List* IE, the SAS shall use the *Round Trip Time Info* IE.

If the *Horizontal Accuracy Code* IE and possibly the *Vertical Accuracy Code* IE are included in the POSITION CALCULATION REQUEST message, the SAS shall use these values in order to assess whether the resulting position estimation fulfills the requested accuracy.

If the SAS Response Time IE is included in the POSITION CALCULATION REQUEST message, the SAS shall send a POSITION CALCULATION RESPONSE message within the indicated time after reception of the POSITION CALCULATION REQUEST message.

If the *Include Velocity* IE is set to "requested" in the POSITION CALCULATION REQUEST message, the SAS shall include the *Velocity Estimate* IE, if available, in the POSITION CALCULATION RESPONSE message.

If a GANSS Measured Results IE is included in the POSITION CALCULATION REQUEST message and does not contain the GANSS Time ID IE, the SAS shall assume that the corresponding GANSS timing refers to the "Galileo" timing.

The GANSS Measured Results IE contains one or several GANSS Generic Measurement Information IEs, each of them associated with a given GANSS:

- If a *GANSS Generic Measurement Information* IE does not contain the *GANSS ID* IE, the SAS shall assume that the associated GANSS is "Galileo".
- If a *GANSS Generic Measurement Information* IE associated with "Galileo" does not contain the *GANSS Signal ID* IE, the SAS shall assume the value "Galileo L1 OS" (see [22]).

Response Message:

If the SAS was able to calculate the position estimate, it shall respond with a POSITION CALCULATION RESPONSE message.

Whenever one of the geographic area shapes *Ellipsoid point with uncertainty Ellipse* IE, *Ellipsoid point with altitude* and uncertainty *Ellipsoid* IE or *Ellipsoid Arc* IE is reported, the *Confidence* IE shall indicate the probability that the UE is located within the uncertainty region of the shape. The value of the *Confidence* IE shall be in the interval of "1" to "100".

If at least the *Horizontal Accuracy Code* IE was included in the POSITION CALCULATION REQUEST message and the calculated position estimate fulfils the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy fulfilled" shall be included in the POSITION CALCULATION RESPONSE message. If the calculated position estimate does not fulfil the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy not fulfilled" shall be included in the POSITION CALCULATION RESPONSE message.

8.2.3 Unsuccessful Operation




Figure 2: Position Calculation procedure, Unsuccessful Operation

If the SAS is unable to perform the position estimate for any reason, it shall return a POSITION CALCULATION FAILURE message to the SRNC.

Typical cause values are:

- Invalid reference information;
- Position calculation error: invalid GPS or Galileo measured results;
- Initial UE Position Estimate missing;

- Processing Overload;
- Hardware Failure;
- O&M Intervention.;
- Invalid U-TDOA measured results;
- U-TDOA positioning method not supported;
- U-TDOA positioning method not supported in specified UTRAN cell;
- SAS unable to perform U-TDOA positioning within Response Time.

8.2.4 Abnormal Conditions

If the *Vertical Accuracy Code* IE is included and the *Horizontal Accuracy Code* IE is not included in the POSITION CALCULATION REQUEST message, the SAS shall reject the procedure.

If the RRC State is indicated as being *CELL_DCH* in the POSITION CALCULATION REQUEST message and [FDD - neither the *DCH Information* IE nor the *E-DPCH Information* IE][TDD – no *DCH Information* IE] is included, the SAS shall reject the procedure using the POSITION CALCULATION FAILURE message.

If the *GPS Measured Results* IE is included in the POSITION CALCULATION REQUEST message but the *Initial UE Position Estimate* IE is not, the SAS shall return the POSITION CALCULATION FAILURE message to the SRNC.

If neither of the *GPS Measurement Results* IE, the *Cell-ID Measured Results Sets* IE nor the *OTDOA Measurement Group* IE is included in the POSITION CALCULATION REQUEST message, the SAS shall return the POSITION CALCULATION FAILURE message to the SRNC.

8.3 Information Exchange Initiation

8.3.1 General

This procedure is used by a RNC to request the initiation of an information exchange with a SAS.

This procedure uses the signalling bearer connection for the Information Exchange Context.

8.3.2 Successful Operation




Figure 3: Information Exchange Initiation procedure, Successful Operation

The procedure is initiated with an INFORMATION EXCHANGE INITIATION REQUEST message sent from RNC to SAS.

If the Information Type IE is set to 'Implicit', the SAS is responsible for selecting the type of assistance data.

Upon reception, the SAS shall provide the requested information according to the parameters given in the request. Unless specified below, the meaning of the parameters are given in other specifications.

If the *Information Exchange Object Type* IE is set to "Cell-ID Measured Results Sets" the SAS shall use the "Cell-ID Measured Results Info List" for obtaining an initial UE position estimate.

If the *GANSS-UTRAN Time Relationship Uncertainty* IE included in the INFORMATION EXCHANGE INITIATION REQUEST message does not contain the *GANSS ID* IE, the SAS shall assume that the *GANSS-UTRAN Time Relationship Uncertainty* IE is associated with "Galileo".

If the *Information Type* IE is set to "Explicit" and an *Explicit Information Item* IE is set to "GANSS Common Data", at least one of the GANSS Reference Time, GANSS Ionosphere Model or GANSS Reference Location types shall be requested.

If the *Information Type* IE is set to "Explicit" and an *Explicit Information Item* IE is set to "GANSS Generic Data", at least one of the *GANSS Real Time Integrity*, *DGANSS Corrections*, *GANSS Almanac and Satellite Health*, *GANSS Reference Measurement Information*, *GANSS UTC Model*, *GANSS Time Model* or *GANSS Navigation Mode* IEs shall be present in each *GANSS Generic Data Item* IE associated with a given GANSS.

- If the *GANSS Generic Data Item* IE does not contain the *GANSS ID* IE, the SAS shall assume that the corresponding GANSS is "Galileo".

Information Report Characteristics:

The Information Report Characteristics IE indicates how the reporting of the information shall be performed.

If the *Information Report Characteristics* IE is set to 'On-Demand', the SAS shall report the requested information immediately.

If the *Information Report Characteristics* IE is set to "Periodic", the SAS shall report the requested information immediately and then shall periodically initiate the Information Reporting procedure for all the requested information, with the requested report frequency.

If the *Information Report Characteristics* IE is set to "On-Modification", the SAS shall report the requested information immediately if available. If the requested information is not available at the moment of receiving the INFORMATION EXCHANGE INITIATION REQUEST message, but expected to become available after some acquisition time, the SAS shall initiate the Information Reporting procedure when the requested information becomes available. The SAS shall then initiate the Information Reporting procedure in accordance to the following conditions:

- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Almanac and Satellite Health", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change in the t_{oa} or WN_a parameter has occurred in almanac/health information for at least one visible satellite.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "UTC Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change in the t_{ot} or WN_t parameter has occurred in the GPS UTC model.
 - If the *Transmission TOW Indicator* IE is set to "requested", then the SAS shall include the *GPS Transmission TOW* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to 'Explicit' and the *Explicit Information Item* IE includes "Ionospheric Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the GPS ionospheric model.
 - If the *Transmission TOW Indicator* IE is set to "requested", then the SAS shall include the *GPS Transmission TOW* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Navigation Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the clock/ephemeris information for at least one visible satellite or in the list of visible satellites.
 - If the *Transmission TOW Indicator* IE is set to "requested", then the SAS shall include the *GPS Transmission TOW* IE in the INFORMATION REPORT message.

- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "DGPS Corrections", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the quality of the DGPS corrections information for at least one visible satellite or in the list of visible satellites.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Reference Time", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the time-of-week assistance information for at least one visible satellite or in the list of visible satellites.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Acquisition Assistance", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in acquisition assistance information for at least one visible satellite or in the list of visible satellites.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Real Time Integrity", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the real-time integrity status of at least one visible satellite.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "Almanac and Satellite Health SIB", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in almanac/health information for at least one visible satellite.
 - If the *Transmission TOW Indicator* IE is set to "requested", then the SAS shall include the *GPS Transmission TOW* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Almanac and Satellite Health", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change in the t_{oa} or WN_a parameter has occurred in almanac/health information for at least one visible satellite.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.
- If the Information Type IE is set to "Explicit" and the Explicit Information Item IE includes "GANSS UTC Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change in the t_{ot} or WN_t parameter has occurred in the GANSS UTC model.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to 'Explicit' and the *Explicit Information Item* IE includes "GANSS Ionospheric Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the GANSS ionospheric model.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Navigation Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the ephemeris information for at least one visible satellite or in the list of visible satellites.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Time Model", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the time information.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "DGANSS Corrections", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the quality of the DGANSS corrections information for at least one visible satellite or in the list of visible satellites.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.

- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Reference Time", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the time-of-week assistance information for at least one visible satellite or in the list of visible satellites.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Reference Measurement Information", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in acquisition assistance information for at least one visible satellite or in the list of visible satellites.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.
- If the *Information Type* IE is set to "Explicit" and the *Explicit Information Item* IE includes "GANSS Real Time Integrity", the SAS shall initiate the Information Reporting procedure for this specific Explicit Information Type when a change has occurred in the real-time integrity status of at least one visible satellite.
 - If the *GANSS Time Indicator* IE is set to "requested", then the SAS shall include the *GANSS Reference Time* IE in the INFORMATION REPORT message.
- If any of the above *Information Type* IEs becomes temporarily unavailable, the SAS shall initiate the Information Reporting procedure for this specific Information Item by indicating "Information Not Available" in the *Requested Data Value Information* IE. If the Information becomes available again, the SAS shall initiate the Information Reporting procedure for this specific Information.

Response message:

If the SAS is able to determine the information requested by the RNC, it shall respond with the INFORMATION EXCHANGE INITIATION RESPONSE message. The message shall include the same Information Exchange ID that was included in the INFORMATION EXCHANGE INITIATION REQUEST message. When the *Report Characteristics* IE is set to "On Modification" or "Periodic", the INFORMATION EXCHANGE INITIATION RESPONSE message shall contain the *Requested Data Value* IE if the data are available. When the *Report Characteristics* IE is set to "On Demand", the INFORMATION EXCHANGE INITIATION RESPONSE message shall contain the *Requested Data Value* IE.

When the response message includes data to be reported (see above), the SAS shall include at least one IE in the *Requested Data Value* IE.

If the Requested DataValue IE contains the GANSS Common Assistance Data IE, at least one of the GANSS Reference Time, GANSS Ionosphere Model or GANSS Reference Location IEs shall be present.

- If the *GANSS Reference Location* IE does not contain the *GANSS Time ID* IE, the corresponding GANSS timing refers to the "Galileo" timing.

Any GANSS Generic Assistance Data IE associated with a given GANSS included in the Requested DataValue IE shall contain at least one of the GANSS Real Time Integrity, DGANSS Corrections, GANSS Almanac and Satellite Health, GANSS Reference Measurement Information, GANSS UTC Model, GANSS Time Model or GANSS Navigation Model IEs.

- If the GANSS Generic Data Item IE does not contain the GANSS ID IE, the corresponding GANSS is "Galileo".
- The *DGANSS Corrections* IE contains one or several *DGANSS Information* IE(s), each of them associated with a GANSS Signal. A *DGANSS Information* IE for "Galileo" that does not contain the *GANSS Signal ID* IE is by default associated with "Galileo L1 OS" (see [22]).
- The *GANSS Real Time Integrity* IE contains one or several *Satellite Information* IEs, each of them associated with a satellite and a GANSS Signal. A *Satellite Information* IE for "Galileo" that does not contain the *Bad GANSS Signal ID* IE is by default associated with all the signals of the corresponding satellite (see [22]).
- The GANSS Reference Measurement Information IE is associated with a GANSS Signal. A GANSS Reference Measurement Information IE for "Galileo" that does not contain the GANSS Signal ID IE is by default associated with "Galileo L1 OS" (see [22]).

8.3.3 Unsuccessful Operation




Figure 4: Information Exchange Initiation procedure, Unsuccessful Operation

If the requested Information Type received in the *Information Type* IE indicates a type of information that SAS cannot provide, the SAS shall regard the Information Exchange Initiation procedure as failed.

If the requested information provision cannot be carried out, the SAS shall send the INFORMATION EXCHANGE INITIATION FAILURE message. The message shall include the same Information Exchange ID that was used in the INFORMATION EXCHANGE INITIATION REQUEST message and the *Cause* IE set to an appropriate value.

Typical cause values are as follows:

- Information temporarily not available;
- Information Provision not supported for the object;
- Processing Overload;
- Hardware Failure;
- O&M Intervention.

8.3.4 Abnormal Conditions

If the *Information Exchange Object Type* IE is set to "Reference Position" and the *Information Type* IE set to "Explicit" and the *Explicit Information Item* IE is set to "Reference Location" the SAS shall reject the Information Exchange Initiation procedure and shall send the INFORMATION EXCHANGE INITIATION FAILURE message.

The allowed combinations of the Information Type and Information Report Characteristics are shown in the table below marked with "X". For not allowed combinations, the SAS shall reject the Information Exchange Initiation procedure using the INFORMATION EXCHANGE INITIATION FAILURE message.

Table 3a: Allowed Information Type and Information Report Characteristics combinations

Туре	Information Report Characteristics Type		
	On Demand	Periodic	On Modification
Almanac and Satellite Health	Х	Х	X
UTC Model	X	Х	Х
Ionospheric Model	Х	Х	Х
Navigation Model	X X X	X X X	X X X
DGPS	Х	Х	Х
Corrections			
Reference Time	X X	X X	X
Acquisition Assistance		Х	X
Real Time Integrity	Х	Х	Х
Almanac and Satellite Health SIB	Х	Х	Х
Reference Location	X		
GANSS Reference Time	Х	Х	X
GANSS Ionospheric Model	Х	Х	Х
GANSS Reference Location	Х		
GANSS Real Time Integrity	Х	Х	Х
DGANSS Corrections	Х	Х	X
GANSS Almanac and Satellite Health	Х	Х	Х
GANSS Reference Measurement Information	Х	Х	Х
GANSS UTC Model	Х	Х	Х
GANSS Time Model	Х	Х	Х
GANSS Navigation Model	Х	Х	Х

8.4 Information Reporting

8.4.1 General

This procedure is used by a SAS to report the result of information requested by a RNC using the Information Exchange Initiation.

This procedure uses the signalling bearer connection for the Information Exchange Context.

8.4.2 Successful Operation




Figure 5: Information Reporting procedure, Successful Operation

If the requested information reporting criteria are met, the SAS shall initiate an Information Reporting procedure. Unless specified below, the meaning of the parameters are given in other specifications.

The *Information Exchange ID* IE shall be set to the Information Exchange ID provided by the RNC when initiating the information exchange with the Information Exchange Initiation procedure.

The Requested Data Value IE shall include at least one IE containing the data to be reported.

If the Requested DataValue IE contains the GANSS Common Assistance Data IE, at least one of the GANSS Reference Time, GANSS Ionosphere Model or GANSS Reference Location IEs shall be present.

Any GANSS Generic Assistance Data IE associated with a given GANSS included in the Requested DataValue IE shall contain at least one of the GANSS Real Time Integrity, DGANSS Corrections, GANSS Almanac and Satellite Health, GANSS Reference Measurement Information, GANSS UTC Model, GANSS Time Model or GANSS Navigation Model IEs

- If the GANSS Generic Data Item IE does not contain the GANSS ID IE, the corresponding GANSS is "Galileo".
- The *DGANSS Corrections* IE contains one or several *DGANSS Information* IE(s), each of them associated with a GANSS Signal. A *DGANSS Information* IE for "Galileo" that does not contain the *GANSS Signal ID* IE is by default associated with "Galileo L1 OS" (see [22]).
- The *GANSS Real Time Integrity* IE contains one or several *Satellite Information* IEs, each of them associated with a satellite and a GANSS Signal. A *Satellite Information* IE for "Galileo" that does not contain the *Bad GANSS Signal ID* IE is by default associated with all the signals of the corresponding satellite (see [22]).
- The *GANSS Reference Measurement Information* IE is associated with a GANSS Signal. A *GANSS Reference Measurement Information* IE for "Galileo" that does not contain the *GANSS Signal ID* IE is by default associated with "Galileo L1 OS" (see [22]).

8.4.3 Abnormal Conditions

_

8.5 Information Exchange Termination

8.5.1 General

This procedure is used by a RNC to terminate the information exchange requested using the Information Exchange Initiation.

This procedure uses the signalling bearer connection for the Information Exchange Context.

8.5.2 Successful Operation




Figure 6: Information Exchange Termination procedure, Successful Operation

This procedure is initiated with an INFORMATION EXCHANGE TERMINATION REQUEST message.

Upon reception, the SAS shall terminate the information exchange corresponding to the Information Exchange ID.

8.5.3 Abnormal Conditions

-

8.6 Information Exchange Failure

8.6.1 General

This procedure is used by a SAS to notify a RNC that the information exchange it previously requested using the Information Exchange Initiation can no longer be reported.

This procedure uses the signalling bearer connection for the Information Exchange Context.

8.6.2 Successful Operation




Figure 7: Information Exchange Failure procedure, Successful Operation

This procedure is initiated with a INFORMATION EXCHANGE FAILURE INDICATION message, sent from the SAS to the RNC, to inform the RNC that information previously requested by the Information Exchange Initiation procedure can no longer be reported. The message shall include the same Information Exchange ID that was used in the INFORMATION EXCHANGE INITIATION REQUEST message and the *Cause* IE set to an appropriate value.

Typical cause values are as follows:

- Information temporarily not available.

8.7 Error Indication

8.7.1 General

The Error Indication procedure is used by a node to report detected errors in one incoming message, provided they cannot be reported by an appropriate failure message.

8.7.2 Successful Operation




Figure 8: Error Indication procedure, SAS Originated, Successful Operation




Figure 9: Error Indication procedure, RNC Originated, Successful Operation

When the conditions defined in clause 10 are fulfilled, the Error Indication procedure is initiated by an ERROR INDICATION message sent from the receiving node. This message shall use the same mode of the signalling bearer and the same signalling bearer connection (if connection oriented) as the message that triggers the procedure.

The ERROR INDICATION message shall include either the *Cause* IE, or the *Criticality Diagnostics* IE, or both the *Cause* IE and the *Criticality Diagnostics* IE.

Typical cause values are as follows:

- Transfer Syntax Error;
- Abstract Syntax Error (Reject);
- Abstract Syntax Error (Ignore and Notify);
- Message not Compatible with Receiver State;
- Unspecified.

8.7.3 Abnormal Conditions

-

8.8 Position Initiation

8.8.1 General

This procedure is used by an SRNC to request from an SAS the position (non-periodic or periodic) of a UE using the SAS centric mode of operation.

The connection-oriented service of the signalling bearer shall be established in conjunction with this procedure.

8.8.2 Successful Operation




Figure 9a: Position Initiation procedure, Successful Operation

This procedure is initiated with a POSITION INITIATION REQUEST message sent from the SRNC to the SAS and ends with a POSITION INITIATION RESPONSE message from the SAS to the SRNC.

The POSITION INITIATION REQUEST message may contain one or several *Network Assisted GANSS Support* IE(s), each of them indicating the UE position capability with regard to GANSS.

- If a *Network Assisted GANSS Support* IE does not contain the *GANSS ID* IE, the SAS shall assume that the corresponding GANSS is "Galileo".
- If a *Network Assisted GANSS Support* IE corresponding to "Galileo" does not contain the *GANSS Signal ID* IE, the SAS shall assume that the corresponding GANSS Signal is "Galileo L1 OS" (see [22]).

Response Message:

If the POSITION INITIATION REQUEST message contains a request for direct reporting, and following completion of one or more positioning attempts, possibly using multiple positioning methods, the SAS shall pass the UE position to the SRNC in a POSITION INITIATION RESPONSE message.

If the POSITION INITIATION REQUEST message contains a request for periodic reporting, the SAS shall pass the final UE position to the SRNC in a POSITION INITIATION RESPONSE message.

Whenever one of the geographic area shapes *Ellipsoid point with uncertainty Ellipse* IE, *Ellipsoid point with altitude* and uncertainty *Ellipsoid* IE or *Ellipsoid Arc* IE is reported, the *Confidence* IE shall indicate the probability that the UE is located within the uncertainty region of the shape. The value of the *Confidence* IE shall be in the interval of "1" to "100".

If at least the *Horizontal Accuracy Code* IE was included in the POSITION INITIATION REQUEST message and the calculated position estimate fulfils the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy fulfilled" shall be included in the POSITION INITIATION RESPONSE message. If the calculated position estimate does not fulfil the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy not fulfilled" shall be included in the POSITION INITIATION RESPONSE message.

8.8.3 Unsuccessful Operation




Figure 9b: Position Initiation procedure, Unsuccessful Operation

When the SAS is unable to accept a POSITION INITIATION REQUEST message or the SAS cannot provide a position estimate in case of direct reporting, the POSITION INITIATION FAILURE message shall be sent to the SRNC.

Typical cause values are:

- Processing Overload;
- Hardware Failure;
- O&M Intervention;
- Information temporarily not available

8.8.4 Abnormal Conditions

If the *Vertical Accuracy Code* IE is included and the *Horizontal Accuracy Code* IE is not included in the POSITION INITIATION REQUEST message, the SAS shall reject the procedure.

8.9 Position Activation

8.9.1 General

The purpose of the Position Activation procedure is to enable the SAS to initiate a particular positioning method used for an individual positioning event. This procedure uses connection-oriented signalling.

8.9.2 Successful Operation




Figure 9c: Position Activation procedure, Successful Operation

The SAS initiates this procedure by sending a POSITION ACTIVATION REQUEST message to the SRNC containing the required positioning method and any assistance data and instructions associated with that positioning method. The SRNC then sends a POSITION ACTIVATION RESPONSE message to the SAS confirming the requested action and providing any information required by the requested positioning method; e.g. UE channel information for the U-TDOA positioning method or A-GPS measurements for UE assisted A-GPS. In the POSITION ACTIVATION RESPONSE message, the SRNC should include either the *UE Position Estimate Info* IE, *GPS Measurement Results* IE, *GANSS Measurement Results* IE, *Cell-ID Measured Results Sets* IE, *OTDOA Measured Results Sets* IE or *UTDOA Group* IE.

If the POSITION ACTIVATION REQUEST message contains periodic reporting information to start a periodic RNC positioning procedure (i.e., *Amount of Reporting IE* is included), the POSITION ACTIVATION RESPONSE message may be returned confirming the requested action and not including any measurements. In that case, all periodic measurement reports are conveyed using POSITION PERIODIC REPORT messages.

If the GPS Positioning Instructions IE or the GANSS Positioning Instructions IE is included in a POSITION ACTIVATION REQUEST message containing the Measurement Validity IE, the SRNC should include the Measurement Instructions Used IE in a POSITION ACTIVATION RESPONSE message if the Measurement Validity used by the SRNC is different from the Measurement Validity requested by the SAS.

If the POSITION ACTIVATION REQUEST message contains the *Position Method* IE with value "Cell ID", the *Amount of Reporting* IE shall not be included.

If the POSITION ACTIVATION REQUEST message contains the *Position Method* IE with value "Cell ID", the RNC may include the measurements requested in the *Requested Cell-ID Measurements* IE in the POSITION ACTIVATION RESPONSE message. If both of the *Round Trip Time Info* IE and the *Round Trip Time Info With Type 1* IE are included in the POSITION ACTIVATION RESPONSE message, the SAS shall use the *Round Trip Time Info* IE.

If the SRNC receives a new POSITION ACTIVATION REQUEST message before it has responded to a previous non-periodic request, the SRNC should terminate all activity for the previous request, without sending any response to the initial request, and process the new request.

If the SRNC receives a new POSITION ACTIVATION REQUEST message for UE position measurement reporting using A-GPS or A-GANSS or OTDOA (periodic or non-periodic) while it is still performing activity for a previous A-GPS or A-GANSS or OTDOA periodic request, the SRNC should terminate all activity for the previous request, including terminating the periodic measurement reporting in the UE, and should process the new request.

If the SRNC receives a new POSITION ACTIVATION REQUEST message for Cell-ID or U-TDOA positioning while it is still performing activity for a previous A-GPS or A-GANSS or OTDOA periodic request (but after returning any POSITION ACTIVATION RESPONSE for this request), the SRNC may both continue with the previous request and process the new request.

If the *GANSS Positioning* IE is included in the POSITION ACTIVATION REQUEST message and contains the *Requested Data Value* IE:

- If the GANSS Generic Assistance Data IE, associated with a given GANSS, is included in the Requested DataValue IE, it shall contain a GANSS Real Time Integrity, DGANSS Corrections, GANSS Almanac and Satellite Health, GANSS Reference Measurement Information, GANSS UTC Model, GANSS Time Model or GANSS Navigation Model IE.
 - If the *GANSS Generic Data Item* IE does not contain the *GANSS ID* IE, the corresponding GANSS is "Galileo".
 - The *DGANSS Corrections* IE contains one or several *DGANSS Information* IE(s), each of them associated with a GANSS Signal. A *DGANSS Information* IE for "Galileo" that does not contain the *GANSS Signal ID* IE is by default associated with "Galileo L1 OS" (see [22]).
 - The *GANSS Real Time Integrity* IE contains one or several *Satellite Information* IEs, each of them associated with a satellite and a GANSS Signal. A *Satellite Information* IE for "Galileo" that does not contain the *Bad GANSS Signal ID* IE is by default associated with all the signals of the corresponding satellite (see [22]).
 - The GANSS Reference Measurement Information IE is associated with a GANSS Signal. A GANSS Reference Measurement Information IE for "Galileo" that does not contain the GANSS Signal ID IE is by default associated with "Galileo L1 OS" (see [22]).

If the RRC State is indicated as being *CELL_DCH* in the POSITION ACTIVATION RESPONSE message, [FDD - either the *DCH Information* IE] or the *E-DPCH Information* IE] [TDD - the *DCH Information* IE] should be included.

If the *GANSS Measured Results* IE is included in the POSITION ACTIVATION RESPONSE message and does not contain the *GANSS Time ID* IE, the SAS shall assume that the corresponding GANSS timing refers to the "Galileo" timing.

The GANSS Measured Results IE contains one or several GANSS Generic Measurement Information IEs, each of them associated with a given GANSS:

- If a *GANSS Generic Measurement Information* IE does not contain the *GANSS ID* IE, the SAS shall assume that the associated GANSS is "Galileo".
- If a *GANSS Generic Measurement Information* IE associated with "Galileo" does not contain the *GANSS Signal ID* IE, the SAS shall assume the value "Galileo L1 OS" (see [22]).

8.9.3 Unsuccessful Operation




Figure 9d: Position Activation procedure, Unsuccessful Operation

When the SRNC is unable to accept a POSITION ACTIVATION REQUEST message, the POSITION ACTIVATION FAILURE message should be sent to the SAS.

Typical cause values are:

- Processing Overload;
- Hardware Failure;

- O&M Intervention:
- Positioning Method Not Supported
- Location Measurement Failure

8.9.4 Abnormal Conditions

_

8.10 Position Parameter Modification

8.10.1 General

The purpose of the Position Parameter Modification procedure is to inform the SAS of any relevant changes to the RF connection or other changes during a positioning event. This procedure uses connectionless signalling when invoked in RNC centric mode and connection-oriented signalling when invoked in SAS centric mode.

8.10.2 Successful Operation



Figure 9e: Position Parameter Modification procedure, Successful Operation

If the SAS receives a POSITION PARAMETER MODIFICATION message, the SAS shall apply the information to the ongoing position estimate (e.g. reconfigure LMUs for U-TDOA) or to a new positioning attempt (e.g. use new serving cell to provide A-GPS assistance data). If there is more than one signalling connection for a UE, the SRNC should send the POSITION PARAMETER MODIFICATION message on each connection. When operating in the RNC centric mode the *Transaction ID* IE should be used to associate the POSITION PARAMETER MODIFICATION message to the correct positioning event.

In the POSITION PARAMETER MODIFICATION message, only one of the *UTRAN Cell Identifier* IE or the *UTDOA GROUP* IE should be included.

The SRNC should send a POSITION PARAMETER MODIFICATION message if an RRC measurement procedure for periodic UE positioning measurement reporting in the UE has been activated by the SRNC upon reception of a POSITION ACTIVATION REQUEST message, and if there is a RRC state transition during the RRC measurement procedure, which does not result in a termination of the UE measurement reporting. The SRNC should continue to notify the SAS of such RRC state changes until the periodic position measurement reporting has been completed or terminated.

8.10.3 Abnormal Conditions

-

8.11 Abort

8.11.1 General

The purpose of the Abort procedure is to inform the SAS that the RNC is unable to continue the current positioning activity for a particular UE. This procedure uses connectionless signalling when invoked in RNC centric mode and connection-oriented signalling when invoked in SAS centric mode.

8.11.2 Successful Operation




Figure 9f: Abort procedure, Successful Operation

The SRNC should send an ABORT message when the SRNC is unable to continue positioning activity due to cell reselection that results in a different SRNC, loss of contact with the UE or any other reason. When operating in the RNC centric mode the *Transaction ID* IE should be used to associate the ABORT message to the correct positioning event.

If the SAS receives an ABORT message while in the SAS centric mode it should immediately cease positioning attempts and return a POSITION INITIATION RESPONSE message to the SRNC carrying any location estimate already obtained or a POSITION INITIATION FAILURE message if no location estimate was obtained.

If the SAS receives an ABORT message while in the RNC centric mode it should immediately cease positioning attempts and return a POSITION CALCULATION RESPONSE message to the SRNC carrying any location estimate already obtained or a POSITION CALCULATION FAILURE message if no location estimate was obtained. After sending an ABORT message the SRNC should cease positioning activity, if any.

Typical cause values are:

- Processing Overload;
- Hardware Failure;
- O&M Intervention;
- Loss of contact with the UE

8.11.3 Abnormal Conditions

-

8.12 Position Periodic Report

8.12.1 General

The purpose of the Position Periodic Report procedure is to send measurement information or UE position estimate from the SRNC to the SAS for periodic location in SAS-centric mode. This procedure uses connection-oriented signalling.

8.12.2 Successful Operation



Figure 9g: Position Periodic Report procedure, Successful Operation

This procedure is initiated with a POSITION PERIODIC REPORT message sent from the SRNC to the SAS. The POSITION PERIODIC REPORT message provides the SAS measurement information such as GPS or OTDOA measurements, or an indication of measurement failure.

The SRNC should send the first POSITION PERIODIC REPORT message one reporting interval after the POSITION ACTIVATION RESPONSE message, and should continue to send further POSITION PERIODIC REPORT messages one reporting interval after the previous POSITION PERIODIC REPORT message based on the available measurements. If the RNC can not deliver measurement information when a POSITION PERIODIC REPORT is triggered, the *Cause* IE should be included in the POSITION PERIODIC REPORT message, indicating the reason for measurement failure, e.g. "UE Positioning Error: Not enough OTDOA cells", "UE Positioning Error: Not accomplished GPS Timing of Cell Frames" or "UE Positioning Error: Undefined Error". If the *Cause* IE is included in a POSITION PERIODIC REPORT message, the *UE Position Estimate Info* IE, *Velocity Estimate* IE, *GPS Measurement Results* IE, *GANSS Measurement Results* IE, *Cell-ID Measured Results Sets* IE, and *OTDOA Measured Results Sets* IE should not be included.

If the *Cell-ID Measured Results Sets* IE is included in the POSITION PERIODIC REPORT message and both of the *Round Trip Time Info* IE and the *Round Trip Time Info With Type 1* IE are included in the *Cell-ID Measured Results Info List* IE, the SAS shall use the *Round Trip Time Info* IE.

If the *GANSS Measured Results* IE is included in the POSITION PERIODIC REPORT message and does not contain the *GANSS Time ID* IE, the SAS shall assume that the corresponding GANSS timing refers to the "Galileo" timing.

The GANSS Measured Results IE contains one or several GANSS Generic Measurement Information IEs, each of them associated with a given GANSS:

- If a *GANSS Generic Measurement Information* IE does not contain the *GANSS ID* IE, the SAS shall assume that the associated GANSS is "Galileo".
- If a *GANSS Generic Measurement Information* IE associated with "Galileo" does not contain the *GANSS Signal ID* IE, the SAS shall assume the value "Galileo L1 OS" (see [22]).

8.12.3 Abnormal Conditions

-

8.13 Position Periodic Result

8.13.1 General

The purpose of the Position Periodic Result procedure is to provide UE position estimates from the SAS to the SRNC for periodic location in SAS-centric mode. This procedure uses connection-oriented signalling.

8.13.2 Successful Operation




Figure 9h: Position Periodic Result procedure, Successful Operation

This procedure is initiated with a POSITION PERIODIC RESULT message sent from the SAS to the SRNC. The POSITION PERIODIC RESULT message conveys the UE position estimate (or an indication of positioning failure) from the SAS to the SRNC.

The SAS shall send a POSITION PERIODIC RESULT message one reporting interval after the previous POSITION PERIODIC RESULT message. If the SAS can not deliver measurement information when a POSITION PERIODIC RESULT is triggered, the *Cause* IE shall be included in the POSITION PERIODIC RESULT message, indicating the reason for measurement failure, e.g. "Position Calculation error: invalid GPS measured results", "Position Calculation error: invalid Cell-ID measured results", "Position Calculation error: invalid OTDOA measured results" or "Position Calculation error: invalid U-TDOA measured results". If the *Cause* IE is included in a POSITION PERIODIC RESULT message, the *UE Position Estimate* IE, *Velocity Estimate* IE, *Position Data* IE, and *Accuracy Fulfilment Indicator* IE shall not be included.

If the *UE Position Estimate* IE is included in a POSITION PERIODIC RESULT message, the *Position Data* IE shall also be included.

Whenever one of the geographic area shapes *Ellipsoid point with uncertainty Ellipse* IE, *Ellipsoid point with altitude* and uncertainty *Ellipsoid* IE or *Ellipsoid Arc* IE is reported, the *Confidence* IE shall indicate the probability that the UE is located within the uncertainty region of the shape. The value of the *Confidence* IE shall be in the interval of "1" to "100".

If at least the *Horizontal Accuracy Code* IE was included in a POSITION INITIATION REQUEST message which initiates periodic position reporting, and the periodic position estimate included in a POSITION PERIODIC RESULT messages fulfils the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy fulfilled" shall be included. If the calculated position estimate does not fulfil the requested accuracy, the *Accuracy Fulfilment Indicator* IE with the value "requested accuracy not fulfilled" shall be included in the POSITION PERIODIC RESULT message.

8.13.3 Abnormal Conditions

_

8.14 Position Periodic Termination

8.14.1 General

The Position Periodic Termination procedure is used by a node to request terminatation of an ongoing periodic location, or to inform a node about termination of periodic location in SAS-centric mode. This procedure uses connection-oriented signalling.

8.14.2 Successful Operation




Figure 9i: Position Periodic Termination procedure, SAS Originated, Successful Operation




Figure 9k: Position Periodic Termination procedure, RNC Originated, Successful Operation

When the SAS or SRNC needs to terminate ongoing periodic location, a POSITION PERIODIC TERMINATION message is sent to the receiving node.

If an RRC measurement procedure for periodic UE positioning measurement reporting in the UE has been activated by the SRNC upon reception of a POSITION ACTIVATION REQUEST message, and if the SRNC receives a POSITION PERIODIC TERMINATION message, the SRNC should terminate the periodic UE positioning measurement reporting in the UE.

The SRNC should send a POSITION PERIODIC TERMINATION message if an RRC measurement procedure for periodic UE positioning measurement reporting in the UE has been activated by the SRNC upon reception of a POSITION ACTIVATION REQUEST message, and if the SRNC or UE terminates the measurement reporting (e.g., after RRC state transition).

8.14.3 Abnormal Conditions

-

9 Elements for PCAP Communication

9.1 Message Functional Definition and Content

9.1.1 General

Clause 9.1 presents the contents of PCAP messages in tabular format. The corresponding ASN.1 definitions are presented in clause 9.3. In case there is contradiction between the tabular format in clause 9.1 and the ASN.1 definition, the ASN.1 shall take precedence, except for the definition of conditions for the presence of conditional IEs, where the tabular format shall take precedence.

NOTE: The messages have been defined in accordance to the guidelines specified in [12].

9.1.2 Message Contents

9.1.2.1 Presence

All information elements in the message descriptions below are marked mandatory, optional or conditional according to table 4.

Table 4: Meaning of abbreviations used in PCAP messages

Abbreviation	Meaning
M	IEs marked as Mandatory (M) shall always be included in the
	message.
0	IEs marked as Optional (O) may or may not be included in the
	message.
С	IEs marked as Conditional (C) shall be included in a message only if
	the condition is satisfied. Otherwise the IE shall not be included.

9.1.2.2 Criticality

Each Information Element or Group of Information Elements may have a criticality information applied to it. Following cases are possible.

Table 5: Meaning of content within "Criticality" column

Abbreviation	Meaning
_	No criticality information is applied explicitly.
YES	Criticality information is applied. This is usable only for non- repeatable IEs
GLOBAL	The IE and all its repetitions together have one common criticality information. This is usable only for repeatable IEs.
EACH	Each repetition of the IE has its own criticality information. It is not allowed to assign different criticality values to the repetitions. This is usable only for repeatable IEs.

9.1.2.3 Range

The Range column indicates the allowed number of copies of repetitive IEs/IE groups.

9.1.2.4 Assigned Criticality

This column provides the actual criticality information as defined in clause 10.3.2, if applicable.

9.1.3 Position Calculation Request

Table 6

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.2.24		YES	reject
Transaction ID	М		9.2.2.28		_	
Initial UE Position Estimate	0		Geographical Area 9.2.2.6		YES	reject
GPS Measured Results		0 <maxnoofsets></maxnoofsets>			GLOBAL	reject
>GPS Measured Results	М		9.2.2.12		_	
Cell-ID Measured Results Sets		0 <maxnoofmea surements></maxnoofmea 			GLOBAL	reject
>Cell-ID Measured Results Info List	М		9.2.2.31		-	
OTDOA Measurement Group		01			YES	reject
>OTDOA Reference Cell Info	М		9.2.2.34		_	
>OTDOA Neighbour Cell Info List		1 <maxnoofmea sNCell></maxnoofmea 			_	
>>OTDOA Neighbour Cell Info	М		9.2.2.33		_	
>OTDOA Measured Results Sets		1 <maxnoofmea surements=""></maxnoofmea>			_	
>>OTDOA Measured Results Info List	М		9.2.2.32		_	
Horizontal Accuracy Code	0		9.2.2.38		YES	ignore
Vertical Accuracy Code	0		9.2.2.39		YES	ignore
UTDOA Group	0		9.2.2.74		YES	reject
SAS Response Time	0		Positioning Response Time 9.2.2.69	Indicates the interval allowed for a SAS response for U-TDOA positioning.	YES	ignore
Include Velocity	0		9.2.2.97		YES	ignore
Periodic Position Calculation Info	0		9.2.2.106		YES	ignore
GANSS Measured Results		0 <maxnoofsets></maxnoofsets>			GLOBAL	reject
>GANSS Measured Results	М		9.2.2.117		_	

Table 7

Range bound	Explanation
maxNoOfMeasNCell	Maximum number of neighbouring cells on which information can be reported. The value of maxNoOfMeasCell is 32.
maxNoOfSets	Maximum number of sets of Measured Results included in the Position Calculation Request message. The value for maxNoOfSets is 3.
maxNoOfMeasurements	Maximum number of Measurements of Cell-ID Measured Results Info List and OTDOA Measured Results Info List included in the Position Calculation Request message. The value for maxNoOfMeasurements is 16.

9.1.4 Position Calculation Response

Table 8

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		_	
UE Position Estimate	M		Geographical Area 9.2.2.6		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore
Accuracy Fulfilment Indicator	0		9.2.2.40		YES	ignore
Velocity Estimate	0		9.2.2.98		YES	ignore

9.1.5 POSITION CALCULATION FAILURE

Table 9

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		_	
Cause	M		9.2.2.3		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.6 Information Exchange Initiation Request

Table 10

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		_	
Information Exchange ID	M		9.2.2.19		YES	reject
CHOICE Information Exchange Object Type	М				YES	reject
>Reference Position					_	
>>Reference Position Estimate/UE Initial Position	М		Geographi cal Area 9.2.2.6	For RNC- centric mode.	-	
>Additional Information Exchange Object Types						
>>Reference Position UC-ID						
>>>UTRAN Cell Identifier/UE Initial Position	М		UTRAN Cell Identifier 9.2.2.37	For SAS- centric mode.	-	
>>Cell-ID Measured Results Sets		0 <max NoOfM easure ments></max 			GLOBAL	ignore
>>>Cell-ID Measured Results Info List	М		9.2.2.31	For SAS- centric mode.	_	
Information Type	M		9.2.2.22		YES	reject
Information Report Characteristics	М		9.2.2.21		YES	reject
GPS-UTRAN Time Relationship Uncertainty	C-GPS		9.2.2.18		YES	reject
GANSS-UTRAN Time Relationship Uncertainty	C-GANSS		9.2.2.121		YES	reject

Table 11

Condition	Explanation		
GPS	The IE shall be present if the information requested in the <i>Information Type</i> IE contains GPS-related data		
GANSS	The IE shall be present if the information requested in the <i>Information Type</i> IE contains GANSS-related data		

Table 11a

Range bound	Explanation
maxNoOfMeasurements	Maximum number of Measurements of Cell-ID Measured
	Results Sets. The value for maxNoOfMeasurements is 16.

9.1.7 Information Exchange Initiation Response

Table 12

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	М		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		_	
Information Exchange ID	M		9.2.2.19		YES	ignore
CHOICE Information Exchange Object Type	0				YES	ignore
>Reference Position					_	
>>Requested Data Value	М		9.2.2.26		_	
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.8 Information Exchange Initiation Failure

Table 13

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		_	
Information Exchange ID	М		9.2.2.19		YES	ignore
Cause	M		9.2.2.3		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.9 Information Report

Table 14

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	М		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		_	_
Information Exchange ID	M		9.2.2.19		YES	ignore
CHOICE Information Exchange Object Type	М				YES	ignore
>Reference Position					-	
>>Requested Data Value Information	M		9.2.2.27		ı	

9.1.10 Information Exchange Termination Request

Table 15

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		_	
Information Exchange ID	M		9.2.2.19		YES	ignore

9.1.11 Information Exchange Failure Indication

Table 16

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		_	
Information Exchange ID	M		9.2.2.19		YES	ignore
Cause	М		9.2.2.3		YES	ignore

9.1.12 Error Indication

Table 17

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		_	
Cause	0		9.2.2.3		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.13 POSITION INITIATION REQUEST

Table 17a

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		-	-
Request Type	M		9.2.2.50		YES	reject
UE Positioning Capability	M		9.2.2.51		YES	reject
UTRAN Cell Identifier	M		9.2.2.37		YES	reject
Vertical Accuracy Code	0		9.2.2.39		YES	ignore
Response Time	0		9.2.2.52		YES	ignore
Positioning Priority	0		9.2.2.53		YES	ignore
Client Type	0		9.2.2.54		YES	ignore
Include Velocity	0		9.2.2.97		YES	ignore
Periodic Location Info	0		9.2.2.107		YES	ignore

9.1.14 position INITIATION response

Table 17b

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		-	
UE Position Estimate	M		Geographi cal Area 9.2.2.6		YES	reject
Position Data	M		9.2.2.65		YES	ignore
Accuracy Fulfilment Indicator	0		9.2.2.40		YES	ignore
Velocity Estimate	0		9.2.2.98		YES	ignore

9.1.15 position INITIATION Failure

Table 17c

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.2.24		YES	reject
Transaction ID	М		9.2.2.28		-	
Cause	М		9.2.2.3		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.16 position activation request

Table 17d

IE/Group Name	Presence	Range	IE type and	Semantics description	Criticality	Assigned Criticality
			reference			
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		-	. ,
Positioning Method	M		9.2.2.55	Indicates the	YES	reject
RNC Response Time	IVI		Positioning Response Time 9.2.2.69	interval allowed for a RNC response, or the periodic reporting interval if Amount of Reporting IE	YES	ignore
				is present.		
Positioning Priority	0		9.2.2.53		YES	ignore
Environment Characterisation	0		9.2.2.62		YES	ignore
U-TDOA Positioning		01		Only present if Positioning Method is U- TDOA	YES	reject
>U-TDOA Bit Count	M		9.2.2.56	Used if UE is in CELL_FACH mode	-	
>U-TDOA Time Interval	M		9.2.2.57	Used if UE is in CELL_FACH mode	-	
GPS Positioning		01		Only present if Positioning Method is A- GPS	YES	reject
>GPS Positioning Instructions	М		9.2.2.101		_	
>Requested Data Value	0		9.2.2.26		_	
OTDOA Assistance Data		01		Only present if Positioning Method is OTDOA	YES	reject
>UE Positioning OTDOA Assistance data	M		9.2.2.59		_	
Include Velocity	0		9.2.2.97		YES	ignore
Amount of Reporting	0		9.2.2.108	Amount of reports for periodic reporting.	YES	ignore
Cell-ID Positioning		01		Only present if Positioning Method is Cell-ID	YES	ignore
>Requested Cell-ID Measurements	М		9.2.2.112		-	
GANSS Positioning		01		Only present if Positioning Method is GNSS	YES	reject
>GANSS Positioning Instructions	M		9.2.2.120		-	

>Requested Data Value	0	9.2.2.26	_	

9.1.17 position activation response

Table 17e

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		-	
UE Position Estimate Info	0		9.2.2.102	Position information for UE based positioning methods	YES	ignore
GPS Measured Results		0 <ma xNoOfS ets></ma 			GLOBAL	reject
>GPS Measured Results	M		9.2.2.12		_	
Cell-ID Measured Results Sets		0 <ma xNoOf Measur ements ></ma 			GLOBAL	reject
>Cell-ID Measured Results Info List	М		9.2.2.31		_	
OTDOA Measured Results Sets		0 <ma xNoOf Measur ements ></ma 			GLOBAL	reject
>OTDOA Measured Results Info List	М		9.2.2.32		_	
UTDOA Group	0		9.2.2.74		YES	reject
Velocity Estimate	0		9.2.2.98		YES	ignore
Measurement Instructions Used	0		9.2.2.109		YES	ignore
GANSS Measured Results		0 <ma xNoOfS ets></ma 			GLOBAL	reject
>GANSS Measured Results	М		9.2.2.117		_	

Table 17f

Range bound	Explanation
maxNoOfSets	Maximum number of sets of Measured Results included in the Position Activation Response message. The value for maxNoOfSets is 3.
maxNoOfMeasurements	Maximum number of Measurements of Cell-ID Measured Results Info List and OTDOA Measured Results Info List included in the Position Activation Response message. The value for maxNoOfMeasurements is 16.

9.1.18 position ACTIVATION Failure

Table 17g

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	reject
Transaction ID	M		9.2.2.28		-	
Cause	M		9.2.2.3		YES	ignore
Criticality Diagnostics	0		9.2.2.4		YES	ignore

9.1.19 Position Parameter modification

Table 17h

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		-	
UTRAN Cell Identifier	0		9.2.2.37		YES	reject
UTDOA Group	0		9.2.2.74		YES	reject
RRC State Change	0		9.2.2.110		YES	ignore

9.1.20 ABORT

Table 17i

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		-	
Cause	M		9.2.2.3		YES	ignore

9.1.21 position Periodic Report

Table 17.k

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		-	-
UE Position Estimate Info	0		9.2.2.102		YES	ignore
Velocity Estimate	0		9.2.2.98		YES	ignore
GPS Measured Results		0 <ma xNoOfS ets></ma 			GLOBAL	ignore
>GPS Measured Results	M		9.2.2.12		_	
Cell-ID Measured Results Sets		0 <ma xNoOf Measur ements ></ma 			GLOBAL	ignore
>Cell-ID Measured Results Info List	М		9.2.2.31		_	
OTDOA Measured Results Sets		0 <ma xNoOf Measur ements ></ma 			GLOBAL	ignore
>OTDOA Measured Results Info List	М		9.2.2.32		_	
Cause	0		9.2.2.3		YES	ignore
GANSS Measured Results		0 <ma xNoOfS ets></ma 			GLOBAL	ignore
>GANSS Measured Results	М		9.2.2.117		_	

Table 17.I

Range bound	Explanation
maxNoOfSets	Maximum number of sets of Measured Results included in the
	Position Periodic Report message. The value for maxNoOfSets is 3.
maxNoOfMeasurements	Maximum number of Measurements of Cell-ID Measured Results
	Info List and OTDOA Measured Results Info List included in the
	Position Periodic Report message. The value for
	maxNoOfMeasurements is 16.

9.1.22 position Periodic Result

Table 17.m

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	М		9.2.2.24		YES	ignore
Transaction ID	М		9.2.2.28		-	Ğ
UE Position Estimate	0		Geographi cal Area 9.2.2.6		YES	ignore
Velocity Estimate	0		9.2.2.98		YES	ignore
Position Data	0		9.2.2.65		YES	ignore
Accuracy Fulfilment Indicator	0		9.2.2.40		YES	ignore
Cause	0		9.2.2.3		YES	ignore

9.1.23 Position Periodic Termination

Table 17.n

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M		9.2.2.24		YES	ignore
Transaction ID	M		9.2.2.28		_	
Periodic Position	0		9.2.2.111		YES	ignore
Termination Cause						

9.2 Information Element Functional Definitions and Contents

9.2.1 General

Clause 9.2 presents the PCAP IE definitions in tabular format. The corresponding ASN.1 definitions are presented in clause 9.3. In case there is contradiction between the tabular format in clause 9.2 and the ASN.1 definition, the ASN.1 shall take precedence, except for the definition of conditions for the presence of conditional elements, where the tabular format shall take precedence.

When specifying information elements which are to be represented by bitstrings, if not otherwise specifically stated in the semantics description of the concerned IE or elsewhere, the following principle applies with regards to the ordering of bits:

- The first bit (leftmost bit) contains the most significant bit (MSB);
- The last bit (rightmost bit) contains the least significant bit (LSB);
- When importing bitstrings from other specifications, the first bit of the bitstring contains the first bit of the concerned information;

9.2.2 Radio Network Layer Related IEs

9.2.2.1 Almanac and Satellite Health SIB

Table 18

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
GPS Almanac and Satellite Health	М		9.2.2.9	
SatMask	М		BIT STRING(132)	indicates the satellites that contain the pages being broadcast in this data set
LSB TOW	M		BIT STRING (8)	

9.2.2.2 Altitude and direction

Table 19

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Direction of Altitude	М		ENUMERATED (Height, Depth)	
Altitude	М		INTEGER (02 ¹⁵ -1)	The relation between the value (N) and the altitude (a) in meters it describes is $N \le a < N+1$, except for $N=2^{15}-1$ for which the range is extended to include all greater values of (a).

9.2.2.3 Cause

The purpose of the cause information element is to indicate the reason for a particular event for the whole protocol.

Table 20

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Cause Group				
>Radio Network Layer				
>Radio Network Layer >>Radio Network Layer Cause	M		ENUMERATED (invalid reference information, information temporarily not available, information provision not supported for the object, position calculation error: invalid GPS measured results,, position calculation error: invalid Cell-ID measured results, position calculation error: invalid OTDOA measured results, position calculation error: A-GPS positioning method not supported, position calculation error: Cell-ID positioning method not supported, position calculation error: OTDOA positioning method not supported, lnitial UE Position Estimate missing, position calculation error: invalid U-TDOA measured results, position calculation error: U-TDOA positioning method not supported, position calculation error: U-TDOA positioning method not supported, positioning method not supported in specified UTRAN cell, positioning method not supported, loss of contact with UE, SAS unable to perform U-TDOA positioning within Response Time, Location measurement failure, UE Positioning Error: Not enough OTDOA cells, UE Positioning Error: Not enough GPS Satellites,	
>Transport Layer			UE Positioning Error: Reference Cell not serving cell, UE Positioning Error: Not Accomplished GPS Timing of Cell Frames, UE Positioning Error: Undefined Error, position calculation error: invalid Galileo measured results, position calculation error: A-Galileo positioning method not supported, UE Positioning Error: Not enough Galileo Satellites, UE Positioning Error: Not Accomplished Galileo Timing of Cell Frames)	
>Transport Layer	N 4		ENH IMEDATED	
>>Transport Layer Cause	M		ENUMERATED (Transport Resource Unavailable, Unspecified,)	
>Protocol				
>>Protocol Cause	M		ENUMERATED (Transfer Syntax Error, Abstract Syntax Error (Reject), Abstract Syntax Error (Ignore and Notify), Message not Compatible with Receiver State, Semantic Error, Unspecified, Abstract Syntax Error (Falsely Constructed Message),)	

>Misc			
>>Misc Cause	М	ENUMERATED (Processing Overload, Hardware Failure, O&M Intervention, Unspecified,	

The meaning of the different cause values is described in the following table. In general, "not supported" cause values indicate that the concerning capability is missing. On the other hand, "not available" cause values indicate that the concerning capability is present, but insufficient resources were available to perform the requested action.

Table 21

Radio Network Layer cause	Meaning
Invalid reference information	The reference information (GPS-UTRAN Time Relationship
	Uncertainty and/or Initial UE Position Estimate) provided by the
	RNC are invalid
Information temporarily not	The information requested by RNC is temporarily not available
available	
Information Provision not supported	The SAS does not support provision of the requested information
for the object	for the concerned object types
Position calculation error: invalid	The SAS cannot calculate position due to invalid GPS measured results
GPS measured results Position calculation error: invalid	The SAS cannot calculate position due to invalid Cell-ID measured
Cell-ID measured results	results
Position calculation error: invalid	The SAS cannot calculate position due to invalid OTDOA
OTDOA measured results	measured results
Position calculation error: A-GPS	The SAS cannot calculate position because it does not support the
positioning method not supported	A-GPS positioning method
Position calculation error: Cell-ID	The SAS cannot calculate position because it does not support the
positioning method not supported	Cell-ID positioning method
Position calculation error: OTDOA	The SAS cannot calculate position because it does not support the
positioning method not supported	OTDOA positioning method
Position calculation error: invalid U-	The SAS cannot calculate position due to invalid U-TDOA
TDOA measured results	measured results
Position calculation error: U-TDOA	The SAS cannot calculate position because it does not support the
positioning method not supported Position calculation error: U-TDOA	U-TDOA positioning method The SAS cannot calculate position because it does not support the
positioning method not supported	U-TDOA positioning method in the specified UTRAN cell
in specified UTRAN cell	0-100A positioning method in the specified of than cell
Positioning method not supported	The RNC does not support the requested positioning method
Loss of contact with UE	The RNC reports that it has lost contact with the UE
SAS unable to perform U-TDOA	The SAS did not send a U-TDOA position estimate within the
positioning within Response Time	interval defined by the Response Time IE
Location measurement failure	The SRNC cannot deliver the requested positioning measurement
	due to measurement failure.
UE Positioning Error: Not enough	The SRNC cannot deliver the requested positioning measurement
OTDOA cells	due to UE positioning error reported by the UE with error reason
UE Positioning Error: Not enough	"Not enough OTDOA cells". The SRNC cannot deliver the requested positioning measurement
GPS Satellites	due to UE positioning error reported by the UE with error reason
Of O datemites	"Not enough GPS Satellites".
UE Positioning Error: Reference	The SRNC cannot deliver the requested positioning measurement
Cell not serving cell	due to UE positioning error reported by the UE with error reason
	"Reference Cell not serving cell"
UE Positioning Error: Not	The SRNC cannot deliver the requested positioning measurement
Accomplished GPS Timing of Cell	due to UE positioning error reported by the UE with error reason
Frames	"Not Accomplished GPS Timing of Cell Frames"
UE Positioning Error: Undefined	The SRNC cannot deliver the requested positioning measurement
Error	due to UE positioning error reported by the UE with error reason
Position calculation error: invalid	"Undefined Error" The SAS cannot calculate position due to invalid Galileo measured
Galileo measured results	results
Position calculation error: A-Galileo	The SAS cannot calculate position because it does not support the
positioning method not supported	A-Galileo positioning method
UE Positioning Error: Not enough	The SRNC cannot deliver the requested positioning measurement
Galileo Satellites	due to UE positioning error reported by the UE with error reason
	"Not enough Galileo Satellites".
UE Positioning Error: Not	The SRNC cannot deliver the requested positioning measurement
Accomplished Galileo Timing of	due to UE positioning error reported by the UE with error reason
Cell Frames	"Not Accomplished Galileo Timing of Cell Frames"

Transport Network Layer cause	Meaning
Transport resource unavailable	The required transport resources are not available
Unspecified	Sent when none of the above cause values applies but still the
	cause is Transport Network Layer related

Table 23

Protocol cause	Meaning
Abstract Syntax Error (Reject)	The received message included an abstract syntax error and the concerning criticality indicated "reject" (see clause 10.3)
Abstract Syntax Error (Ignore and Notify)	The received message included an abstract syntax error and the concerning criticality indicated "ignore and notify" (see clause 10.3)
Abstract syntax error (falsely	The received message contained IEs or IE groups in wrong order
constructed message)	or with too many occurrences (see clause 10.3)
Message not Compatible with Receiver State	The received message was not compatible with the receiver state (see clause 10.4)
Semantic Error	The received message included a semantic error (see clause 10.4)
Transfer Syntax Error	The received message included a transfer syntax error (see clause 10.2)
Unspecified	Sent when none of the above cause values applies but still the cause is Protocol related

Table 24

Miscellaneous cause	Meaning
Processing Overload	RNC/SAS processing overload
Hardware Failure	RNC/SAS hardware failure
O&M Intervention	Operation and Maintenance intervention related to RNC/SAS equipment
Unspecified	Sent when none of the above cause values applies and the cause is not related to any of the categories Radio Network Layer, Transport Network Layer or Protocol

9.2.2.4 Criticality Diagnostics

The *Criticality Diagnostics* IE is sent by the RNC or the SAS when parts of a received message have not been comprehended or are missing. It contains information about which IE was not comprehended or is missing.

For further details on how to use the Criticality Diagnostics IE, see annex A.

Table 25

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Procedure Code	0		INTEGER (0255)	
Triggering Message	0		ENUMERAT ED (initiating message, successful outcome, unsuccessful outcome, outcome,	The Triggering Message is used only if the Criticality Diagnostics is part of Error Indication.
Procedure Criticality	0		ENUMERAT ED (reject, ignore, notify)	This Procedure Criticality is used for reporting the Criticality of the Triggering message (Procedure).
Transaction ID Information Element	0	0 amounoof	9.2.2.28	
Criticality Diagnostics		0 <maxnoof errors=""></maxnoof>		
>IE Criticality	М		ENUMERAT ED (reject, ignore, notify)	The IE Criticality is used for reporting the criticality of the triggering IE. The value 'Ignore" shall never be used.
>IE ld	M		INTEGER (065535)	The IE Id of the not understood or missing IE as defined in the ASN.1 part of the specification.
>Repetition Number	0		INTEGER (0255)	The Repetition Number IE gives - in case of a not understood IE: The number of occurrences of the reported IE up to and including the not understood occurrence - in case of a missing IE: The number of occurrences up to but not including the missing occurrence. Note: All the counted occurrences of the reported IE must have the same top-down hierarchical message structure of IEs with assigned criticality above them.
>Message Structure	0		9.2.2.23	The Message Structure IE describes the structure where the not understood or missing IE was detected. This IE is included if the not understood IE is not the top level of the message.
>Type of Error	М		ENUMERAT ED(not understood, missing,)	

Range bound	Explanation
maxnooferrors	Maximum number of IE errors allowed to be reported with a single
	message. The value for maxnooferrors is 256.

9.2.2.5 DGPS Corrections

This IE contains DGPS corrections, which may be employed to compensate for ranging errors due to atmospheric delay, orbital modelling, and satellite clock drift.

Table 27

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
GPS TOW sec	М		INTEGER (0604799)	In seconds GPS time-of-week when the DGPS corrections were calculated
Status/Health	М		ENUMERAT ED (UDRE scale 1.0, UDRE scale 0.75, UDRE scale 0.5, UDRE scale 0.3, UDRE scale 0.2, UDRE scale 0.1, no data, invalid data)	
DPGS information	C- Status/Hea Ith	1 <maxsat ></maxsat 		
>SatID	M		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].
>IODE	M		INTEGER (0255)	
>UDRE	M		ENUMERAT ED (UDRE \(\) 1.0 m, 1.0m < UDRE \(\) 4.0m, 4.0m < UDRE \(\) 8.0m, 8.0m < UDRE)	The value in this field shall be multiplied by the UDRE Scale Factor in the IE Status/Health to determine the final UDRE estimate for the particular satellite.
>PRC	M		INTEGER (- 20472047.)	Scaling factor 0.32 Meters
>Range Rate Correction	М		INTEGER (- 127127)	Scaling factor 0.032 meters/sec

Table 28

Condition	Explanation
Status/Health	This IE shall be present if the Status/Health IE is not
	equal to "no data" or "invalid data"

Range bound	Explanation
MaxSat	Maximum number of satellites for which data is included in this IE.

9.2.2.6 Geographical Area

Geographical Area IE is used to identify an area using geographical coordinates. The reference system is the same as the one used in [11].

Table 30

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Geographical Area				
>Point				Ellipsoid point
>>Geographical Coordinates	M		9.2.2.7	
>Point With Uncertainty				Ellipsoid point with uncertainty circle
>>Geographical Coordinates	М		9.2.2.7	
>>Uncertainty Code	M		INTEGER (0127)	The uncertainty "r" expressed in meters is derived from the "Uncertainty Code" k by r = 10x(1.1 ^k -1)
>Polygon				List of Ellipsoid points
>>Polygon		1 <maxnoofpoints></maxnoofpoints>		
>>>Geographical Coordinates	M		9.2.2.7	
>Ellipsoid point with uncertainty Ellipse				
>>Geographical Coordinates	М		9.2.2.7	
>>Uncertainty Ellipse	М		9.2.2.30	
>>Confidence	М		INTEGER (0100)	In percentage
>Ellipsoid point with altitude			0100)	
>>Geographical Coordinates	М		9.2.2.7	
>>Altitude and direction	М		9.2.2.2	
>Ellipsoid point with altitude and uncertainty Ellipsoid				
>>Geographical Coordinates	М		9.2.2.7	
>>Altitude and direction	М		9.2.2.2	
>>Uncertainty Ellipse	М		9.2.2.30	
>>Uncertainty Altitude	M		INTEGER (0127)	The uncertainty altitude "h" expressed in metres is derived from the "Uncertainty Altitude" <i>k</i> , by: h=45x(1.025 ^k -1)
>>Confidence	М		INTEGER (0100)	In percentage
>Ellipsoid Arc				
>>Geographical Coordinates	М		9.2.2.7	
>>Inner radius	M		INTEGER (02 ¹⁶ -1)	The relation between the value (N) and the radius (r) in meters it describes is $5N \le r < 5(N+1)$, except for $N=2^{16}-1$ for which the range is extended to include all grater values of (r).
>>Uncertainty radius	M		INTEGER (0127)	The uncertainty "r" is derived from the "Uncertainty radius" k by r = 10x(1.1 ^k -1)

IE/Group Name	Presence	Range	IE type and reference	Semantics description
>>Offset angle	М		INTEGER (0179)	The relation between the value (N) and the angle (a) in degrees it describes is 2N≤ a <2(N+1)
>>Included angle	М		INTEGER (0179)	The relation between the value (N) and the angle (a) in degrees it describes is 2N< a ≤2(N+1)
>>Confidence	M		INTEGER (0100)	

Table 31

Range bound	Explanation
maxnoofPoints	Maximum no. of points in polygon. Value is 15.

9.2.2.7 Geographical Coordinates

This IE contains the geographical coordinates.

Table 32

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Latitude Sign	M		ENUMERATED (North, South)	
Degrees Of Latitude	M		INTEGER (02 ²³ -1)	The IE value (N) is derived by this formula: N≤2 ²³ X /90 < N+1 X being the latitude in degree (0° 90°)
Degrees Of Longitude	М		INTEGER (-2 ²³ 2 ²³ -1)	The IE value (N) is derived by this formula: N≤2 ²⁴ X /360 < N+1 X being the longitude in degree (-180°+180°)

9.2.2.8 GPS Acquisition Assistance

This IE contains parameters that enable fast acquisition of the GPS signals in UE-assisted GPS positioning.

Table 33

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
GPS TOW msec	M		INTEGER (06.048*10 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit).	_	
Satellite information		1 <ma xSat></ma 			_	
>SatID	M		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].	-	
>Doppler (0 th order term)	М		INTEGER (- 20482047)	Scaling factor 2.5Hz	-	
>Extra Doppler		01	,		-	
>>Doppler (1 st order term)	М		INTEGER (- 4221)	Scaling factor 1/42	1	
>>Doppler Uncertainty	M		ENUMERAT ED (12.5,25,50, 100,200,)	In Hz	-	
>Code Phase	M		INTEGER (01022)	In Chips, specifies the centre of the search window	-	
>Integer Code Phase	М		INTEGER (019)	Number of 1023 chip segments	-	
>GPS Bit number	M		INTEGER (03)	Specifies GPS bit number (20 1023 chip segments)	-	
>Code Phase Search Window	M		ENUMRATE D (1023,1,2,3, 4,6,8,12,16,2 4,32,48,64,9 6,128,192)	Specifies the width of the search window.	-	
>Azimuth and Elevation		01			_	
>>Azimuth	М		INTEGER (031)	Scaling factor 11.25 Degrees	-	
>>Elevation	М		INTEGER (07)	Scaling factor 11.25 Degrees	_	
UTRAN GPS Reference Time	0		9.2.2.103	This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore

Table 34

Range bound	Explanation
mMaxSat	Maximum number of satellites for which data is included in this IE.
	The value of maxSat is 16.

9.2.2.9 GPS Almanac and Satellite Health

This IE contains a reduced-precision subset of the clock and ephemeris parameters.

Table 35

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
WNa	М		BIT STRING (8)	
Satellite information		1 <maxsat Almanac></maxsat 	, ,	
>DataID	M		BIT STRING (2)	See [10]
>SatID	М		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].
>e	M		BIT STRING (16)	Eccentricity [10]
>t _{oa}	M		BIT STRING (8)	Reference Time of Almanac [10]
>δί	M		BIT STRING (16)	Correction to Inclination (semi-circles) [10]
>OMEGADOT	M		BIT STRING (16)	Rate of Right Ascension (semi-circles/sec) [10]
>SV Health	M		BIT STRING (8)	[10]
>A ^{1/2}	М		BIT STRING (24)	Semi-Major Axis (meters) ^{1/2} [10]
>OMEGA ₀	М		BIT STRING (24)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [10]
>M ₀	М		BIT STRING (24)	Mean Anomaly at Reference Time (semi-circles) [10]
>ω	M		BIT STRING (24)	Argument of Perigee (semicircles) [10]
>af ₀	М		BIT STRING (11)	apparent clock correction [10]
>af₁	M		BIT STRING (11)	apparent clock correction [10]
SV Global Health	0		BIT STRING (364)	This enables GPS time recovery and possibly extended GPS correlation intervals

Table 36

Range bound	Explanation
maxSatAlmanac	Maximum number of satellites for which data is included in this IE.
	The value of maxSatAlmanac is 32.

9.2.2.10 GPS Clock and Ephemeris Parameters

The IE contains the GPS clock information and GPS Ephemeris.

Table 37

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
C/A or P on L2	М		BIT STRING (2)	Code(s) on L2 Channel [10]
URA Index	М		BIT STRING (4)	User Range Accuracy [10]
SV Health	М		BIT STRING (6)	[10]
IODC	М		BIT STRING (10)	Issue of Data, Clock [10]
L2 P Data Flag	М		BIT STRING (1)	[10]
SF 1 Reserved	М		BIT STRING (87)	[10]
T _{GD}	М		BIT STRING (8)	Estimated group delay differential [10]
toc	М		BIT STRING (16)	apparent clock correction [10]
af ₂	М		BIT STRING (8)	apparent clock correction [10]
af ₁	М		BIT STRING (16)	apparent clock correction [10]
af ₀	М		BIT STRING (22)	apparent clock correction [10]
C _{rs}	М		BIT STRING (16)	Amplitude of the Sine Harmonic Correction Term to the Orbit Radius (meters) [10]
Δη	М		BIT STRING (16)	Mean Motion Difference From Computed Value (semi- circles/sec) [10]
M ₀	М		BIT STRING (32)	Mean Anomaly at Reference Time (semi-circles) [10]
Cuc	М		BIT STRING (16)	Amplitude of the Cosine Harmonic Correction Term To The Argument Of Latitude (radians) [10]
е	М		BIT STRING (32)	Eccentricity [10]
Cus	M		BIT STRING (16)	Amplitude of the Sine Harmonic Correction Term To The Argument Of Latitude (radians) [10]
(A) ^{1/2}	М		BIT STRING (32)	Semi-Major Axis (meters) ^{1/2} [10]
t _{oe}	М		BIT STRING (16)	Reference Time Ephemeris [10]
Fit Interval Flag	М		BIT STRING (1)	[10]
AODO	М		BIT STRING (5)	Age Of Data Offset [10]
C _{ic}	М		BIT STRING (16)	Amplitude of the Cosine Harmonic Correction Term To The Angle Of Inclination (radians) [10]
OMEGA ₀	М		BIT STRING (32)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [10]
C _{is}	М		BIT STRING (16)	Amplitude of the Sine Harmonic Correction Term To The Angle Of Inclination (radians) [10]
i ₀	М		BIT STRING (32)	Inclination Angle at Reference Time (semi-circles) [10]
Crc	М		BIT STRING (16)	Amplitude of the Cosine Harmonic Correction Term to the Orbit Radius (meters) [10]

ω	M	BIT STRING (32)	Argument of Perigee (semicircles) [10]
OMEGAdot	M	BIT STRING (24)	Rate of Right Ascension (semi- circles/sec) [10]
Idot	M	BIT STRING	Rate of Inclination Angle (semi-
		(14)	circles/sec) [10]

9.2.2.11 GPS Ionospheric Model

The IE contains fields needed to model the propagation delays of the GPS signals through the ionosphere.

Table 38

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
α_0	M		BIT STRING (8)	NOTE 1
α_1	M		BIT STRING (8)	NOTE 1
α2	M		BIT STRING (8)	NOTE 1
α3	M		BIT STRING (8)	NOTE 1
β_0	M		BIT STRING (8)	NOTE 2
β ₁	M		BIT STRING (8)	NOTE 2
β ₂	M		BIT STRING (8)	NOTE 2
β_3	M		BIT STRING (8)	NOTE 2

NOTE 1: The parameters α_n are the coefficients of a cubic equation representing the amplitude of the vertical delay [10].

NOTE 2: The parameters β_n are the coefficients of a cubic equation representing the period of the ionospheric model [10].

9.2.2.12 GPS Measured Results

The purpose of this information element is to provide reported GPS measurement information from the SRNC to the SAS.

Table 39

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
GPS TOW msec	М		INTEGER (06.048*1 0 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit).	-	
				If the UTRAN GPS reference time Result is present, this IE shall be set to 0 by the transmitter and ignored by the receiver.		
Measurement Parameters		1 <ma xSat></ma 			_	
>Satellite ID	М		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].	-	
>C/N₀	M		INTEGER (063)	The estimate of the carrier-to-noise ratio of the received signal from the particular satellite used in the measurement. It is given in units of dB-Hz (Typical levels will be in the range of 20 – 50 dB-Hz).	-	
>Doppler	М		INTEGER (-32768 32768)	Hz, scale factor 0.2.	-	
>Whole GPS Chips	М		INTEGER (01022)	Unit in GPS chips	_	
>Fractional GPS Chips	М		INTEGER (0(2 ¹⁰ -1))	Scale factor 2 ⁻¹⁰	_	
>Multipath Indicator	M		ENUMERA TED (NM, low, medium, high)	See NOTE 1	-	
>Pseudorange RMS Error	М		INTÉGER (063)	See NOTE 2	_	
UTRAN GPS Reference Time Result	0		9.2.2.104	This IE may only be present if SAS operates in SAS- centric mode.	YES	ignore

NOTE 1: Table 41 gives the mapping of the multipath indicator field.

NOTE 2: Table 42 gives the bitmapping of the Pseudorange RMS Error field.

Table 40

Range bound	Explanation
maxSat	Maximum number of satellites for which data is included in this IE.
	The value of maxSat is 16.

Table 41

Value	Multipath Indication			
NM	Not measured			
Low	MP error < 5m			
Medium	5m < MP error < 43m			
High	MP error > 43m			

Table 42

Value	Mantissa	Exponent	Floating-Point value, x _i	Pseudorange value, P
0	000	000	0.5	P < 0.5
1	001	000	0.5625	0.5 <= P < 0.5625
i	X	Υ	0.5 * (1 + x/8) * 2y	xi-1 <= P < xi
62	110	111	112	104 <= P < 112
63	111	111		112 <= P

9.2.2.13 GPS Navigation Model

This IE contain information required to manage the transfer of precise navigation data to the GPS-capable UE.

Table 43

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Satellite information		1 <maxs< td=""><td></td><td></td></maxs<>		
		at>		
>SatID	M		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].
>Satellite Status	М		ENUMERAT ED (NS_NN, ES_SN, ES_NN, REVD)	See NOTE
>GPS Clock and Ephemeris	C-Satellite		9.2.2.10	
parameters	status			

NOTE: The UE shall interpret enumerated symbols as follows.

Table 44

Value	Indication
NS_NN	New satellite, new Navigation Model
ES_SN	Existing satellite, same Navigation Model
ES_NN	Existing satellite, new Navigation Model
REVD	Reserved

Condition	Explanation
Satellite status	The IE shall be present if the Satellite Status IE is not
	set to ES_SN

Table 46

Range bound	Explanation
maxSat	Maximum number of satellites for which data is included in this IE.
	The value of maxSat is 16.

9.2.2.14 GPS Real Time Integrity

Table 47

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Bad Satellites				
Presence				
>Bad Satellites				
>>Satellite information		1 <maxno< td=""><td></td><td></td></maxno<>		
		Sat>		
>>>BadSatID	M		INTEGER	Identifies the satellite and is
			(063)	equal to (SV ID No - 1) where
				SV ID No is defined in [10].
>No Bad Satellites			NULL	

Table 48

Range bound	Explanation
maxNoSat	Maximum number of satellites for which data is included in this IE.
	The value of maxNoSat is 16.

9.2.2.15 GPS Reference Time

Table 49

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
GPS Week	М		INTEGER (01023)		ı	
GPS TOW msec	M		INTEGER (06.048*10 ⁸ -1)	GPS Time of Week in milliseconds (rounded down to the nearest millisecond unit).	_	
GPS TOW Assist		0 <maxs at></maxs 			-	
>SatID	М		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [10].	-	
>TLM Message	М		BIT STRING (14)		_	
>Anti-Spoof	М		BOOLEAN		_	
>Alert	M		BOOLEAN		_	
>TLM Reserved	M		BIT STRING (2)		1	
UTRAN GPS Reference Time	0		9.2.2.103	This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore
SFN-TOW Uncertainty	0		GPS- UTRAN Time Relationship Uncertainty 9.2.2.18	This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore
T _{UTRAN-GPS} Drift Rate	0		9.2.2.105	This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore

Table 50

Range bound	Explanation
maxSat	Maximum number of satellites for which data is included in this IE.
	The value of maxSat is 16.

9.2.2.16 GPS Transmission TOW

Table 51

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
GPS Transmission TOW			INTEGER (0604799)	The GPS time-of-week in seconds

9.2.2.17 GPS UTC Model

The UTC Model field contains a set of parameters needed to relate GPS time to Universal Time Coordinate (UTC).

Table 52

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
A ₁	M		BIT STRING (24)	sec/sec [10]
A_0	M		BIT STRING (32)	seconds [10]
t _{ot}	M		BIT STRING (8)	seconds [10]
Δt_{LS}	M		BIT STRING (8)	seconds [10]
WNt	M		BIT STRING (8)	weeks [10]
WN _{LSF}	M		BIT STRING (8)	weeks [10]
DN	M		BIT STRING (8)	days [10]
Δt_{LSF}	M		BIT STRING (8)	seconds [10]

9.2.2.18 GPS-UTRAN Time Relationship Uncertainty

This IE contains the uncertainty of the GPS and UTRAN time relationship.

Table 53

IE/Group Name	Presence	Range	IE Type and Reference	Semantics
				Description
GPS-UTRAN Time			ENUMERATED	RNC or SAS estimate
Relationship Uncertainty			(50ns, 500ns, 1us, 10us,	of uncertainty in
			1ms, 10ms, 100ms,	GPS-UTRAN time
			unreliable,)	relationship

9.2.2.19 Information Exchange ID

The Information Exchange ID uniquely identifies any requested information per RNC-SAS pair.

Table 54

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Information Exchange ID			INTEGER (0	
			2^20-1)	

9.2.2.20 Information Exchange Object Type

Void.

9.2.2.21 Information Report Characteristics

The information report characteristics define how the reporting shall be performed.

Table 56

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Information Report Characteristics Type	M		ENUMERAT ED(On Demand, Periodic, On Modification,)	
CHOICE Information Report Periodicity	C-Periodic			Indicates the frequency with which the SAS shall send broadcast data reports.
>Min				
>>Minutes	M		INTEGER (160,)	
>Hour				
>>Hours	М		INTEGER (124,)	

Table 57

Condition	Explanation
Periodic	This IE shall be present if the Information Report
	Characteristics Type IE indicates 'periodic'

9.2.2.22 Information Type

The Information Type indicates which kind of information the SAS shall provide.

Table 58

CHOICE Information Type	IE/Group Name	Presenc e	Range	IE Type and Reference	Semantics Description
Sexplicit Sexp	CHOICE Information Type				
SEXPICIT Society Soc	>Implicit				
		M		9.2.2.25	
Social Content					
Information Item	•				
NULL		M			
Satellite Health S>>>JUTG Model S>>>JUTG Model S>>>JUTG Model S>>>Transmission M 9.2.2.29 STOWN Indicator S>>>>Transmission M 9.2.2.29 STOWN Indicator S>>>>Transmission M 9.2.2.29 STOWN Indicator S>>>>Navigation Model S>>>>Transmission M 9.2.2.29 STOWN Indicator S>>>>Navigation Model S>>>>SPB M STEGER STOWN Indicator SSEMBLE SSEMBLE					
SysylTransmission				NULL	
Note					
TOW Indicator					
>>>>lonospheric Model		M		9.2.2.29	
Note					
TOW Indicator		N 4		0.0.00	
		IVI		9.2.2.29	
Number N					
TOW Indicator		N 4		0.2.2.20	
Note		IVI		9.2.2.29	
Madditional Data			0.1		
New New			01		
Week (0.1023) INTEGER (0.167) GPS time of ephemeris in hours of the latest ephemeris set		M		INTEGER	
>>>>GPS_Toe M (0.167) GPS time of ephemeris in hours of the latest ephemeris set >>>>>T-Toe limit M Integer (010) ephemeris age tolerance in hours >>>>>Satellite related data >>>>>>SatID M (063) (063) (063) (063) (063) (063) (063) (063) (063) (063) (0255)		IVI			
September Sept		М			GPS time of enhemeris in
Sysystation	/////OC	101		_	
>>>>>T-Toe limit M Integer (010) ephemeris age tolerance in hours				(007)	
>>>>Satellite related data >>>>>>SatID M INTEGER (063) Where SV ID No : 1) where SV ID No is defined in [10].	>>>>T-Toe limit	М		Integer (010)	
Telated data			0	integer (en re)	
>>>>SatID M INTEGER (063) Identifies the satellite and is equal to (SV ID No -1) where SV ID No is defined in [10]. >>>>DGPS Corrections >>>Reference Time >>>>Real Time Integrity >>>>Transmission TOW Indicator >>>>Reference Location NULL			U <maxsat></maxsat>		
(063) equal to (SV ID No - 1) where SV ID No is defined in [10].		N /		INITECED	Identifies the setallite and is
>>>>>IODE M INTEGER (0255) Issue of Data Ephemeris for (0255) SatID >>>>DGPS Corrections >>>>Reference Time NULL >>>>Acquisition NULL Assistance NULL NULL Integrity >>>>Almanac and Satellite Health SIB >>>> Transmission TOW Indicator >>>>Reference NULL This IE may only be present if SAS operates in SAScentric mode. >>>> GANSS Common Data >>>> GANSS OPERATED (Requested, Not-Requested) >>>> GANSS OPERATED (Requested) >>>> GANSS OPERATED (Requested) >>>> GANSS OPERATED (Requested)	>>>>>odiiD	IVI			equal to (SV ID No - 1) where SV ID No is defined
>>> DGPS Corrections >>> Reference Time >>> Acquisition Assistance >>> Real Time Integrity >>> Almanac and Satellite Health SIB >>>> Transmission TOW Indicator >>> Reference Location >>>> GANSS Common Data >>>> GANSS Reference Time SAS-centric mode.	>>>>>IODE	М			Issue of Data Ephemeris for
Corrections	>>>>DGP:S				Julib
>>>>Reference Time NULL >>>>Acquisition NULL Assistance NULL >>>>Real Time NULL Integrity NULL >>>>Almanac and Satellite Health SIB >>>>>Transmission M TOW Indicator NULL >>>>Reference NULL Location If SAS operates in SAScentric mode. >>>> GANSS Common Data >>>>>GANSS O Reference Time Requested, Not-Requested, Not-Requested) >>>>>GANSS O Ionosphere Model ENUMERATED(Requested)				1,022	
>>>>Acquisition Assistance >>>>Real Time Integrity >>>>Almanac and Satellite Health SIB >>>>Transmission TOW Indicator >>>> Reference Location >>>> GANSS Common Data >>>>GANSS Reference Time Requested, Not-Requested, Not-Requested)				NULL	
Assistance >>>Real Time					
Integrity >>>>Almanac and Satellite Health SIB >>>>>Transmission M 9.2.2.29 TOW Indicator >>>>Reference NULL This IE may only be present if SAS operates in SAS-centric mode. >>>> GANSS Common Data >>>> GANSS O ENUMERATED(Requested, Not-Requested) >>>> GANSS O ENUMERATED(Requested, Not-Requested) >>>> GANSS O ENUMERATED(Requested, Not-Requested, Not-Requested, Not-Requested)	I .				
>>>>Almanac and Satellite Health SIB >>>>>Transmission TOW Indicator >>>>Reference Location >>>> GANSS Common Data >>>>>GANSS Reference Time >>>> GANSS Indicator Sharp Common Data >>>>> GANSS Reference Time Sharp Common Data >>>>> GANSS Reference Time Sharp Common Data ENUMERATED(Requested, Not- Requested) Sharp Common Data Requested)	>>>Real Time			NULL	
Satellite Health SIB >>>>Transmission	Integrity				
>>>>>Transmission M 9.2.2.29 TOW Indicator NULL This IE may only be present if SAS operates in SAS-centric mode. >>>> GANSS Common Data >>>>>GANSS O ENUMERATED(Requested, Not-Requested) >>>>>GANSS O ENUMERATED(Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested)					
TOW Indicator >>>Reference Location NULL This IE may only be present if SAS operates in SAS-centric mode. >>>> GANSS Common Data >>>> GANSS Reference Time Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested)					
>>>>Reference Location NULL This IE may only be present if SAS operates in SAS-centric mode. >>>> GANSS Common Data >>>> GANSS Reference Time Requested, Not-Requested) >>>> GANSS Ionosphere Model NULL This IE may only be present if SAS operates in SAS-centric mode. ENUMERATED(Requested, Not-Requested)		M		9.2.2.29	
Location SAS operates in SAS-centric mode.				.	
Centric mode.				NULL	
>>>> GANSS Common Data >>>> GANSS O ENUMERATED(Requested, Not- Requested) >>>> GANSS O ENUMERATED(Requested, Not- Requested, Not- Requested, Not- Requested, Not- Requested, Not- Requested)	Location				
Common Data >>>>GANSS Reference Time >>>>GANSS Requested, Not-Requested) >>>>GANSS Requested) >>>>>GANSS Requested, Not-Requested, Not-Requested, Not-Requested, Not-Requested)	SSS CANCO				centric mode.
>>>>GANSS O ENUMERATED(Reference Time Requested, Not- Requested) >>>>GANSS O ENUMERATED(Ionosphere Model Requested, Not- Requested, Not- Requested)					
Reference Time Requested, Not- Requested) >>>>GANSS O ENUMERATED(Requested, Not- Requested, Not- Requested)		0		ENLIMERATED/	
Requested) >>>>GANSS O ENUMERATED(Requested, Not- Requested)					
>>>>GANSS O ENUMERATED(Ionosphere Model Requested, Not- Requested)	TOO OF THE				
Ionosphere Model Requested, Not- Requested)	>>>>GANSS	0			
Requested)		-			
	issspirors model				
	>>>>GANSS	0		ENUMERATED(

Reference Location			Requested, Not-	
Neierence Location			Requested)	
>>>GANSS Generic Data				
>>>>GANSS		1 <maxganss></maxganss>		
Generic Data Item				
>>>>GANSS ID	0		INTEGER(07)	Identifies the GANSS Coded as defined in [4].
>>>>GANSS	0			
Real Time				
Integrity				
>>>>GANSS	0		9.2.2.127	
Time Indicator				
>>>>DGANSS	0			
Corrections				
>>>>GANSS	0		9.2.2.127	
Time Indicator				
>>>>GANSS	0			
Almanac and Satellite Health				
>>>>GANSS	0		9.2.2.127	
Time Indicator	<u> </u>			
>>>>GANSS	0			
Reference				
Measurement				
Information				
>>>> GANSS	0		9.2.2.127	
Time Indicator				
>>>>GANSS UTC Model	0			
>>>>GANSS	0		9.2.2.127	
Time Indicator			9.2.2.121	
>>>>GANSS	0			
Time Model				
>>>>GNSS-	М		BIT STRING(9)	Defines the time model
GNSS Time ext				required.
				Bit 1 is the MSB and bit 9 is the LSB (see 9.2.1).
				Bit 1 stands for GPS, Bit 2 stands for Galileo.
				Other bits are reserved.
>>>>>GANSS Time Indicator	0		9.2.2.127	3.5. 2.12 6.0 (000)7001
>>>>GANSS	0			
Navigation Model				
>>>>GANSS	М		INTEGER(040	
Week			95)	
>>>>GANSS Toe	М		INTEGER(016 7)	
>>>>GANSS T-Toe Limit	М		INTEGER(010)	
>>>>Satellit		0 <maxgansss< td=""><td></td><td></td></maxgansss<>		
e Related Data		at>		
>>>>>Sat	M		INTEGER(063)	
ID				
>>>>>IOD	M		BIT STRING(10)	

Table 59

Range Bound	Explanation
maxnoofExpInfo	Maximum number of Explicit Information supported in one
	Information Exchange. The value of maxnoofExpInfo is 32.
maxSat	Maximum number of satellites for which data is included in this IE.
	The value of maxSat is 16.
maxGANSS	Maximum number of GANSS systems for which data is included in
	this IE. The value of maxGANSS is 8.
maxGANSSSat	Maximum number of satellites for which data is included in this IE.
	The value of maxGANSSSat is 32

9.2.2.23 Message Structure

The *Message Structure* IE gives information for each level with assigned criticality in an hierarchical message structure from top level down to the lowest level above the reported level for the occured error (reported in the *Information Element Criticality Diagnostics* IE).

Table 60

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Message structure		1 <maxnoo flevels></maxnoo 		The first repetition of the Message Structure IE corresponds to the top level of the message. The last repetition of the Message Structure IE corresponds to the level above the reported level for the occurred error of the message.
>IE ID	М		INTEGER (065535)	The IE ID of this level's IE containing the not understood or missing IE.
>Repetition Number	0		INTEGER (1256)	The Repetition Number IE gives, if applicable, the number of occurrences of this level's reported IE up to and including the occurrence containing the not understood or missing IE. Note: All the counted occurrences of the reported IE must have the same top-down hierarchical message structure of IEs with assigned criticality above them.

Table 61

Range bound	Explanation
maxnooflevels	Maximum no. of message levels to report. The value for
	maxnooflevels is 256.

9.2.2.24 Message Type

Message Type IE uniquely identifies the message being sent. It is mandatory for all messages.

Table 62

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Procedure Code	M		INTEGER(0255)	"1" = Position Calculation "2" = Information Exchange Initiation "3" = Information Reporting "4" = Information Exchange Termination, "5" = Information Exchange Failure "6" = Error Indication "8" = Position Parameter Modification "9" = Position Initiation "10" = Position Activation "11" = Abort
Type of Message	M		ENUMERATED (Initiating Message, Successful Outcome, Unsuccessful Outcome, Outcome)	

9.2.2.25 Method Type

Table 63

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Method Type			ENUMERATED	
			(UE_Assisted,	
			UE_Based)	

9.2.2.26 Requested Data Value

The Requested Data Value contains the relevant data concerning the ongoing information exchange, or positioning event.

Table 64

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
GPS Almanac and	0		9.2.2.9	•	_	
Satellite Health						
GPS UTC Model	0		9.2.2.17		_	
GPS Ionospheric Model	0		9.2.2.11		_	
GPS Navigation Model	0		9.2.2.13		_	
DGPS Corrections	0		9.2.2.5		_	
GPS Reference Time	0		9.2.2.15		_	
GPS Acquisition	0		9.2.2.8		_	
Assistance						
GPS Real Time Integrity	0		9.2.2.14		_	
Almanac and Satellite Health SIB	0		9.2.2.1		1	
GPS Transmission TOW	0		9.2.2.16		ı	
GPS Reference Location	0		Geo- graphical Area 9.2.2.6	This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore
GANSS Common	0				YES	ignore
Assistance Data						
>GANSS Reference Time	0		9.2.2.124		_	
>GANSS Ionospheric Model	0		9.2.2.116		_	
>GANSS Reference Location	0		Geo- graphical Area 9.2.2.6		-	
GANSS Generic Assistance Data		0 <max GANSS ></max 			GLOBAL	ignore
>GANSS ID	0		INTEGER(07)	Identifies the GANSS. Coded as defined in [4].	-	
>GANSS Real Time Integrity	0		9.2.2.122		_	
>DGANSS Corrections	0		9.2.2.113		_	
>GANSS Almanac and	0		9.2.2.114		_	
Satellite Health						
>GANSS Reference	0		9.2.2.123		_	
Measurement						
Information						
>GANSS UTC Model	0		9.2.2.126		_	
>GANSS Time Model	0		9.2.2.125		_	
>GANSS Navigation Model	0		9.2.2.118		-	

Table 64A

Range Bound	Explanation
maxGANSS	Maximum number of GANSS systems for which data is included in
	this IF. The value of maxGANSS is 8

9.2.2.27 Requested Data Value Information

The *Requested Data Value Information* IE provides information on whether or not the Requested Data Value is available in the message and also the Requested Data Value itself if available.

In case of "Periodic" and "On Modification" reporting, "Information Not Available" shall be used when at least one part of the requested information was not available at the moment of initiating the Information Reporting procedure.

Table 65

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
CHOICE Information Availability Indicator	М				_	
>Information Available					_	
>>Requested Data Value	М		9.2.2.26		_	
>Information not Available			NULL		_	

9.2.2.28 Transaction ID

The Transaction ID is used to associate all the messages belonging to the same procedure. Messages belonging to the same procedure shall use the same Transaction ID.

The Transaction ID is determined by the initiating peer of a procedure.

The Transaction ID shall uniquely identify a procedure among all ongoing parallel procedures using the same procedure code, and initiated by the same protocol peer.

Table 66

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Transaction ID Length				The Transaction ID shall be interpreted for its integer value, not for the type of encoding ("short" or "long").
>Short				
>>Transaction ID Value	M		INTEGER (0127)	
>Long				
>>Transaction ID Value	M		INTEGER (032767)	

9.2.2.29 Transmission TOW Indicator

Table 67

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Transmission TOW			ENUMERATE	
Indicator			D (requested,	
			not	
			requested)	

9.2.2.30 Uncertainty Ellipse

This IE contains the uncertainty ellipse of a geographical area.

Table 68

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Uncertainty semi-major	M		INTEGER (0127)	The uncertainty "r" is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Uncertainty semi-minor	M		INTEGER (0127)	The uncertainty "r" is derived from the "uncertainty code" k by $r = 10x(1.1^k-1)$
Orientation of major axis	M		INTEGER (089)	The relation between the IE value (N) and the angle (a) in degrees it describes is 2N≤ a <2(N+1)

9.2.2.31 Cell-ID Measured Results Info List

This IE contains the Cell-ID measurements of signals associated with one or more cells.

Table 69

IE/Group Name	Presenc e	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Cell-ID Measured Results Info		1 <maxno OfMeasNC ell></maxno 			-	
>UC-ID	М		9.2.2.37	The identifier of the measured cell.	-	
>UTRAN Access Point Position with Altitude	M		9.2.2.36	Exact geographical position of the base station antenna. If the SAS operates in SAS-centric mode, the	I	
				values of this IE shall be set to 0 by the transmitter and shall be ignored by the receiver.		
>Geographical Area	0		9.2.2.6	May only be present if the SAS operates in RNC-centric mode.	-	
>Round Trip Time Info		01		FDD only	_	
>>UE Rx-Tx Time Difference Type 2	M		INTEGER (08191)	According to mapping in [13].	_	
>>UE Positioning Measurement Quality	M		9.2.2.35	Quality of the UE Rx-Tx time difference measurement.	-	
>>Round Trip Time	М		INTEGER (032766)	According to mapping in [13].	-	
>>Extended Round Trip Time	0		INTEGER (3276710 3041)	Continuation of intervals as mapped in [13]. Included only if the Round Trip Time IE above is included with its maximum value and if the actual value is outside the possible range for the Round Trip Time IE	YES	ignore
>Rx Timing Deviation Info		01		3.84Mcps TDD only	_	
>>Rx Timing Deviation	M		INTEGER (08191)	According to mapping in [14].	_	
>>Timing Advance	М	0.1	INTEGER (063)	According to [4].	_	
>Rx Timing Deviation LCR Info	NA.	01	INITEGES	1.28Mcps TDD only	_	
>>Rx Timing Deviation LCR	M		(0511)	According to mapping in [14].	_	
>>Timing Advance LCR	М		INTEGER (02047)	According to mapping in [14].	_	

Dethless	10	1	INTEGED	Linette alD		
>Pathloss	0		INTEGER	Unit: dB	_	
			(46158)	downlink		
				pathloss as		
				defined in [4]		
				subclause		
				10.3.7.3		
>Rx Timing Deviation		01		7.68Mcps TDD	YES	reject
768Info				only		,
>>Rx Timing Deviation	М		INTEGER	According to	_	
7.68Mcps			(0 65535)	mapping in [14].		
>>Timing Advance	М		INTEGER	According to [4].	_	
7.68Mcps	IVI		(0 511)	According to [4].	_	
>Rx Timing Deviation		0.4	(0 511)	2.04Mana TDD	VEC	maia at
>RX Timing Deviation		01		3.84Mcps TDD	YES	reject
384ext Info				only		
>>Rx Timing Deviation	М		INTEGER	According to	_	
			(0 32767)	mapping in [14].		
>>Timing Advance	M		INTEGER	According to [4].	_	
			(0 255)			
>Round Trip Time Info		01	(/	FDD only	YES	ignore
With Type 1		0,		1 DD 01y	. 20	1911010
>>UE Rx-Tx Time	М		INTEGER	According to		
	IVI				_	
Difference Type 1			(7681280	mapping in [13].		
)			
>>Round Trip Time	M		INTEGER	According to	_	
			(032766)	mapping in [13].		
>>Extended Round	0		ÎNTEGER	Continuation of	_	
Trip Time			(3276710	intervals as		
The time			3041)	mapped in [13].		
			3041)			
				Included only if		
				the Round Trip		
				Time IE above is		
				included with its		
				maximum value		
				and if the actual		
				value is outside		
		1	1	the possible		
		1	1	range for the		
				Dought Trin Time		
		1	1	Round Trip Time		
		 	1	IE .		
>Additional UE		01	1	FDD only	YES	ignore
Measurement Info						
>>CPICH RSCP	0		INTEGER	According to	_	
		1	(-591)	CPICH_RSCP		
		1	` ′	in [13].		
>>CPICH Ec/N0	0	1	INTEGER	According to	_	
//OI IOI I E0/NO	~	1	(049)	CPICH_Ec/No in	_ _	
			(049)	[13].		
	1	1	1	1.11.31	i e	

Range bound	Explanation
maxNoOfMeasNCell	Maximum number of neighbour cells on which information can be
	reported. The value of maxNoOfMeasNCell is 32.

9.2.2.32 OTDOA Measured Results Info List

This IE contains the OTDOA measurements of signals sent from the reference and neighbour cells.

Table 71

IE/Group Name	Presenc e	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
OTDOA Measured Results Info		1 <maxno ofMeasNC ell></maxno 			-	
>UC-ID	M		9.2.2.37	The identifier of the neighbour cell.	-	
>UE SFN-SFN Observed Time Difference Type 2 Info		1			_	
>>SFN-SFN Observed Time Difference Type 2	M		INTEGER (040961)	Gives the observed timing of the neighbour cell relative to the reference cell.	-	
>>UE Positioning Measurement Quality	М		9.2.2.35	Quality of the observed time difference measurement.	-	
>>Measurement Delay	M		INTEGER (065535)	The interval of time, in units of 10ms frames, spanning the following two events:	-	
				1) Time of applicability of the SFN-SFN Value or TUTRAN-GPS/SFN relationship provided for the corresponding neighbour cell in 9.2.2.33 or TUTRAN-GANSS/SFN relationship provided for the corresponding		
				neighbour cell in 9.2.2.33.		
				2) The point in time when this corresponding SFN-SFN observed time difference measurement was captured by the UE.		
				If the SAS operates in SAS-centric mode, 1) above shall be set to zero. I.e., in SAS-centric mode this IE		

			indicates the SFN during which the corresponding SFN-SFN observed time difference measurement was captured by the UE.		
>Additional OTDOA Measured Results	0		This IE may only be present if SAS operates in SAS-centric mode.	YES	ignore
>>Primary CPICH Info	М	Primary Scrambling Code 9.2.2.46	The identifier of the neighbour cell.	1	

Range bound	Explanation
MaxNoOfMeasNCell	Maximum number of neighbouring cells on which information can be
	reported. The value of MaxNoOfMeasNCell is 32.

9.2.2.33 OTDOA Neighbour Cell Info

Table 73

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
UC-ID	М		9.2.2.37	The identifier of the neighbour cell.
UTRAN Access Point Position with Altitude	М		9.2.2.36	Exact geographical position of the base station antenna.
CHOICE Relative Timing Difference Info	М			
>SFN-SFN Measurement				
Value Information				
>>SFN-SFN Value	M		INTEGER (0614399)	
>>SFN-SFN Quality	0		INTEGER (0255)	Indicates the standard deviation (std) of the SFN-SFN otd (observed time difference) measurements in 1/16 chip. SFN-SFN Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported SFN-SFN Value, where x is the reported SFN-SFN Value and μ = $E[x]$ is the expectation value of x.
>>SFN-SFN Drift Rate	М		INTEGER (-100+100)	Indicates the SFN-SFN drift rate in 1/256 chip per second. A positive value indicates that the Reference cell clock is running at a greater frequency than the measured neighbouring cell.
>>SFN-SFN Drift Rate Quality	0		INTEGER (0100)	Indicates the standard deviation (std) of the SFN-SFN drift rate measurements in 1/256 chip per second. SFN-SFN Drift Rate Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported SFN-SFN Drift Rate, where x is the reported SFN-SFN Drift Rate and $\mu = E[x]$ is the expectation value of x.
>T _{UTRAN-GPS} Measurement Value Information				
>>SFN	М		INTEGER (04095)	SFN during which the T _{UTRAN-GPS} measurement was performed
>>T _{UTRAN-GPS}		1		Indicates the UTRAN GPS Timing of Cell Frame for LCS.
>>>MS	М		INTEGER (016383)	Most significant part
>>>LS	М		INTEGER (042949672 95)	Least significant part
>>Tutran-gps Quality	0		INTEGER (0255)	Indicates the standard deviation (std) of the $T_{UTRAN-GPS}$ measurements in 1/16 chip. $T_{UTRAN-GPS}$ Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported $T_{UTRAN-GPS}$ Value, where x is the reported $T_{UTRAN-GPS}$ Value and $\mu = E[x]$ is the expectation value of x.
>>Tutran-gps Drift Rate	М		INTEGER (-50+50)	Indicates the T _{UTRAN-GPS} drift rate in 1/256 chip per second. A positive value indicates that

	I	1		La LITOAN L
				the UTRAN clock is running at a lower frequency than GPS clock.
T D''(D)			INITEGED	
>>Tutran-gps Drift Rate Quality	0		INTEGER (050)	Indicates the standard deviation (std) of the $T_{UTRAN-GPS}$ drift rate measurements in 1/256 chip per second. $T_{UTRAN-GPS}$ Drift Rate Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported $T_{UTRAN-GPS}$ Drift Rate, where x is the reported $T_{UTRAN-GPS}$ Drift Rate and $\mu = E[x]$ is the
				expectation value of x.
>T _{UTRAN-GANSS} Measurement Value Information				
>>GANSS ID	0		INTEGER (07)	Identifies a GANSS Coded as defined in [4].
>>SFN	M		INTEGER (04095)	SFN during which the T _{UTRAN-} GANSS measurement was performed
>>T _{UTRAN-GANSS}		1		Indicates the UTRAN GANSS Timing of Cell Frame for LCS.
>>>MS	М		INTEGER(0 16383)	Most significant part
>>>LS	М		INTEGER(0 4294967295)	Least significant part
>>Tutran-ganss Quality	0		INTEGER(0 255)	Indicates the standard deviation (std) of the $T_{UTRAN-GANSS}$ measurements in 1/16 chip. $T_{UTRAN-GANSS}$ Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported $T_{UTRAN-GANSS}$ Value, where x is the reported $T_{UTRAN-GANSS}$ Value and $\mu = E[x]$ is the expectation value of x.
>>T _{UTRAN-GANSS} Drift Rate	M		INTEGER(- 5050)	Indicates the T _{UTRAN-GANSS} drift rate in 1/256 chip per second. A positive value indicates that the UTRAN clock is running at a lower frequency than GANSS clock.
>>Tutran-ganss Drift Rate Quality	0		INTEGER(0 50)	Indicates the standard deviation (std) of the $T_{UTRAN-GANSS}$ drift rate measurements in 1/256 chip per second. $T_{UTRAN-GANSS}$ Drift Rate Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported $T_{UTRAN-GANSS}$ Drift Rate, where x is the reported $T_{UTRAN-GANSS}$ Drift Rate and μ = $E[x]$ is the expectation value of x.

9.2.2.34 OTDOA Reference Cell Info

Table 74

IE/Group Name	Presen ce	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
UC-ID	М		9.2.2.37	The identifier of the reference cell.	-	
UTRAN Access Point Position with Altitude	M		9.2.2.36	Exact geographical position of the base station antenna.	_	
T _{UTRAN-GPS} Measurement Value Information		01			_	
>SFN	М		INTEGER (04095)	SFN during which the T _{UTRAN-GPS} measurement was performed	-	
>T _{UTRAN-GPS}		1		Indicates the UTRAN GPS Timing of Cell Frame for LCS.	_	
>>MS	М		INTEGER (016383)	Most significant part	_	
>>LS	M		INTEGER (0429496 7295)	Least significant part	_	
>Tutran-gps Quality	0		INTEGER (0255)	Indicates the standard deviation (std) of the $T_{UTRAN-GPS}$ measurements in 1/16 chip. $T_{UTRAN-GPS}$ Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported $T_{UTRAN-GPS}$ Value, where x is the reported $T_{UTRAN-GPS}$ Value and μ = $E[x]$ is the expectation value of x.	-	
>T _{UTRAN-GPS} Drift Rate	M		INTEGER (-50+50)	Indicates the T _{UTRAN-GPS} drift rate in 1/256 chip per second. A positive value indicates that the UTRAN clock is running at a lower frequency than GPS clock.	-	
>T _{UTRAN-GPS} Drift Rate Quality	0		INTEGER (050)	Indicates the standard deviation (std) of the T _{UTRAN-GPS} drift rate measurements in 1/256 chip per second. T _{UTRAN-GPS} Drift Rate Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported T _{UTRAN-GPS} Drift Rate, where x is the reported T _{UTRAN-GPS} Drift Rate and μ = $E[x]$ is the expectation value of	_	

				X.		
T _{UTRAN-GANSS} Measurement Value Information		01			GLOBAL	ignore
>GANSS ID	0		INTEGER (07)	Identifies a GANSS Coded as defined in [4]	-	
>SFN	M		INTEGER (04095)	SFN during which the T _{UTRAN-GANSS} measurement was performed	-	
>Tutran-ganss		1		Indicates the UTRAN GANSS Timing of Cell Frame for LCS.	-	
>>MS	М		INTEGER(016383)	Most significant part	-	
>>LS	М		INTEGER(04294967 295)	Least significant part	-	
>Tutran-ganss Quality	0		INTEGER(0255)	Indicates the standard deviation (std) of the T _{UTRAN} -GANSS measurements in 1/16 chip. T _{UTRAN} -GANSS Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported T _{UTRAN} -GANSS Value, where x is the reported T _{UTRAN} -GANSS Value and $\mu = E[x]$ is the expectation value of x.	1	
>T _{UTRAN-GANSS} Drift Rate	M		INTEGER(-5050)	Indicates the T _{UTRAN-GANSS} drift rate in 1/256 chip per second. A positive value indicates that the UTRAN clock is running at a lower frequency than GANSS clock.		
>Tutran-ganss Drift Rate Quality	0		INTEGER(050)	Indicates the standard deviation (std) of the T_{UTRAN} . GANSS drift rate measurements in 1/256 chip per second. T_{UTRAN} . GANSS Drift Rate Quality = $\sqrt{E[(x-\mu)^2]}$ = std of reported T_{UTRAN} . GANSS Drift Rate, where x is the reported T_{UTRAN} . GANSS Drift Rate and $\mu = E[x]$ is the expectation value of x.		

9.2.2.35 UE Positioning Measurement Quality

Table 75

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Std Resolution	М		BIT STRING (2)	Std Resolution field includes the resolution used in Std of Measurements field. Encoding on two bits as follows: '00' 10 meters '01' 20 meters '10' 30 meters '11' Reserved
Number of Measurements	M		BIT STRING (3)	The 'Number of Measurements' field indicates how many measurements have been used in the UE to determine the sample standard deviation of the measurements. Following 3 bit encoding is used: '001' 5-9 '010' 10-14 '011' 15-24 '100' 25-34 '101' 35-44 '110' 45-54 '111' 55 or more Special case: '000':In this case the field 'Std of Measurements' contains the std of the reported measurement value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and μ = $E[x]$ is the expectation value (i.e. the true value) of x. This std can be used irrespective of the number of measurements and reporting of the number of measurements is not needed. Also other measurements such as Ec/No or Rx levels can be utilised in this case to evaluate the 'Std of Measurements' reported in this IE.
Std of Measurements	M		BIT STRING (5)	Std of Measurements field includes sample standard deviation of measurements (when number of measurements is reported in 'Number of Measurements' field) or standard deviation of the reported measurement value = $\sqrt{E[(x-\mu)^2]}$, where x is the reported value and μ = $E[x]$ is the expectation value (i.e. the true value) of x (when '000' is given in 'Number of Measurements' field). Following linear 5 bit encoding is used: '00000' 0 - (R*1-1) meters '00001' R*1 - (R*2-1) meters

	'00010' R*2 – (R*3-1) meters
	'11111' R*31 meters or more where R is the resolution defined by Std Resolution field. E.g. R=20 m corresponds to 0-19 m, 20-39
	m,,620+ m.

9.2.2.36 UTRAN Access Point Position with Altitude

The UTRAN Access Point Position with Altitude indicates the exact geographical position of the base station antenna. The altitude shall be included when available.

Table 76

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Geographical Coordinates	M		9.2.2.7	
Altitude and direction	0		9.2.2.2	

9.2.2.37 UTRAN Cell Identifier (UC-ID)

The UC-ID (UTRAN Cell identifier) is the identifier of a cell in one UTRAN.

Table 77

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
RNC-ID	M		INTEGER (04095)	The identifier of one RNC in UTRAN. If the Extended RNC-ID IE is included in the UC-ID IE, the RNC-ID IE shall be ignored.	-	
C-ID	M		INTEGER (065535)	The identifier of a cell in one RNS.	_	_
Extended RNC-ID	0		9.2.2.37A	The Extended RNC-ID IE shall be used if the RNC identity has a value larger than 4095.	YES	reject

9.2.2.37A Extended RNC-ID

This is the identifier of one RNC in UTRAN.

Table 77A

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Extended RNC-ID			INTEGER(409665535)	Note: Application of the Extended RNC-ID IE to very large networks is FFS.

9.2.2.38 Horizontal Accuracy Code

Table 78

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Horizontal Accuracy Code	M		INTEGER(0127)	The requested accuracy "r" is derived from the "Horizontal Accuracy Code" k by r = 10x(1.1 ^k -1)

9.2.2.39 Vertical Accuracy Code

Table 79

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Vertical Accuracy Code	M		INTEGER(0127)	The requested accuracy "v" is derived from the "Vertical Accuracy Code" k by $v = 45x(1.025^k-1)$.

9.2.2.40 Accuracy Fulfilment Indicator

This IE indicates whether the returned position estimate satisfies the requested accuracy or not.

Table 80

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Accuracy Fulfilment Indicator	М		ENUMERATED (requested accuracy fulfilled, requested accuracy not fulfilled,)	

9.2.2.41 Uplink DPCH information

This IE indicates the Uplink DPCH information used in the U-TDOA positioning method.

Table 81

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Choice mode	M			
>FDD				
>>Scrambling code type	M		ENUMERATED	
			(short, long)	
>>Scrambling code number	M		INTEGER(016	
_			777215)	
>>TFCI existence	M		BOOLEAN	TRUE means existence.
>>Number of FBI bits	M		INTEGER(02)	In bits.
>TDD				
>>Cell Parameter ID	М		9.2.2.81	
>>TFCI Coding	М		9.2.2.82	
>>Puncture Limit	M		9.2.2.76	
>>Repetition Period	M		9.2.2.84	
>>Repetition Length	M		9.2.2.83	
>>TDD DPCH Offset	М		9.2.2.85	
>>UL Timeslot Information	М		9.2.2.86	
>>Frame Offset	М		9.2.2.64	
>>Special Burst Scheduling	М		9.2.2.92	

9.2.2.42 Frequency information

This IE indicates the Frequency information used for the U-TDOA positioning method.

Table 82

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
CHOICE mode	M			
>FDD				
>>UARFCN uplink (Nu)	0		INTEGER (016383)	If this IE is not present, the default duplex distance defined for the operating frequency band shall be used [20]
>>UARFCN downlink (Nd)	М		INTEGER (0 16383)	[20]
>TDD				
>>UARFCN	М		INTEGER (0 16383)	[21]

9.2.2.43 PRACH parameters

This IE indicates the PRACH parameter used for the U-TDOA positioning method.

Table 83

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
PRACH parameters		1 <maxp< th=""><th></th><th></th></maxp<>		
		RACH>		
>PRACH information	М		9.2.2.47	
>TFS	M		9.2.2.48	
>TFCS		1 <max TFC></max 		
>>CTFC	M		9.2.2.49	

Table 84

Range bound	Explanation
maxPRACH	Maximum number of PRACHs in a cell. The value is 16.
maxTFC	Maximum number of TFC. Value is 1024.

9.2.2.44 Compressed Mode Assistance Data

This IE provides the assistance data used for the U-TDOA positioning method when the UE is operating in the compressed mode.

Table 85

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
CHOICE mode	M			
>FDD				
>>Downlink information		1		
>>>Primary Scrambling Code	М		9.2.2.65	
>>>Chip Offset	M		9.2.2.63	
>>>Frame Offset	M		9.2.2.64	
>>Uplink information		1		
>>>Transmisson Gap Pattern Sequence Information	М		9.2.2.66	
>>>Active Pattern Sequence Information	М		9.2.2.67	
>>>CFN	M		9.2.2.68	

9.2.2.45 C-RNTI

The cell RNTI (C-RNTI) identifies a UE having a RRC connection within a cell that is used for the U-TDOA positioning method.

Table 86

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
C-RNTI			BIT STRING(16)	

9.2.2.46 Primary Scrambling Code

This IE gives the DL scrambling code of a cell.

Table 87

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
Primary Scrambling Code			INTEGER(0511)	

9.2.2.47 PRACH information

This IE contains the PRACH information used for the U-TDOA positioning method.

Table 88

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE mode	M			
>FDD				
>>Available Signature	M		BIT STRING (16)	Each bit indicates availability for a signature, where the signatures are numbered "signature 0" up to "signature 15". The value 1 of a bit indicates that the corresponding signature is available and the value 0 that it is not available.
>>Available SF	M		ENUMERATED (32,64,128,256,)	In chips per symbol Defines the minimum allowed SF (i.e. the maximum rate)
>>Preamble scrambling code number	M		INTEGER(015)	Identification of scrambling code see [17]
>>Puncturing Limit	M		9.2.2.76	
>>Available Sub Channel Number	M		BIT STRING (12)	Each bit indicates availability for a subchannel, where the subchannels are numbered "subchannel 0" to "subchannel 11". The value 1 of a bit indicates that the corresponding subchannel is available and the value 0 indicates that it is not available.
>TDD				
>>Time Slot	M		9.2.2.87	
>>TDD Channelisation Code	M		9.2.2.91	
>>Max PRACH Midamble Shifts	M		9.2.2.93	
>>PRACH Midamble	M		9.2.2.94	

9.2.2.48 TFS

This IE contains the TFS parameters used for the U-TDOA positioning method.

Table 89

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Dynamic Transport Format Information		1 <maxt F></maxt 		
>RLC Size	М		INTEGER(12950 55)	Unit is bits
>Number of TBs and TTI List		1 <maxt F></maxt 		Present for every valid number of TB's (and TTI) for this RLC Size.
>>Transmission time interval	C- dynamicTT I		ENUMERATED(1 0, 20, 40, 80, dynamic,)	In ms. The value dynamic is only used in TDD mode.
>>Number of Transport blocks Semi-static Transport Format Information	M M		INTEGER(0512) 9.2.2.61	

Range bound	Explanation		
maxTF	Maximum number of Transport Formats. The value is 32.		

Table 91

Condition	Explanation
dynamicTTI	This IE shall be present if TTI IE in Semi-static Transport Format
	Information IE is set to dynamic.

9.2.2.49 CTFC

This IE identifies the TFC used for the U-TDOA positioning method.

Table 92

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE CTFC Size				
>2 bit CTFC				
>>CTFC information	M		INTEGER(03)	
>4 bit CTFC				
>>CTFC information	M		INTEGER(015)	
>6 bit CTFC				
>>CTFC information	M		INTEGER(063)	
>8 bit CTFC				
>>CTFC information	М		INTEGER(0255)	
>12 bit CTFC				
>>CTFC information	M		INTEGER(0409 5)	
>16 bit CTFC				
>>CTFC information	M		INTEGER(0655 35	
>24 bit CTFC				
>>CTFC information	M		INTEGER(0167 77215)	

9.2.2.50 Request Type

This IE contains the Request Type parameters used for SAS centric positioning method selection.

Table 93

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Event	М		ENUMERATED(S top Change of service area, Direct, Change of service area, Stop Direct,,Periodic, Stop Periodic)	Requests related to service area reporting are not supported in the current version of this specification.
Report Area	M		ENUMERATED(S ervice Area, Geographical Area,)	
Horizontal Accuracy Code	0		INTEGER(0127)	The requested accuracy "r" is derived from the "accuracy code" k by r = 10x(1.1 ^k -1).

9.2.2.51 UE Positioning Capability

This IE contains the UE Positioning Capability information used for SAS centric positioning method selection.

Table 94

IE/Group Name	Presenc e	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Standalone location method(s) supported	M		BOOLEAN	Defines if a UE can measure its location by some means unrelated to UTRAN. TRUE means supported	-	
UE based OTDOA supported	М		BOOLEAN	TRUE means supported	_	
Network Assisted GPS support	M		ENUMERA TED (Network based, UE based, Both, None,)	Defines if the UE supports network based or UE based GPS methods.	-	
Support for GPS timing of cell frames measurement	M		BOOLEAN	Defines if a UE has the capability to perform the UE GPS timing of cell frames measurement [4]. TRUE means capable	_	
Support for IPDL	M		BOOLEAN	Defines if a UE has the capability to use IPDL to enhance its 'SFN-SFN observed time difference –type 2' measurement. TRUE means supported	-	
Support for Rx-Tx time difference type2 measurement	М		BOOLEAN	TRUE means supported	-	
Support for UE assisted GPS measurement validity in CELL_PCH and URA_PCH states	M		BOOLEAN	TRUE means supported	-	
Support for SFN-SFN observed time difference type 2 measurement	М		BOOLEAN	TRUE means supported	-	
Network Assisted GANSS Support		0 <max GANSS></max 			GLOBAL	ignore
>GANSS ID	0	5.111002	INTEGER (07)	Identifies a GANSS Coded as defined in [4]	-	
>GANSS mode	M		ENUMERA TED ('Network based', 'UE based', 'Both', 'None')	Defines if the UE supports network based or UE based GANSS methods	I	
>GANSS Signal ID	0		INTEGER(03,)	Coded as defined in [4]	-	
>Support for GANSS timing of cell frames	М		BOOLEAN	Defines if a UE has the	_	

measurement			capability to perform the UE GANSS timing of cell frames measurement [4]. TRUE means capable		
>Support for GANSS Carrier-Phase Measurement	0	BOOLEAN	Defines if a UE has the capability to perform the UE GANSS Carrier-Phase Measurement. TRUE means capable	I	

Table 94A

Range Bound	Explanation
maxGANSS	Maximum number of GANSS systems for which data is included in
	this IE. The value of maxGANSS is 8.

9.2.2.52 Response Time

This IE contains the Response Time used for SAS centric mode.

Table 95

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Response Time			ENUMERATED(The value refers to [15].
			Low Delay, Delay	
			Tolerant,)	

9.2.2.53 Positioning Priority

This IE contains the Positioning Priority used for SAS centric mode.

Table 96

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Positioning Priority			ENUMERATED(High Priority, Normal Priority,)	The value refers to [15]

9.2.2.54 Client Type

This IE contains the Client Type used for SAS centric mode.

Table 97

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Client Type			ENUMERATED(Emergency Services, Value Added Services, PLMN Operator Services, Lawful Intercept Services, PLMN Operator - broadcast services, PLMN Operator - O&M, PLMN Operator - anonymous statistics, PLMN Operator - Target MS service support,)	Identifies the type of client.

9.2.2.55 Positioning Method

This IE contains the Positioning Method used for SAS centric positioning method selection.

Table 98

IE/Group Name	Presenc e	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Additional Method Type	M		9.2.2.58	Description	_	Criticality
Selected Position Method	M		ENUMERATE D(OTDOA, GPS, OTDOA or GPS, Cell ID, UTDOA, , GNSS, OTDOA or GNSS)		-	
GNSS Positioning Method	C-GNSS		BIT STRING(9)	For each bit, if set to '1', indicates that respective GNSS is allowed. Bit 1 is the MSB and bit 9 is the LSB (see 9.2.1). bit 1: GPS bit 2: Galileo bits 3-9: reserved for future GNSSes Note: Bit 1 cannot be the only one set to 1.	YES	ignore

Table 98A

Condition	Explanation
GNSS	This IE shall be present if the Selected Position Method IE value is
	set to "GNSS" or "OTDOA or GNSS"

9.2.2.56 U-TDOA Bit Count

This IE contains the recommended number of pre-coded bits to be transmitted by the UE when the U-TDOA positioning method is selected.

Table 99

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
U-TDOA Bit Count			INTEGER (05000)	Number of bits to be transmitted by the target UE

9.2.2.57 U-TDOA Time Interval

This IE contains the recommended maximum time interval for transmission of the U-TDOA Bit Count number of bits for U-TDOA positioning.

Table 100

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
U-TDOA Time Interval			INTEGER (03000)	Time in ms in which the U- TDOA Bit Count is to be transmitted by the UE

9.2.2.58 Additional Method Type

This IE contains the selected positioning method type for SAS-centric mode.

Table 101

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Additional Method Type			ENUMERATED (UE_Assisted, UE_Based, UE_Based is preferred but UE_assisted is allowed, UE_Assisted is preferred but UE_Assisted is preferred but UE_Based is allowed,)	

9.2.2.59 UE Positioning OTDOA Assistance Data

This IE contains the UE Positioning OTDOA Assistance Data used in the SAS centric mode.

Table 102

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
UE Positioning OTDOA	0				_	•
>SFN	0		INTEGER (04095)	Time stamp (SFN of Reference Cell) of the SFN-SFN relative time differences and SFN-SFN drift rates. Included if any SFN-SFN drift value is included in IE UE positioning OTDOA neighbour cell info.	-	
>CHOICE mode					_	
>>Fdd >>>Primary CPICH Information	M		Primary scrambling code 9.2.2.46		-	
>>Tdd					_	
>Frequency Info	0		9.2.2.42	Default value is the existing value of frequency information. This IE shall always be set to default value	_	
>CHOICE positioning					_	
mode						
>>UE Based	0		Reference Cell	The position of the	_	
>>> Cell position			Position 9.2.2.70	antenna that defines the cell.	_	
>>> Round Trip Time	0		INTEGER (032766)	According to mapping in [13].	_	
>>UE Assisted					_	
>UE positioning IPDL parameters	0		9.2.2.71	If this element is not included there are no idle periods present	_	
>Extended Round Trip Time	0		INTEGER (3276710304 1)	According to mapping in [13]. Included only if the Round Trip Time IE above is included with its maximum value and if the actual value is outside the possible range for the the Round Trip Time IE.	YES	ignore
UE Positioning OTDOA Neighbour Cell List	0				_	
>UE positioing OTDOA Neighbour cell info		1max CellMe as			-	
>>CHOICE mode					_	
>>>FDD	1.4		Deim		_	
>>>>Primary CPICH Information	M		Primary scrambling code 9.2.2.46		_	
>>>TDD					_	
>>Frequency Info	0		9.2.2.42	Default value is the existing value of frequency information	-	

>>UE positioning	0		9.2.2.71		_	
IPDL parameters						
>>SFN-SFN Relative	М		9.2.2.73		_	
Time difference1	'''		0.2.2.70			
>>SFN Offset Validity	0		ENUMERATE	Absence of this		
>>5FN Offset validity	U				_	
			D (false)	element means SFN		
				offset is valid. False		
				means SFN offset is		
				not valid.		
>>SFN-SFN Drift	0		ENUMERATE	Indicates the SFN-	_	
			D	SFN drift rate in 1/256		
			(0,1,2,3,4,5,8,	chip per second.		
			10,15,25,35,50	Criip per secoria.		
			,65,80,100,-1,-			
			2,-3,-4,-5,-8, -			
			10,-15,-25,-			
			35,-50,-65,-			
	<u> </u>		80,-100,)			
>>Search Window	M		ENUMERATE	In chips. If the value	_	
Size			D (c20, c40,	is X then the		
J5			c80, c160,	expected SFN-SFN		
			c320, c640,	observed time		
	1		c1280, c640,	difference is in the		
			moreThan128	range [RTD-X,		
			0,)	RTD+X] where RTD		
				is the value of the		
				field SFN-SFN		
				relative time		
				difference.		
>>CHOICE					_	
positioning mode						
>>>UE Based						
			INTEGED /	0	_	
>>>Relative	0		INTEGER (-	Seconds of angle,	_	
North			2000020000)	scale factor 0.03.		
				Relative position		
				compared to		
				reference cell.		
>>>Relative East	0		INTEGER (-	Seconds of angle,	-	
			2000020000)	scale factor 0.03.		
			2000020000)	Relative position		
				compared to		
5.1.0			INITEOED /	reference cell.		
>>>Relative	0		INTEGER (-	Relative altitude in	_	
Altitude			40004000)	meters compared to		
				ref. cell.		
>>>Fine SFN-	0		INTEGER	Gives finer resolution	_	
SFN	1		(015)			
>>>Round Trip	0		INTEGER	In chips. Included if	_	
Time	1		(032766)	cell is in active set		
>>> UE assisted	1		\302.00)	22.10 111 401110 001	_	
>>Extended Round	0		INTEGER	In chips. Included if	YES	ignore
					150	ignore
Trip Time	1		(3276710304	cell is in active set.		
			1)	Included only if the		
	1			Round Trip Time IE		
				above is included with		
	1			its maximum value		
				and if the actual value		
	1			is outside the		
				possible range for the		
	1					
				the Round Trip Time		
	1	Ī	l	IE.		

Range bound	Explanation
maxCellMeas	Maximum number of cells to measure. The value is 32.

9.2.2.60 UL TrCH information

This IE contains the UL TrCH information used for the U-TDOA positioning method.

Table 104

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Uplink transport channel type	М		ENUMERATED (DCH,USCH,)	USCH is TDD only
TFS	M		9.2.2.48	

9.2.2.61 Semi-static Transport Format Information

This IE contains the Semi-static Transport Format information used for the U-TDOA positioning method.

Table 105

IE/Group Name	Presence	Range	IE Type and	Semantics description
			Reference	
Transmission time interval	M		ENUMERATED(5,	In ms. The value dynamic is
			10, 20, 40, 80,	only used in TDD mode
			dynamic,)	
Type of channel coding	M		ENUMERATED(N	The option "No coding" is
			o coding,	only valid for TDD.
			Convolutional,	
			Turbo,)	
Coding Rate	C-Coding		ENUMERATED(1/	
			2, 1/3,)	
Rate matching attribute	M		INTEGER(1hiRM	
)	
CRC size	M		ENUMERATED(0,	In bits
			8, 12, 16, 24,)	

Table 106

Condition	Explanation
Coding	This IE shall be present if Type of channel coding IE is "Convolutional".

Table 107

Constant	Explanation	Value
HiRM	Maximum number that could be set as rate	256
	matching attribute for a transport channel	

9.2.2.62 Environment Characterisation

This IE contains the Environment Characterisation information used for the SAS centric mode.

IE/Group Name	Presence	Range	IE Type and	Semantics description
			Reference	
Environment Characterisation			ENUMERATED(hea	
			vy multipath and	
			NLOS conditions, no	
			or light multipath and	
			usually LOS	
			conditions, not	
			defined or mixed	
			environment,)	

9.2.2.63 Chip Offset

This IE contains the Chip Offset information used for the U-TDOA positioning method.

The Chip Offset is defined as the radio timing offset inside a radio frame. The Chip offset is used as offset relative to the Primary CPICH timing for the DL DPCH or for the F-DPCH.

Table 109

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Chip Offset			INTEGER(038399)	Unit: chips

9.2.2.64 Frame Offset

This IE contains the Frame Offset information used for the U-TDOA positioning method.

The Frame Offset is the required offset between the dedicated channel downlink transmission frames (CFN, Connection Frame Number) and the broadcast channel frame offset (Cell Frame Number). The Frame Offset is used in the translation between Connection Frame Number (CFN) on Iub/Iur and the least significant 8 bits of SFN (System Frame Number) on Uu. The Frame Offset is UE and cell specific

Table 110

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Frame Offset			INTEGER(0255)	Unit: Frames

9.2.2.65 Position Data

This IE provides data related to the positioning methods used and reported in the SAS centric mode.

Table 111

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Position Data					_	,
Position Data >Positioning Data Discriminator	M		BIT STRING (4)	The positioning data discriminator defines the type of data provided for each positioning method: 0000 indicates the presence of the Positioning Data Set IE (that reports the usage of each non-GANSS method that was successfully used to obtain the location estimate) 0001 indicates the presence of the GANSS Positioning Data Set IE (that reports the usage of each GANSS method that was successfully used to obtain the location estimate) and the absence of the Positioning Data Set IE 1 octet of data is provided for each positioning	-	Criticality
Decitioning Det				method included. All other values are reserved.		
>Positioning Data Set	C- ifDiscrimin ator=0				_	

>>Positioning Method and Usage		1 <max Set></max 	OCTET STRING (1)	Coding of positioning method (bits 8-4): 00000 Reserved 00001 Reserved 00010 Reserved 00011 Reserved 00101 Reserved 00101 Mobile Assisted GPS 00110 Mobile Based GPS 00111 Conventional GPS 01000 U-TDOA 01001 OTDOA 01001 IPDL 01011 RTT 01100 Cell ID 01101 to 01111 reserved for other location technologies 10000 to 11111 reserved for network specific positioning methods Coding of usage (bits 3-1): 000 Attempted unsuccessfully due to failure or interruption - not used. 001 Attempted successfully: results not used to generate location - not used. 010 Attempted successfully: results used to verify but not generate location - not used. 011 Attempted successfully: results used to generate location 100 Attempted successfully: results used to generate location 101 Attempted successfully: results used to generate location 100 Attempted successfully: case where MS supports multiple mobile based positioning methods and the actual method or methods used by the MS cannot be determined.		
>GANSS Positioning Data Set	0				YES	ignore
>> GANSS Positioning Method and Usage		1 <max GANSS Set></max 	OCTET STRING (1)	Coding of Method (Bits 8-7): 00: MS-Based 01: MS-Assisted 10: Conventional 11: Reserved Coding of GANSS ID (Bits 6-4): 000: Galileo other values reserved Coding of usage (bits 3-1):		

	011 Attempted successfully: results used to generate location 100 Attempted successfully: case where MS supports multiple mobile based positioning methods and the actual method or methods used by the MS cannot be determined.
--	--

Condition	Explanation
ifDiscriminator=0	This IE is present if the Positioning Data Discriminator IE is set to
	"0000"

Table 113

Range bound	Explanation	
maxSet	Maximum size of the data set. Value is 9.	
MaxGANSSSet	Maximum size of the data. Value is 32.	

9.2.2.66 Transmission Gap Pattern Sequence Information

This IE contains the Transmission Gap Pattern Sequence information used for the U-TDOA positioning method when the UE is operating in the compressed mode.

Table 114

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Transmission Gap Pattern Sequence Information		1 <maxtgps></maxtgps>		
>TGPS Identifier	М		INTEGER(1ma xTGPS)	Transmission Gap Pattern Sequence Identifier: Establish a reference to the compressed mode pattern sequence. Up to <maxtgps> simultaneous compressed mode pattern sequences can be used.</maxtgps>
>TGSN	M		INTEGER(014)	Transmission Gap Starting Slot Number: The slot number of the first transmission gap slot within the TGCFN.
>TGL1	M		INTEGER(114)	The length of the first Transmission Gap within the transmission gap pattern expressed in number of slots.
>TGL2	0		INTEGER(114)	The length of the second Transmission Gap within the transmission gap pattern. If omitted, then TGL2=TGL1.
>TGD	М		INTEGER(0,15 269)	Transmission Gap Distance: indicates the number of slots between the starting slots of two consecutive transmission gaps within a transmission gap pattern. If there is only one transmission gap in the transmission gap pattern, this parameter shall be set to "0" ("0" =undefined).
>TGPL1	М		INTEGER(114 4,)	The duration of transmission gap pattern 1 in frames.
>Uplink Compressed Mode Method	M		ENUMERATED(SF/2, Higher Layer Scheduling,)	Method for generating uplink compressed mode gap.

Table 115

Range bound	Explanation
maxTGPS	Maximum number of transmission gap pattern sequences. The
	value is 6.

9.2.2.67 Active Pattern Sequence Information

This IE contains the Active Pattern Sequence information used for the U-TDOA positioning method when the UE is operating in the compressed mode.

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CM Configuration Change CFN	М		CFN 9.2.2.68	
Transmission Gap Pattern Sequence Status		0 <maxtgps></maxtgps>		
>TGPS Identifier	M		INTEGER(1ma xTGPS)	If the group is not present, none of the pattern sequences are activated. References an already defined sequence.
>TGPRC	M		INTEGER(051 1)	The number of transmission gap patterns within the Transmission Gap Pattern Sequence. "0"=Infinity
>TGCFN	M		CFN 9.2.2.68	Connection Frame Number of the first frame of the first pattern 1 within the Transmission Gap Pattern Sequence.

Table 117

Range bound	Explanation			
maxTGPS	Maximum number of transmission gap pattern sequences. The			
	value is 6.			

9.2.2.68 CFN

This IE contains the CFN used for the U-TDOA positioning method when the UE is operating in the compressed mode.

Table 118

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CFN			INTEGER(0255)	

9.2.2.69 Positioning Response Time

This IE contains the Positioning Response Time information used for SAS centric mode.

Table 119

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Positioning Response Time			ENUMERATED(250, 500, 1000, 2000, 3000, 4000, 6000, 8000, 12000, 16000, 20000, 24000, 28000, 32000, 64000,)	Unit: millisecond

9.2.2.70 Reference Cell Position

Reference Cell Position IE is used to identify the position of the reference cell using geographical coordinates. The reference system is the same as the one used in [11].

Table 120

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE Geographical Area				
>Point				Ellipsoid point
>>Geographical Coordinates	М		9.2.2.7	
>Ellipsoid point with altitude				
>>Geographical Coordinates	М		9.2.2.7	
>>Altitude and direction	M	•	9.2.2.2	

9.2.2.71 UE Positioning IPDL Parameters

The UE Positioning IPDL Parameters IE is used for OTDOA in the SAS centric mode.

Table 121

IE/Group Name	Presence	Range	IE type and reference	Semantics description
CHOICE mode			10.0.0.00	
>FDD				
>>IP Spacing	М			
>>IP Length	М			
>>IP Offset	М		INTEGER(09)	
>>Seed	М		INTEGER(063)	
>TDD				
Burst Mode Parameters	0		9.2.2.72	

9.2.2.72 Burst Mode Parameters

Burst Mode Parameters IE is used for OTDOA in the SAS centric mode.

Table 122

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Burst Start	M		INTEGER(015)	
Burst Length	M		INTEGER(102 5)	
Burst Frequency	M		INTEGER(116)	

9.2.2.73 SFN-SFN Relative Time Difference1

SFN-SFN Relative Time Difference IE is used for OTDOA in the SAS centric mode

Table 123

IE/Group Name	Presence	Range	IE type and reference	Semantics description
SFN Offset	M		INTEGER	
			(04095)	
SFN-SFN-Relative Time	М		INTEGER	
Difference			(038399)	

9.2.2.74 UTDOA Group

This IE contains information used for the U-TDOA positioning method.

Table 124

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
UTRAN Cell Identifier	M		9.2.2.37	
Frequency Information	M		9.2.2.42	
Choice RRC State	M			
>CELL_DCH				
>>Uplink DPCH Information	М		9.2.2.41	
>>Compressed Mode Assistance Data	0		9.2.2.44	FDD only
>>DCH Information	01			
>>>TFCS	1 <maxtf C></maxtf 			
>>>CTFC	M		9.2.2.49	
>>>TrCH Information List	1 <maxtr CH></maxtr 			
>>>UL TrCH Information	М		9.2.2.60	
>>E-DPCH Information	01			FDD only
>>>Maximum Set of E- DPDCHs	M		9.2.2.75	
>>>Puncture Limit	M		9.2.2.76	
>>>E-TFCS Information	M		9.2.2.77	
>>>E-TTI	M		9.2.2.79	
>>>E-DPCCH Power Offset	0		9.2.2.80	
>CELL_FACH				
>>PRACH Parameters	M		9.2.2.43	
>>C-RNTI	M		9.2.2.45	
>>USCH parameters	0		9.2.2.95	TDD only

Table 125

Range bound	Explanation		
maxTFC	Maximum number of TFC. The value is 1024.		
maxTrCH	Maximum number of Transport Channels. The value is 32.		

9.2.2.75 Maximum Set of E-DPDCHs

The Maximum Set of E-DPDCHs parameter, as defined in [16], is used in UTDOA positioning method.

Table 126

IE/Group Name	Presence	Range	IE Type and	Semantics Description
			Reference	
Maximum Set of E-DPDCHs			ENUMERATED	
			(vN64, vN32,	
			vN16, vN8, vN4,	
			v2xN4, v2xN2,	
			v2xN2plus2xN4,	
)	

9.2.2.76 Puncture Limit

The Puncture Limit parameter is used in UTDOA positioning method indicating the limit in the amount of puncturing that can be applied in order to minimise the number of dedicated physical channels.

Table 127

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Puncture Limit			INTEGER (015)	Unit: % Range: 40100 % Step: 4 % 100% means no puncturing

9.2.2.77 E-DCH Transport Format Combination Set Information (E-TFCS Information)

This IE is used in UTDOA positioning method. Whereas the related Transport Block sizes are standardised in [ref is FFS] this IE gives details on the referenced Transport Block Size Table and the Reference E-TFCIs.

Table 128

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
E-DCH Transport Format Combination Set Index	M		INTEGER (14,)	Indicates which standardised E-TFCS Transport Block Size Table shall be used. The related tables are specified in [ref FFS].
Reference E-TFCI Information		0 <maxnoofrefetf Cls></maxnoofrefetf 		
>Reference E-TFCI	М		INTEGER (0127)	
>Reference E-TFCI Power Offset	М		9.2.2.78	

Table 129

Range Bound	Explanation
maxnoofRefETFCIs	Maximum number of signalled reference E-TFCIs

9.2.2.78 Reference E-TFCI Power Offset

The Reference E-TFCI Power Offset is used in UTDOA positioning method indicating how to calculate the reference E-TFC gain factor.

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Reference E-TFCI Power Offset			INTEGER (08)	According to mapping in ref. [17] subclause 4.2.1.3

9.2.2.79 E-TTI

The E-TTI parameter is used in UTDOA positioning method indicating the Transmission Time Interval for E-DPCH operation.

Table 131

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
E-TTI			ENUMERATED (2ms, 10ms,)	

9.2.2.80 E-DPCCH Power Offset

The E-DPCCH Power Offset is used in UTDOA positioning method indicating how to calculate the E-DPCCH gain factor.

Table 132

IE/Group Name	Presence	Range	IE Type and	Semantics Description
			Reference	
E-DPCCH Power Offset			INTEGER (08)	According to mapping in ref. [17] subclause 4.2.1.3.

9.2.2.81 Cell Parameter ID

The Cell Parameter ID identifies unambiguously the Code Groups, Scrambling Codes, Midambles and Toffset (see ref. [18]).

Table 133

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Cell Parameter ID			INTEGER (0127,)	

9.2.2.82 TFCI Coding

The TFCI Coding describes the way how the TFCI bits are coded. By default 1 TFCI bit is coded with 4 bits, 2 TFCI bits are coded with 8 bits, 3-5 TFCI bits are coded with 16 bits and 6-10 TFCI bits are coded with 32 bits.

Table 134

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
TFCI Coding			ENUMERATED	
			(4, 8, 16, 32,)	

9.2.2.83 Repetition Length

The Repetition Length represents the number of consecutive Radio Frames inside a Repetition Period in which the same Time Slot is assigned to the same Physical Channel see ref. [4].

Table 135

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Repetition Length			INTEGER (163)	

9.2.2.84 Repetition Period

The Repetition Period represents the number of consecutive Radio Frames after which the same assignment scheme of Time Slots to a Physical Channel is repeated. This means that if the Time Slot K is assigned to a physical channel in the Radio Frame J, it is assigned to the same physical channel also in all the Radio Frames J+n*Repetition Period (where n is an integer) see ref. [4].

Table 136

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Repetition Period			ENUMERATED	
			(1, 2, 4, 8, 16, 32,	
			64,)	

9.2.2.85 TDD DPCH Offset

The Offset represents the phase information for the allocation of a group of dedicated physical channels. The first range is used when a starting offset is not required and the TDD Physical channel offset for each DPCH in the CCTrCH shall be directly determined from the TDD DPCH Offset. The second range is used when a starting offset is required. The TDD DPCH Offset shall map to the CFN and the TDD Physical Channel Offet for each DPCH in this CCTrCH shall calculated by TDD DPCH Offset *mod* Repetition period, see ref. [4].

Table 137

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Offset Type				
>Initial Offset				
>>TDD DPCH Offset Value	M		INTEGER (0255)	
>No Initial Offset				
>>TDD DPCH Offset Value	M		INTEGER (063)	

9.2.2.86 UL Timeslot Information

The UL Timeslot Information IE provides information on the time slot allocation for an UL DPCH.

Table 138

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
UL Timeslot Information		1 <maxno ofULts></maxno 		
>Time Slot	M		9.2.2.87	
>Midamble Shift And Burst Type	М		9.2.2.88	
>TFCI Presence	M		9.2.2.89	
>UL Code Information	М		9.2.2.90	

9.2.2.87 Time Slot

The Time Slot represents the minimum time interval inside a Radio Frame that can be assigned to a Physical Channel.

Table 139

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Time Slot			INTEGER (014)	

9.2.2.88 Midamble Shift And Burst Type

This information element indicates burst type and midamble allocation.

The 256 chip midamble supports 3 different time shifts, the 512 chips midamble may support 8 or even 16 time shifts.

Three different midamble allocation schemes exist:

Default midamble: the midamble shift is selected by layer 1 depending on the associated channelisation code (DL and UL)

Common midamble: the midamble shift is chosen by layer 1 depending on the number of channelisation codes (possible in DL only)

UE specific midamble: a UE specific midamble is explicitly assigned (DL and UL)

Table 140

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Burst Type				
>Type1				
>>Midamble Configuration Burst Type 1 And 3	М		INTEGER (4, 8, 16)	As defined in [19]
>>CHOICE Midamble Allocation Mode	М			
>>>Default Midamble			NULL	
>>>Common Midamble			NULL	
>>>UE Specific Midamble				
>>Midamble Shift Long	M		INTEGER (015)	
>Type2				
>>Midamble Configuration Burst Type 2	М		INTEGER (3,6)	As defined in [19]
>>CHOICE Midamble Allocation Mode	М			
>>>Default Midamble			NULL	
>>>Common Midamble			NULL	
>>>UE Specific Midamble				
>>Midamble Shift Short	М		INTEGER (05)	
>Type3				UL only
>>Midamble Configuration Burst Type 1 And 3	М		INTEGER (4, 8, 16)	As defined in [19]
>>CHOICE Midamble Allocation Mode	М			
>>>Default Midamble			NULL	
>>>UE Specific Midamble				
>>Midamble Shift Long	М		INTEGER (015)	

9.2.2.89 TFCI Presence

The TFCI Presence parameter indicates whether the TFCI shall be included. [TDD - If it is present in the timeslot, it will be mapped to the channelisation code defined by [19].]

Table 141

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
TFCI presence			ENUMERATED (
			Present,	
			Not Present)	

9.2.2.90 TDD UL Code Information

The TDD UL Code Information IE provides information for UL Codes that have been established.

Table 142

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
TDD UL Code Information		1 <maxno ofDPCHs></maxno 		
>TDD Channelisation Code	М		9.2.2.91	

Table 143

Range Bound	Explanation
maxnoofDPCHs	Maximum number of DPCHs in one CCTrCH

9.2.2.91 TDD Channelisation Code

The Channelisation Code Number indicates which Channelisation Code is used for a given Physical Channel. In TDD the Channelisation Code is an Orthogonal Variable Spreading Factor code, that can have a spreading factor of 1, 2, 4, 8 or 16.

Table 144

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
TDD Channelisation Code			ENUMERATED ((1/1), (2/1), (2/2), (4/1), (4/4), (8/1), (8/8), (16/1), (16/16),)	

9.2.2.92 Special Burst Scheduling

This information element expresses the number of frames between special burst transmissions during DTX.

Table 145

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Special Burst Scheduling			INTEGER (1256)	Number of frames between special burst transmission during DTX

9.2.2.93 Max PRACH Midamble Shift

Indicates the maximum number of Midamble shifts to be used in a cell.

Table 146

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Max PRACH Midamble Shift			ENUMERATED	
			(4, 8,)	

9.2.2.94 PRACH Midamble

The PRACH Midamble indicates if only the Basic Midamble Sequence or also the time-inverted Midamble Sequence is used.

Table 147

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
PRACH Midamble			ENUMERATED (Inverted, Direct,)	

9.2.2.95 USCH Parameters

In Cell-FACH state, when the UE supports the USCH, and the CRNC is equal to the SRNC, the UE may be given periodic allocations on the uplink shared channel. Furthermore, the UE may also be configured to generate special bursts instead of uplink shared channel transmissions. This information element defines the uplink shared channel transmissions.

Table 148

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Cell Parameter ID	M		9.2.2.81	
TFCI Coding	M		9.2.2.82	
Puncture Limit	M		9.2.2.76	
Repetition Period	M		9.2.2.84	This is the scheduling interval on the USCH.
USCH Scheduling Offset	M		9.2.2.96	
UL Timeslot Information	M		9.2.2.86	
TFCS	1 <maxtf C></maxtf 			
>CTFC	M		9.2.2.49	
TrCH Information List	1 <maxtr CH></maxtr 			
>UL TrCH Information	M		9.2.2.60	

Table 149

Range bound	Explanation
maxTFC	Maximum number of TFC. The value is 1024.
maxTrCH	Maximum number of Transport Channels. The value is 32.

9.2.2.96 USCH Scheduling Offset

This information element indicates the offset relative to CFN=0 that the transmission on the uplink shared channel shall take place.

Table 150

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
USCH scheduling offset			INTEGER(0255)	

9.2.2.97 Include Velocity

This element indicates that the UE's velocity is requested.

Table 151

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Include Velocity	М		ENUMERATED (requested)	

9.2.2.98 Velocity Estimate

The Velocity Estimate IE is used to describe the UE's velocity. The reference system is the same as used in [11].

Table 152

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Choice Velocity Estimate				
>Horizontal Velocity				Horizontal speed and bearing (the direction of travel).
>>Horizontal Speed and Bearing	M		9.2.2.99	
>Horizontal with Vertical Velocity				Horizontal speed and bearing (the direction of travel) as well as vertical speed and the direction (upward or downward)
>>Horizontal Speed and Bearing	M		9.2.2.99	
>>Vertical Velocity	M		9.2.2.100	
>Horizontal Velocity with Uncertainty				Horizontal speed, bearing (the direction of travel), and the uncertainty of the reported speed.
>>Horizontal Speed and Bearing	M		9.2.2.99	
>>Uncertainty Speed	М		INTEGER (0255)	Uncertainty speed is encoded in increments of 1 kilometer per hour using an 8 bit binary coded number (N). The value of N gives the uncertainty speed except for N=255 which indicates that the uncertainty is not specified
>Horizontal with Vertical Velocity and Uncertainty				Horizontal speed and bearing (the direction of travel) as well as vertical speed and the direction (upward or downward) and the uncertainty of the reported speed.
>>Horizontal Speed and Bearing	M		9.2.2.99	
>>Vertical Velocity	M		9.2.2.100	
>>Horizontal Uncertainty Speed	M		INTEGER (0255)	Horizontal Uncertainty Speed is encoded in increments of 1 kilometer per hour using an 8 bit binary coded number (N). The value of N gives the uncertainty speed except for N=255 which indicates that the uncertainty is not specified
>>Vertical Uncertainty Speed	М		INTEGER (0255)	Vertical Uncertainty Speed is encoded in increments of 1 kilometer per hour using an 8 bit binary coded number (N). The value of N gives the uncertainty speed except for N=255 which indicates that the uncertainty is not specified

9.2.2.99 Horizontal Speed and Bearing

This IE contains the two components of horizontal velocity: speed and bearing

Table 153

114

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Bearing	M		INTEGER (0359)	The direction of movement is given in degrees where '0' represents North, '90' represents East, etc.
Horizontal Speed	М		INTEGER (0< 2 ¹¹ -1)	The relationship between (N) and the horizontal speed (h) in kilometers per hour it describes is: $N \le h < N + 0.5$ (N=0) $N - 0.5 \le h < N + 0.5$
				$ \begin{array}{c} (0 < N < 2^{11} - 1) \\ N - 0.5 \le h \\ \end{array} $ (N = 2 ¹¹ -1)

9.2.2.100 Vertical Velocity

This IE contains the two components of vertical velocity: speed and direction

Table 154

IE/Group Name	Presence	Range	IE type and reference	Semantics description
Vertical Speed	M		INTEGER (02 ⁸ -1)	The relationship between (N) and the vertical speed (v) in kilometers per hour it describes is: $N \le v < N + 0.5 \qquad (N = 0)$ $N - 0.5 \le v < N + 0.5 \qquad (0 < N < 2^8 - 1)$ $N - 0.5 \le v (N = 2^8 - 1)$
Vertical Speed Direction			ENUMERATED (upward, downward)	

9.2.2.101 GPS Positioning Instructions

This information element contains positioning instructions for GPS positioning method in SAS-centric mode.

Table 155

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description	Criticality	Assigned Criticality
Horizontal Accuracy Code	0		9.2.2.38		_	
Vertical Accuracy Code	0		9.2.2.39		_	
GPS Timing of Cell Wanted	M		BOOLEAN	This IE is set to TRUE if the UE is requested to report SFN-GPS timing of the reference cell.	-	
Additional Assistance Data Request	M		BOOLEAN	TRUE indicates that the UE is requested to send an additional assistance data request if the provided assistance data are not sufficient.	-	
Measurement Validity	0		ENUMERATED(CELL_DCH, all states except CELL_DCH, all states,)		YES	ignore

9.2.2.102 UE Position Estimate Info

The UE Position Estimate Info is used in UE-based positioning methods providing the UE position estimate from the RNC to the SAS in SAS-centric mode.

Table 156

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
CHOICE Reference Time	M			
>UTRAN GPS reference time Result			9.2.2.104	
>GPS reference time only				
>>GPS TOW msec	М		INTEGER (06.048*10 ⁸ -1,)	GPS Time of Week in milliseconds.
>Cell timing				
>>SFN	М		INTEGER (04095)	SFN during which the position was calculated.
>>UC-ID	М		UTRAN Cell Identifier 9.2.2.37	Identifies the reference cell for SFN.
UE Position Estimate	М		Geographical Area 9.2.2.6	

9.2.2.103 UTRAN-GPS Reference Time

Table 157

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
UTRAN GPS timing of cell frames	M		INTEGER (0 2322431999999,)	GPS timing of cell frames in steps of 1 chip.
UC-ID	0		UTRAN Cell Identifier 9.2.2.37	Identifies the reference cell for the GPS TOW-SFN relationship.
SFN	М		INTEGER (04095)	The SFN which the UTRAN GPS timing of cell frames time stamps.

9.2.2.104 UTRAN-GPS Reference Time Result

Table 158

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
UE GPS timing of cell frames	М		INTEGER(0 37158911999999,)	GPS Time of Week in units of 1/16 th UMTS chips according to [13].
UC-ID	М		UTRAN Cell Identifier 9.2.2.37	Identifies the reference cell for the GPS TOW-SFN relationship
SFN	М		INTEGER(04095)	This IE indicates the SFN at which the UE timing of cell frame is captured.

9.2.2.105 T_{UTRAN-GPS} Drift Rate

Table 159

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
T _{UTRAN-GPS} Drift Rate	0		ENUMERATED (0, 1, 2, 5, 10, 15, 25, 50, -1, -2, -5, -10, -15, -25, -50,)	In 1/256 chips per sec.

9.2.2.106 Periodic Position Calculation Info

The Periodic Position Calculation Info contains information required for periodic location in RNC-centric mode.

Table 160

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Reference Number	М		INTEGER(032767,)	This IE is used to uniquely associate all periodic Position Calculation procedures belonging to the location of the same target UE for periodic location. Position Calculation procedures belonging to the same target UE for periodic location shall use the same Reference Number.
Amount of Outstanding Requests	М		INTEGER(1 8639999,)	This IE indicates the amount of outstanding periodic requests. This IE shall be set to the total number of periodic requests in the first Position Calculation Request message, and decrement by 1 for each new Position Calculation Request for periodic loaction. When the number reaches 1, the SAS will know that the periodic location is complete.
Reporting Interval	М		INTEGER(1 8639999,)	This IE indicates the reporting interval in seconds when the SAS can expect a next Position Calculation Request associated to the same target UE in periodic location.

9.2.2.107 Periodic Location Info

The Periodic Location Info contains the periodic reporting interval and reporting amount for periodic location.

Table 161

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Reporting Amount	М		INTEGER(1 8639999,)	This IE indicates the amount of periodic reports.
Reporting Interval	М		INTEGER(1 8639999,)	This IE indicates the reporting interval in seconds.

9.2.2.108 Amount of Reporting

The Amount of Reporting together with the *RNC Response Time IE* in a POSITION ACTIVATION REQUEST message defines the periodical reporting criteria.

Table 162

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Amount of Reporting	M		ENUMERATED(2,	Amount of reporting for a
			4, 8, 16, 32, 64,	periodic location procedure.
			Infinity,)	

9.2.2.109 Measurement Instructions Used

This information element contains measurement instructions used by the SRNC upon reception of a POSITION ACTIVATION REQUEST message.

Table 163

Presence	Range	IE Type and Reference	Semantics Description
1		ENUMERATED(CELL_DCH, all states except CELL_DCH, all	
	resence	resence Range	Reference ENUMERATED(CELL_DCH, all states except

9.2.2.110 RRC State Change

Table 164

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
New RRC State	M		ENUMERATED(CELL_DCH,	
			CELL_FACH, CELL_PCH,	
			URA_PCH,)	

9.2.2.111 Periodic Position Termination Cause

The Position Periodic Termination Cause element indicates the reason for termination of a periodic reporting procedure in SAS-centric mode.

Table 165

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Periodic Position	M		ENUMERATED(
Termination Cause			RRC State Transition,	
			Cancelled by SRNC,	
			Cancelled by SAS,	
			Undefined,	
)	

9.2.2.112 Requested Cell-ID Measurements

This information element contains a list of requested measurements for Cell-ID positioning method in SAS-centric mode.

Table 166

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Choice mode	М			·
>FDD				
>>Round Trip Time Info	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Round Trip Time Info</i> IE in the Cell-ID Measured Results Info List.
>>Pathloss	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Pathloss</i> IE in the Cell-ID Measured Results Info List.
>>Round Trip Time Info With Type 1	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Round Trip Time Info With Type 1</i> IE in the Cell-ID Measured Results Info List.
>>CPICH RSCP	M		BOOLEAN	If set to TRUE, the RNC is requested to include the CPICH RSCP IE in the Cell-ID Measured Results Info List.
>>CPICH Ec/N0	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>CPICH Ec/NO</i> IE in the Cell-ID Measured Results Info List.
>TDD				
>>Rx Timing Deviation Info	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Rx Timing Deviation Info</i> IE in the Cell-ID Measured Results Info List.
>>Pathloss	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Pathloss</i> IE in the Cell-ID Measured Results Info List.
>>Rx Timing Deviation LCR Info	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Rx Timing Deviation LCR Info</i> IE in the Cell-ID Measured Results Info List.
>>Rx Timing Deviation 768Info	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Rx Timing Deviation 768Info</i> IE in the Cell-ID Measured Results Info List.
>>Rx Timing Deviation 384ext Info	M		BOOLEAN	If set to TRUE, the RNC is requested to include the <i>Rx Timing Deviation 384ext Info</i> IE in the Cell-ID Measured Results Info List.

9.2.2.113 DGANSS Corrections

This IE contains DGANSS corrections to be used by the UE.

Table 167

IE/Group name	Presence	Range	IE Type and	Semantics description
			Reference	
DGANSS Reference Time	M		INTEGER(0. .3570 by step of 30)	Seconds. Time in GNSS system time (modulo 3600 s) when the DGANSS corrections were calculated
DGANSS Information		1 to <maxsgnt ype></maxsgnt 		
>GANSS Signal ID	0		INTEGER(03,)	Coded as defined in [4].

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
>Status/Health	M		ENUMERAT ED(UDRE scale 1.0, UDRE scale 0.75, UDRE scale 0.5, UDRE scale 0.3, UDRE scale 0.2, UDRE scale 0.1, no data, invalid data)	
>DGANSS Signal Information	C- Status/Hea Ith	1 to <maxgan SSSat></maxgan 		If the Cipher information is included these fields are ciphered.
>>SatID	M		INTEGER(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [22].
>>IOD	M		BIT STRING(10)	
>>UDRE	М		ENUMERAT ED(UDRE \le 1.0 m, 1.0m < UDRE \le 4.0m, 4.0m < UDRE \le 8.0m, 8.0m < UDRE)	The value in this field shall be multiplied by the UDRE Scale Factor in the IE Status/Health to determine the final UDRE estimate for the particular satellite.
>>PRC	М		INTEGER(- 20472047)	Scaling factor 0.32 meters
>>RRC	М		INTEGER(- 127127)	Scaling factor 0.032 meters/sec

Table 167A

Range bound	Explanation
maxSgnType	Maximum number of additional signals in GNSS to measure. The value of maxSgnType is 4
maxGANSSSat	Maximum number of satellites for which data is included in this IE. The value of maxGANSSSat is 32

Table 167B

Condition	Explanation
Status/Health	This IE shall be present if the Status/Health IE value
	is not equal to "no data" or "invalid data".

9.2.2.114 GANSS Almanac and Satellite Health

This IE contains a reduced-precision subset of the ephemeris and clock correction parameters.

Table 168

IE/Group name	Presence	Range	IE Type and	Semantics description
			Reference	

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
Week Number	M		INTEGER(0255)	Almanac reference week , number of weeks since the beginning of GANSS specific system time (mod 256)
SV ID Mask	М		BIT STRING(36)	Defines the SV IDs of the satellites included [22].
CHOICE Almanac Model	M			
>Keplerian Parameters				
>>T _{oa}	М		INTEGER(0255)	Scaling factor 2 ¹² s Reference time of almanac within week in GANSS TOD time base
>>IOD _a	M		INTEGER(03)	Issue-Of –Data, common to all satellites
>>Satellite Information KP		1 to <maxgan SSSat></maxgan 		Almanacs are in the order of the SV IDs, the smallest ID first.
>>>e	M		BIT STRING(11)	Eccentricity, dimensionless [22]
>>>δi	М		BIT STRING(11)	semi-circles [22]
>>>OMEGADOT	M		BIT STRING(11)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [22]
>>>SV Health KP	М		BIT STRING(4)	dimensionless
>>>delta A ^{1/2}	М		BIT STRING(17)	Semi-Major Axis delta (meters) ^{1/2} [22]
>>>OMEGA ₀	M		BIT STRING(16)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [22]
>>>M ₀	М		BIT STRING(16)	Mean Anomaly at Reference Time (semi-circles) [22]
>>>0	М		BIT STRING(16)	Argument of Perigee (semi- circles) [22]
>>>af ₀	М		BIT STRING(14)	Seconds [22]
>>>af ₁	М		BIT STRING(11)	sec/sec [22]

Table 168A

Range bound	Explanation
maxGANSSSat	Maximum number of satellites for which data is included in this IE.
	The value of maxGANSSSat is 32

9.2.2.115 GANSS Clock Model

The IE contains fields needed to model the GANSS clock parameters.

Table 169

IE/Group name	Presence	Range	IE Type and	Semantics description
			Reference	

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
Satellite Clock Model		1 to <4>		There may be more than one clock model included if defined in SIS ICD (e.g. two for Galileo)
>t _{oc} _LSB	М		INTEGER(0511)	Least significant bits of Time- of-Clock in seconds
>a _{i2}	М		BIT STRING(12)	defined in [22]
>a _{i1}	М		BIT STRING(18)	defined in [22]
>a _{i0}	М		BIT STRING(28)	defined in [22]
>T _{GD}	M		BIT STRING(10)	defined in [22]
>Model ID	0		INTEGER(01)	Coded as defined in [4].

9.2.2.116 GANSS Ionospheric Model

The IE contains fields needed to model the propagation delays of the GANSS signals through the ionosphere.

Table 170

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
a_{i0}	M		BIT STRING(12)	This parameter is used as defined in [22]
a _{i1}	M		BIT STRING(12)	This parameter is used as defined in [22]
a _{i2}	M		BIT STRING(12)	This parameter is used as defined in [22]
GANSS Ionosphere Regional Storm Flags	0			
>Storm Flag 1	M		BOOLEAN	This parameter is used as defined in [22]
>Storm Flag 2	М		BOOLEAN	This parameter is used as defined in [22]
>Storm Flag 3	М		BOOLEAN	This parameter is used as defined in [22]
>Storm Flag 4	М		BOOLEAN	This parameter is used as defined in [22]
>Storm Flag 5	М		BOOLEAN	This parameter is used as defined in [22]

9.2.2.117 GANSS Measured Results

Table 171

IE/Group name	Presence	Range	IE Type and	Semantics description
			Reference	

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
CHOICE Reference Time	М			
>UTRAN Reference Time				
>>UE GANSS Timing of Cell Frames	M		INTEGER(0.	GANSS Time of Day (TOD) in ns
			8639999999 9750 by step of 250)	
>>GANSS Time ID	0		INTEGER(07)	Coded as defined in [4].
>>GANSS TOD Uncertainty	0		INTEGER(0127)	See note 1.
>>CHOICE mode	М			
>>>FDD	N 4		Durings of the	Identifies the reference cell for
>>>>Primary CPICH Info	М		Primary Scrambling Code 9.2.2.46	the GANSS TOD-SFN relationship.
>>>TDD >>>>Cell Parameters ID	M		Cell	Identifies the reference cell for
>>>>Cell Falaliletels ID	IVI		Parameter ID 8.2.2.81	the GANSS TOD-SFN relationship.
>>Reference SFN	M		INTEGER(04095)	The SFN for which the location is valid. This IE indicates the SFN at which the UE timing of cell frames is captured.
>GANSS Reference Time Only				
>>GANSS TOD msec	M		INTEGER(03599999)	GANSS Time of Day (modulo 1 hour) in milliseconds (rounded down to the nearest millisecond unit).
>>GANSS Time ID	0		INTEGER(07)	Coded as defined in [4].
>>GANSS TOD Uncertainty	0		INTEGER(0127)	See note 1.
GANSS Generic Measurement Information	M	1 to <maxgan SS></maxgan 		
>GANSS ID	0		INTEGER(07)	Coded as defined in [4].
>GANSS Signal ID	0		INTEGER(03,)	Coded as defined in [4].
> GANSS Measurement Parameters	M	1 to <maxgan SSSat></maxgan 		
>>Satellite ID	M		INTEGER(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [22].
>>C/N _o	M		INTEGER(063)	the estimate of the carrier-to- noise ratio of the received signal from the particular satellite used in the measurement. It is given in units of dB-Hz (typical levels will be in the range of 20 – 50 dB-Hz).
>>Multipath Indicator	М		ENUMERAT ED(NM, low, medium, high)	Coding as in 9.2.2.12
>>Carrier Quality Indicaton	0		BIT STRING(2)	Coded as defined in [4].
>>Code Phase	М		INTEGER(02 ²¹ -1)	Scale factor 2 ⁻²¹ Code phase for the particular satellite signal at the time of

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
				measurement in the units of milliseconds. Increasing binary values of the field signify increasing measured pseudoranges. GNSS specific code phase measurements (e.g. chips) are converted into unit of ms by dividing the measurements by the nominal values of the measured signal chipping rate.
>>Integer Code Phase	0		INTEGER(063)	In ms Indicates the integer millisecond difference of the code phase measurement made by the UE with respect to the first satellite signal measurement in the GANSS Measurement Parameters list only if the UE has information of the absolute integer millisecond difference.
>>Code Phase RMS Error	М		INTEGER (063)	Coding as Pseudorange RMS Error in section 9.2.2.12
>>Doppler	M		INTEGER(- 327683276 7)	m/s, scale factor 0.04. Doppler measured by the UE for the particular satellite signal
>>ADR	0		INTEGER(0. .33554431)	Meters, scale factor 2 ⁻¹⁰ ADR measurement measured by the UE for the particular satellite signal.

Table 171A

Range bound	Explanation
maxGANSS	Maximum number of GANSS. The value of maxGANSS is 8.
maxGANSSSat	Maximum number of satellites for which data is included in this IE.
	The value of maxGANSSSat is 32

NOTE 1: GANSS TOD Uncertainty

This parameter provides the accuracy of the relation between GANSS TOD and UTRAN time if UTRAN GANSS timing of cell frames is provided. Its coding is defined in [4].

9.2.2.118 GANSS Navigation Model

This IE contain information required to manage the transfer of precise navigation data to the GANSS-capable UE.

Table 172

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
Non-Broadcast Indication	0		ENUMERAT	If this IE is present, GANSS
			ED(true)	navigation model is not
				derived from satellite
				broadcast. See NOTE 1
T _{oe/c} MSB	C-Orbit		INTEGER(0.	The most significant bits of
	model		.31)	parameters Time-of-
				Ephemeris and Time-of-Clock
				in seconds, scale factor 21600

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
e MSB	C-Orbit model		INTEGER(0127)	The most significant bits of eccentricity, scale factor 2 ⁻⁸
SqrtA MSB	C-Orbit model		INTEGER(063)	The most significant bits of Semi-Major Axis in (meters) ^{1/2} , scale factor 2 ⁷
Satellite Information	M	1 to <maxgan SSSat></maxgan 		
>SatID	M		INTEGER(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [22].
>SV Health	M		BIT STRING(5)	Coded as defined in [4].
>IOD	М		BIT STRING(10)	
>GANSS Clock Model	M		GANSS clock model 9.2.2.115	
>GANSS Orbit Model	M		GANSS orbit model 9.2.2.119	

Table 172A

Range bound	Explanation			
maxGANSSSat	Maximum number of satellites for which data is included in this IE.			
	The value of maxGANSSSat is 32			

Table 172B

Condition	Explanation		
Orbit model	The IE shall be present if the GANSS Orbit Model IE		
	indicates "Keplerian Parameters"		

NOTE 1: The Non-Broadcast Indication allows to inform that the navigation model is bit-to-bit the one broadcast by the satellite. If it is set to 1, the UE is informed that techniques such as data wiping off applied to the navigation model may not work for instance.

9.2.2.119 GANSS Orbit Model

This IE contains information for GANSS orbit model parameters.

Table 173

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
CHOICE Orbit Model	M			
>Keplerian Parameters				
>>toe_LSB	M		INTEGER(0511)	Least significant bits of Time- of-Ephemeris in seconds, scale factor 60
>>ω	M		BIT STRING(32)	Argument of Perigee (semicircles) [22]
>>∆n	M		BIT STRING(16)	Mean Motion Difference From Computed Value (semi- circles/sec) [22]
>>M ₀	М		BIT STRING(32)	Mean Anomaly at Reference Time (semi-circles) [22]

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
>>OMEGAdot	М		BIT STRING(24)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles/sec) [22]
>>e_LSB	М		INTEGER(033554431)	Least significant bits of eccentricity, scale factor 2 ⁻³³
>>ldot	M		BIT STRING(14)	Rate of Inclination Angle (semi-circles/sec) [22]
>>sqrtA_LSB	M		INTEGER(067108863)	Least significant bits of Semi- Major Axis in (meters) ^{1/2} , scale factor 2 ⁻¹⁹
>>i ₀	M		BIT STRING(32)	Inclination Angle at Reference Time (semi-circles) [22]
>>OMEGA ₀	М		BIT STRING(32)	Longitude of Ascending Node of Orbit Plane at Weekly Epoch (semi-circles) [22]
>>C _{rs}	М		BIT STRING(16)	Amplitude of the Sine Harmonic Correction Term to the Orbit Radius (meters) [22]
>>C _{is}	M		BIT STRING(16)	Amplitude of the Sine Harmonic Correction Term To The Angle Of Inclination (radians) [22]
>>C _{us}	M		BIT STRING(16)	Amplitude of the Sine Harmonic Correction Term To The Argument Of Latitude (radians) [22]
>>C _{rc}	М		BIT STRING(16)	Amplitude of the Cosine Harmonic Correction Term to the Orbit Radius (meters) [22]
>>C _{ic}	М		BIT STRING(16)	Amplitude of the Cosine Harmonic Correction Term To The Angle Of Inclination (radians) [22]
>>C _{uc}	M		BIT STRING(16)	Amplitude of the Cosine Harmonic Correction Term To The Argument Of Latitude (radians) [22]

9.2.2.120 GANSS Positioning Instructions

This information element contains positioning instructions for GANSS positioning method in SAS-centric mode.

Table 174

IE/Group Name	Presence	Range	IE Type and Reference	Semantics Description
Horizontal Accuracy Code	0		9.2.2.38	
Vertical Accuracy Code	0		9.2.2.39	
GANSS Timing of Cell Wanted	M		BOOLEAN	This IE is set to TRUE if the UE is requested to report SFN-GANSS timing of the reference cell.
Additional Assistance Data Request	M		BOOLEAN	TRUE indicates that the UE is requested to send an additional assistance data request if the provided assistance data are not sufficient.
Measurement Validity	0		ENUMERATED(CELL_DCH, all states except CELL_DCH, all states,)	

9.2.2.121 GANSS-UTRAN Time Relationship Uncertainty

This IE contains the uncertainty of the GANSS and UTRAN time relationship.

Table 175

IE/Group Name	Presence	Range	IE Type and Reference	Semantics
				Description
GANSS-UTRAN Time	M		ENUMERATED	RNC estimate of
Relationship Uncertainty			(50ns, 500ns, 1us, 10us,	uncertainty in
·			1ms, 10ms, 100ms,	GANSS-UTRAN time
			unreliable,)	relationship
GANSS ID	0		INTEGER (07)	Coded as defined in
				[4].

9.2.2.122 GANSS Real Time Integrity

This IE contains parameters that describe the real-time status of the GANSS constellation.

Table 176

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
Satellite Information		1 to <maxgan SSSat></maxgan 		
>Bad GANSS SatID	M		INTEGER(063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [22].
>Bad GANSS Signal ID	0		INTEGER(04,)	Coded as defined in [4].

Table 176A

Range bound	Explanation
maxGANSSSat	Maximum number of satellites for which data is included in this IE.
	The value of maxGANSSSat is 32

9.2.2.123 GANSS Reference Measurement Information

This IE contains parameters that enable fast acquisition of the GANSS signals in UE-assisted GANSS positioning.

Table 177

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
GANSS Signal ID	0		INTEGER(03,)	Coded as defined in [4].
Satellite Information		1 to <maxgan SSSat></maxgan 	10, 11,	
>SatID	M		INTEGER (063)	Identifies the satellite and is equal to (SV ID No - 1) where SV ID No is defined in [22].
>Doppler (0 th order term)	M		INTEGER(- 20482047)	Scaling factor 0.5 m/s Conversion between m/s and Hz shall be made by using the nominal wavelength of the assisted signal.
>Extra Doppler	0			g
>>Doppler (1 st order term)	M		INTEGER (- 4221)	Scaling factor 1/210 m/s ²
>>Doppler Uncertainty	М		ENUMERAT ED (40,20,10,5, 2.5)	m/s. The Doppler experienced by a stationary UE is in the range "Doppler – Doppler Uncertainty" to "Doppler + Doppler Uncertainty".
>Code Phase	M		INTEGER(01023)	ms, scaling factor 2 ⁻¹⁰ Nominal chipping rate of the GNSS signal shall be used in conversion. Increasing binary values of the field signify increasing predicted pseudoranges.
>Integer Code Phase	M		INTEGER(0127)	ms. Integer code phase (expressed modulo 128 ms) currently being transmitted at the GANSS Reference Time, as seen by a receiver at the Reference Location
>Code Phase Search Window	M		INTEGER(031)	Expected code-phase is in the range "Code Phase – Code Phase Search Window" to "Code Phase + Code Phase Search Window". Coded as defined in [4].
>Azimuth and Elevation	0			
>>Azimuth	М		INTEGER(031)	Scaling factor 11.25 Degrees An angle of x degrees means the satellite azimuth a is in the range $x \le a < x+11.25$ degrees.
>>Elevation	M		INTEGER(07)	Scaling factor 11.25 Degrees An angle of y degrees means the satellite elevation e is in the range y ≤ e < y+11.25 degrees except for y=78.75 where the range is extended to include 90 degrees.

Table 177A

Range bound	Explanation
maxGANSSSat	Maximum number of satellites for which data is included in this IE.
	The value of maxGANSSSat is 32

9.2.2.124 GANSS Reference Time

Table 178

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
GANSS Day	0		INTEGER(0 8191)	The number of days from the beginning of GNSS system time (mod 8192)
GANSS TOD	M		INTEGER(0 86399)	GANSS Time of Day in seconds
GANSS TOD Uncertainty	0		INTEGER(0 127)	Note
GANSS Time ID	0		INTEGER(0 7)	Coded as defined in [4].
UTRAN GANSS Reference Time	0			
>UTRAN GANSS Timing of Cell Frames	М		INTEGER(0 8639999997 50 by step of 250)	UTRAN GANSS timing of cell frames in steps of 250 ns. Indicates sub-second part of GANSS TOD See [4]
>CHOICE mode	0			
>>FDD >>>Primary CPICH Info	M		Primary Scrambling Code 9.2.2.46	Identifies the reference cell for the GANSS TOD-SFN relationship
>>TDD				
>>>Cell Parameters ID	М		Cell Parameter ID 9.2.2.81	Identifies the reference cell for the GANSS TOD-SFN relationship.
>SFN	М		Integer(040 95)	The SFN which the UTRAN GANSS timing of cell frames time stamps.
Tutran-ganss Drift Rate	0		ENUMERAT ED (0, 1, 2, 5, 10, 15, 25, 50, -1, -2, -5, -10, -15, -25, -50,)	in 1/256 chips per sec.

Note: GANSS TOD Uncertainty

This parameter provides the accuracy of the relation between GANSS TOD and UTRAN time if UTRAN GANSS timing of cell frames is provided. Its coding is defined in [4].

9.2.2.125 GANSS Time Model

The *GANSS Time Model* IE contains a set of parameters needed to relate GANSS time to selected time reference indicated by GNSS_TO_ID.

Table 179

IE/Group name	Presence	Range	IE Type and	Semantics description
iL/Oroup manie	i reserice	ivarige	in Type and	Jemanilos description
			Reference	İ
			1/51515116	1

IE/Group name	Presence	Range	IE Type and	Semantics description
			Reference	
GANSS Time Model Reference	M		INTEGER(0.	GANSS reference time
Time			.65535)	(modulo 1 week) in seconds
T _{A0}	M		INTEGER(-	Seconds, scale factor 2 ⁻³⁵
			2147483648.	
			.2147483647	
)	
T _{A1}	0		INTEGER(-	sec/sec, scale factor 2 ⁻⁵¹
			838860883	·
			88607)	
T _{A2}	0		INTEGER(-	sec/sec ² , scale factor 2 ⁻⁶⁸
			6463)	·
GNSS_Time Offset_ID	M		INTEGER(0.	Coded as defined in [4].
_			.7)	
Week Number	0		INTEGER(0.	Reference week of GANSS
			.8191)	Time Model

9.2.2.126 GANSS UTC Model

The $GANSS\ UTC\ Model$ IE contains a set of parameters needed to relate GANSS time to Universal Time Coordinate (UTC).

Table 180

IE/Group name	Presence	Range	IE Type and Reference	Semantics description
A ₁	М		BIT STRING(24)	sec/sec [22]
A ₀	М		BIT STRING(32)	seconds [22]
tot	М		BIT STRING(8)	seconds [22]
WNt	М		BIT STRING(8)	weeks [22]
Δt_{LS}	М		BIT STRING(8)	seconds [22]
WN _{LSF}	М		BIT STRING(8)	weeks [22]
DN	М		BIT STRING(8)	days [22]
Δt_{LSF}	M		BIT STRING(8)	seconds [22]

9.2.2.127 GANSS Time Indicator

Table 181

IE/Group Name	Presence	Range	IE Type and	Semantics Description
			Reference	
GANSS Time Indicator			ENUMERATE	
			D (requested,	
			not	
			requested)	

9.3 Message and Information Element Abstract Syntax (with ASN.1)

9.3.0 General

PCAP ASN.1 definition conforms with [7], [8], and [9].

The ASN.1 definition specifies the structure and content of PCAP messages. PCAP messages can contain any IEs specified in the object set definitions for that message without the order or number of occurrence being restricted by ASN.1. However, for this version of the standard, a sending entity shall construct a PCAP message according to the PDU definitions module and with the following additional rules (Note that in the following IE means an IE in the object set with an explicit id. If one IE needed to appear more than once in one object set, then the different occurrences have different IE ids):

- IEs shall be ordered (in an IE container) in the order they appear in object set definitions.
- Object set definitions specify how many times IEs may appear. An IE shall appear exactly once if the presence field in an object has value "mandatory". An IE may appear at most once if the presence field in an object has value "optional" or "conditional". If in a tabular format there is multiplicity specified for an IE (i.e. an IE list) then in the corresponding ASN.1 definition the list definition is separated into two parts. The first part defines an IE container list where the list elements reside. The second part defines list elements. The IE container list appears as an IE of its own. For this version of the standard an IE container list may contain only one kind of list elements.

If a PCAP message that is not constructed as defined above is received, this shall be considered as Abstract Syntax Error, and the message shall be handled as defined for Abstract Syntax Error in clause 10.3.6.

Clause 9.3 presents the Abstract Syntax of PCAP protocol with ASN.1. In case there is contradiction between the ASN.1 definition in this clause and the tabular format in clauses 9.1 and 9.2, the ASN.1 shall take precedence, except for the definition of conditions for the presence of conditional elements, where the tabular format shall take precedence.

9.3.1 Usage of private message mechanism for non-standard use

The private message mechanism for non-standard use may be used:

- for special operator- (and/or vendor) specific features considered not to be part of the basic functionality, i.e. the functionality required for a complete and high-quality specification in order to guarantee multivendor interoperability;
- by vendors for research purposes, e.g. to implement and evaluate new algorithms/features before such features are proposed for standardisation.

The private message mechanism shall not be used for basic functionality. Such functionality shall be standardised.

9.3.2 Elementary Procedure Definitions

```
__ **********************
IMPORTS
   Criticality,
    ProcedureCode,
   TransactionID
FROM PCAP-CommonDataTypes
    PositionCalculationRequest,
    PositionCalculationResponse,
    PositionCalculationFailure,
    InformationExchangeInitiationRequest,
    InformationExchangeInitiationResponse,
    InformationExchangeInitiationFailure,
    InformationReport,
    InformationExchangeTerminationRequest,
    InformationExchangeFailureIndication,
    ErrorIndication,
    PrivateMessage,
    PositionInitiationRequest,
    PositionInitiationResponse,
    PositionInitiationFailure,
    PositionActivationRequest,
    PositionActivationResponse,
    PositionActivationFailure.
    PositionParameterModification,
    Abort,
    PositionPeriodicReport,
    PositionPeriodicResult,
    PositionPeriodicTermination
FROM PCAP-PDU-Contents
    id-PositionCalculation,
    id-InformationExchangeInitiation,
    id-InformationReporting,
    id-InformationExchangeTermination,
    id-InformationExchangeFailure,
    id-ErrorIndication,
    id-privateMessage,
    id-PositionInitiation,
   id-PositionActivation.
    id-PositionParameterModification,
    id-Abort,
    id-PositionPeriodicReport,
    id-PositionPeriodicResult,
    id-PositionPeriodicTermination
FROM PCAP-Constants;
__ *****************
-- Interface Elementary Procedure Class
__ *****************
PCAP-ELEMENTARY-PROCEDURE ::= CLASS {
   &InitiatingMessage
   &SuccessfulOutcome OPTIONAL,
&UnsuccessfulOutcome OPTIONAL,
&Outcome OPTIONAL,
&procedureCode ProcedureCode UNIQUE,
&criticality Criticality DEFAULT ignore
}
WITH SYNTAX {
   INITIATING MESSAGE &InitiatingMessage [SUCCESSFUL OUTCOME &SuccessfulOutcome] [UNSUCCESSFUL OUTCOME &UnsuccessfulOutcome] [OUTCOME &Outcome]
                               &procedureCode
    PROCEDURE CODE
   [CRITICALITY
                                &criticality]
}
__ *********************
-- Interface PDU definitions
```

```
__ *********************
PCAP-PDU ::= CHOICE {
    initiatingMessage
                           InitiatingMessage,
    successfulOutcome
                           SuccessfulOutcome,
    unsuccessfulOutcome
                          UnsuccessfulOutcome,
    out.come
                           Out.come.
}
InitiatingMessage ::= SEQUENCE {
   procedureCode PCAP-ELEMENTARY-PROCEDURE.&procedureCode criticality PCAP-ELEMENTARY-PROCEDURE.&criticality
                                                                    ({PCAP-ELEMENTARY-PROCEDURES}),
                                                                    ( { PCAP-ELEMENTARY-
PROCEDURES \ {@procedureCode \} ) ,
   transactionID TransactionID,
                   PCAP-ELEMENTARY-PROCEDURE.&InitiatingMessage
                                                                    ({PCAP-ELEMENTARY-
    value
PROCEDURES \ {@procedureCode \} )
}
SuccessfulOutcome ::= SEQUENCE {
   procedureCode PCAP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                    ({PCAP-ELEMENTARY-PROCEDURES}),
    criticality
                   PCAP-ELEMENTARY-PROCEDURE.&criticality
                                                                    ({PCAP-ELEMENTARY-
PROCEDURES \ {@procedureCode \} ) ,
    transactionID TransactionID,
                   PCAP-ELEMENTARY-PROCEDURE.&SuccessfulOutcome
                                                                    ({PCAP-ELEMENTARY-
    value
PROCEDURES \ {@procedureCode \} )
}
{\tt UnsuccessfulOutcome} \; ::= \; {\tt SEQUENCE} \; \; \{ \;
   procedureCode pCAP-ELEMENTARY-PROCEDURE.&procedureCode criticality PCAP-ELEMENTARY-PROCEDURE.&criticality
                                                                    ({PCAP-ELEMENTARY-PROCEDURES}),
                                                                    ( PCAP-ELEMENTARY-
PROCEDURES \ {@procedureCode \} ) ,
    transactionID TransactionID,
                   PCAP-ELEMENTARY-PROCEDURE.&UnsuccessfulOutcome ({PCAP-ELEMENTARY-
    value
PROCEDURES \ {@procedureCode \} )
Outcome ::= SEQUENCE {
   procedureCode PCAP-ELEMENTARY-PROCEDURE.&procedureCode
                                                                    ({PCAP-ELEMENTARY-PROCEDURES}),
    criticality
                   PCAP-ELEMENTARY-PROCEDURE.&criticality
                                                                    ( { PCAP-ELEMENTARY-
PROCEDURES \ {@procedureCode \} ) ,
    transactionID TransactionID,
    value
                   PCAP-ELEMENTARY-PROCEDURE. & Outcome
                                                                    ({PCAP-ELEMENTARY-
PROCEDURES \ {@procedureCode \} )
-- Interface Elementary Procedure List
PCAP-ELEMENTARY-PROCEDURES PCAP-ELEMENTARY-PROCEDURE ::= {
    PCAP-ELEMENTARY-PROCEDURES-CLASS-1
    PCAP-ELEMENTARY-PROCEDURES-CLASS-2
}
PCAP-ELEMENTARY-PROCEDURES-CLASS-1 PCAP-ELEMENTARY-PROCEDURE ::= {
    positionCalculation
    informationExchangeInitiation,
   positionInitiation |
   positionActivation
}
PCAP-ELEMENTARY-PROCEDURES-CLASS-2 PCAP-ELEMENTARY-PROCEDURE ::= {
    informationReporting
    informationExchangeTermination
    informationExchangeFailure
    errorIndication
    privateMessage,
    positionParameterModification
    abort
```

```
positionPeriodicReport
        positionPeriodicResult
        positionPeriodicTermination
}
 __ ***********************
-- Interface Elementary Procedures
 __ *********************************
\verb"positionCalculation PCAP-ELEMENTARY-PROCEDURE ::= \{
        INITIATING MESSAGE PositionCalculationRequest SUCCESSFUL OUTCOME PositionCalculationRespons
                                                           PositionCalculationResponse
        UNSUCCESSFUL OUTCOME PositionCalculationFailure PROCEDURE CODE id-PositionCalculation
        CRITICALITY
                                                           reject
}
informationExchangeInitiation PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE InformationExchangeInitiationRequest SUCCESSFUL OUTCOME InformationExchangeInitiationRespons
                                                           InformationExchangeInitiationResponse
        UNSUCCESSFUL OUTCOME InformationExchangeInitiationFailure PROCEDURE CODE id-InformationExchangeInitiation
        PROCEDURE CODE
        CRITICALITY
                                                         reject
\verb"positionInitiation PCAP-ELEMENTARY-PROCEDURE ::= \{
        INITIATING MESSAGE PositionInitiationRequest SUCCESSFUL OUTCOME PositionInitiationRespons
                                                           PositionInitiationResponse
                                                      PositionInitiationFailure id-PositionInitiation
        UNSUCCESSFUL OUTCOME
        PROCEDURE CODE
        CRITICALITY
                                                           reject
positionActivation PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE PositionActivationRequest SUCCESSFUL OUTCOME PositionActivationResponse
        SUCCESSFUL OUTCOME
UNSUCCESSFUL OUTCOME
PROCEDURE CODE
CRITICALITY
POSITIONACTIVATIONACTIVATION
POSITIONACTIVATION
POSITIONACTI
informationReporting PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE InformationReport
        PROCEDURE CODE
                                                            id-InformationReporting
        CRITICALITY
                                                            ignore
}
informationExchangeTermination PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE InformationExchangeTerminationRequest
        PROCEDURE CODE
                                                            id-InformationExchangeTermination
        CRITICALITY
                                                            ignore
}
informationExchangeFailure PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE InformationExchangeFailureIndication
        PROCEDURE CODE
                                                            id-InformationExchangeFailure
        CRITICALITY
                                                           ignore
}
errorIndication PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE ErrorIndication
        PROCEDURE CODE
                                                            id-ErrorIndication
        CRITICALITY
                                                           ignore
privateMessage PCAP-ELEMENTARY-PROCEDURE ::= {
        INITIATING MESSAGE PrivateMessage
        PROCEDURE CODE
                                                            id-privateMessage
        CRITICALITY
                                                            ignore
}
```

```
positionParameterModification PCAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE PositionParameterModification
   PROCEDURE CODE
                         id-PositionParameterModification
   CRITICALITY
                          ignore
abort PCAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE Abort
   PROCEDURE CODE
                          id-Abort
   CRITICALITY
                          ignore
}
positionPeriodicReport PCAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE PositionPeriodicReport
   PROCEDURE CODE
                         id-PositionPeriodicReport
   CRITICALITY
                        ignore
positionPeriodicResult PCAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE PositionPeriodicResult
   PROCEDURE CODE
                         id-PositionPeriodicResult
   CRITICALITY
                          ignore
}
positionPeriodicTermination PCAP-ELEMENTARY-PROCEDURE ::= {
   INITIATING MESSAGE PositionPeriodicTermination
   PROCEDURE CODE
                          id-PositionPeriodicTermination
   CRITICALITY
                         ignore
}
END
```

9.3.3 PDU Definitions

```
-- PDU definitions for PCAP.
__ *********************************
PCAP-PDU-Contents {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
umts-Access (20) modules (3) pcap(4) version1 (1) pcap-PDU-Contents (1) }
DEFINITIONS AUTOMATIC TAGS ::=
-- IE parameter types from other modules.
__ *********************************
IMPORTS
   Cause,
   CriticalityDiagnostics,
   GPS-UTRAN-TRU,
   InformationExchangeID,
   InformationReportCharacteristics,
   InformationType,
   MeasuredResultsList,
   RequestedDataValue,
   RequestedDataValueInformation,
   UE-PositionEstimate.
   CellId-MeasuredResultsSets,
   OTDOA-MeasurementGroup,
   AccuracyFulfilmentIndicator,
   HorizontalAccuracyCode,
   VerticalAccuracyCode,
   RequestType,
   UE-PositioningCapability,
   UC-ID,
   ResponseTime,
   PositioningPriority,
   ClientType,
```

```
PositioningMethod,
    UTDOAPositioning,
    GPSPositioning,
    OTDOAAssistanceData,
    UTDOA-Group,
    Positioning-ResponseTime,
    EnvironmentCharacterisation,
    PositionData,
    IncludeVelocity,
    VelocityEstimate,
    UE-PositionEstimateInfo,
    OTDOA-MeasuredResultsSets,
    PeriodicPosCalcInfo,
    PeriodicLocationInfo,
    AmountOfReporting,
    MeasInstructionsUsed,
    RRCstateChange,
    PeriodicTerminationCause,
    CellIDPositioning,
    GANSS-MeasuredResultsList,
    GANSSPositioning,
    GANSS-UTRAN-TRU
FROM PCAP-IEs
   TransactionID
FROM PCAP-CommonDataTypes
    ProtocolExtensionContainer{},
    ProtocolIE-ContainerList{},
    ProtocolIE-Container{},
    ProtocolIE-Single-Container{},
    PrivateIE-Container{},
    PCAP-PRIVATE-IES.
    PCAP-PROTOCOL-EXTENSION,
    PCAP-PROTOCOL-IES
FROM PCAP-Containers
    id-Cause,
    id-CriticalityDiagnostics,
    id-GPS-UTRAN-TRU,
    id-InformationExchangeID,
    id-InformationExchangeObjectType-InfEx-Rprt,
    id-InformationExchangeObjectType-InfEx-Rqst,
    id-InformationExchangeObjectType-InfEx-Rsp,
    id-InformationReportCharacteristics,
    id-InformationType,
    id-GPS-MeasuredResultsList,
    id-RequestedDataValue,
    id-RequestedDataValueInformation,
    id-TransactionID,
    id-UE-PositionEstimate,
    id-CellId-MeasuredResultsSets,
    id-OTDOA-MeasurementGroup,
    id-AccuracyFulfilmentIndicator,
    id-HorizontalAccuracyCode,
    id-VerticalAccuracyCode,
    id-RequestType,
    id-UE-PositioningCapability,
    id-UC-id,
    id-ResponseTime,
    id-PositioningPriority,
    id-ClientType,
    id-PositioningMethod,
    id-UTDOAPositioning,
    id-GPSPositioning,
    id-OTDOAAssistanceData,
    id-UTDOA-Group,
    \verb|id-Positioning-ResponseTime|,\\
    id-EnvironmentCharacterisation,
    id-PositionData,
    id-IncludeVelocity,
    id-VelocityEstimate,
    id-UE-PositionEstimateInfo,
    id-UC-ID-InfEx-Rqst,
    id-OTDOA-MeasuredResultsSets,
    id-PeriodicPosCalcInfo,
    id-PeriodicLocationInfo,
```

```
id-AmountOfReporting,
  id-MeasInstructionsUsed,
  id-RRCstateChange,
  id-PeriodicTerminationCause,
  id-CellIDPositioning,
  id-GANSS-MeasuredResultsList,
  id-GANSSPositioning,
  id-GANSS-UTRAN-TRU
FROM PCAP-Constants;
__ ***********************************
-- POSITION CALCULATION REQUEST
PositionCalculationRequest ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionCalculationRequestIEs} }, protocolExtensions ProtocolExtensionContainer { {PositionCalculationRequestExtensions} }
  protocolIEs
  OPTIONAL,
}
PositionCalculationRequestIEs PCAP-PROTOCOL-IES ::= {
  PRESENCE optional } |
  PRESENCE optional },
{\tt PositionCalculationRequestExtensions} \ {\tt PCAP-PROTOCOL-EXTENSION} \ ::= \ \{
  PRESENCE optional } |
  { ID id-OTDOA-MeasurementGroup
                             CRITICALITY reject EXTENSION OTDOA-MeasurementGroup
     PRESENCE optional } |
  PRESENCE optional } |
  { ID id-VerticalAccuracyCode
                             CRITICALITY ignore EXTENSION VerticalAccuracyCode
     PRESENCE optional } |
  { ID id-UTDOA-Group
                             CRITICALITY reject EXTENSION UTDOA-Group
     PRESENCE optional } |
  PRESENCE optional } |
  { ID id-IncludeVelocity PRESENCE optional } |
                             CRITICALITY ignore EXTENSION IncludeVelocity
  { ID id-PeriodicPosCalcInfo CRITICALITY ignore EXTENSION PeriodicPosCalcInfo
    PRESENCE optional } |
  PRESENCE optional },
}
__ **********************
-- POSITION CALCULATION RESPONSE
__ *****************
PositionCalculationResponse ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionCalculationResponseIEs} },
  protocolExtensions ProtocolExtensionContainer { {PositionCalculationResponseExtensions} }
  OPTIONAL.
{\tt PositionCalculationResponseIEs} \ {\tt PCAP-PROTOCOL-IES} \ ::= \ \{
  mandatory } |
  { ID id-CriticalityDiagnostics
                          CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                 PRESENCE
optional },
}
{\tt PositionCalculationResponseExtensions} \ {\tt PCAP-PROTOCOL-EXTENSION} \ ::= \ \{
```

```
{ ID id-AccuracyFulfilmentIndicator CRITICALITY ignore EXTENSION AccuracyFulfilmentIndicator
            PRESENCE optional |
      { ID id-VelocityEstimate
                                                            CRITICALITY ignore EXTENSION VelocityEstimate
      PRESENCE optional },
}
__ ********************
-- POSITION CALCULATION FAILURE
__ *********************************
PositionCalculationFailure ::= SEQUENCE {
     protocolIEs ProtocolIE-Container { {PositionCalculationFailureIEs} },
      protocolExtensions ProtocolExtensionContainer { {PositionCalculationFailureExtensions} }
      OPTIONAL,
}
PositionCalculationFailureIEs PCAP-PROTOCOL-IES ::= {
       { ID id-Cause
                                                              CRITICALITY ignore TYPE Cause
                                                                                                                                                     PRESENCE
mandatory} |
    PRESENCE
optional },
PositionCalculationFailureExtensions PCAP-PROTOCOL-EXTENSION ::= {
-- INFORMATION EXCHANGE INITIATION REQUEST
__ *****************
InformationExchangeInitiationRequest ::= SEQUENCE {
                                                                                    \{\{\texttt{InformationExchangeInitiationRequest-IEs}\}\}\,,
     protocolIEs ProtocolIE-Container {{InformationExchangeInitiationRequest-IEs}} protocolExtensions ProtocolExtensionContainer {{InformationExchangeInitiationRequest-
     protocolIEs
Extensions}}
OPTIONAL,
InformationExchangeInitiationRequest-IES PCAP-PROTOCOL-IES ::= {
      CRITICALITY reject TYPE
InformationExchangeID
     InformationExchangeObjectType-InfEx-Rqst PRESENCE mandatory }
      -- This IE represents both the Information Exchange Object Type IE and the choice based on the
Information Exchange Object Type
        - as described in the tabular message format in clause 9.1.
      { ID id-InformationType
                                                                                         CRITICALITY reject TYPE InformationType
                                                        PRESENCE
                                                                             mandatory } |
      { ID id-InformationReportCharacteristics
                                                                                         CRITICALITY reject TYPE
InformationReportCharacteristics
                                                                             PRESENCE mandatory }
      { ID id-GPS-UTRAN-TRU
                                                                                          CRITICALITY reject TYPE GPS-UTRAN-TRU
                                                         PRESENCE conditional },
      -- This IE shall be present if the information requested in the Information Type IE contains
GPS-related data
InformationExchangeInitiationRequest-Extensions PCAP-PROTOCOL-EXTENSION ::= {
      ormationExchangernicide | CRITICAL | CRITICAL | CRITICAL | CRITICAL | PRESENCE conditional | Presence | CRITICAL | PRESENCE | CONDUCTOR | PRESENCE | CONDUCTOR | PRESENCE | PRES
                                                                                   CRITICALITY reject EXTENSION GANSS-UTRAN-TRU
      -- This IE shall be present if the information requested in the {\it Information Type} IE contains
GANSS-related data
}
InformationExchangeObjectType-InfEx-Rqst ::= CHOICE {
      referencePosition
                                                                                                RefPosition-InfEx-Rqst,
      extension-InformationExchangeObjectType-InfEx-Rqst
                                                                                               Extension-InformationExchangeObjectType-
InfEx-Rast
```

```
}
RefPosition-InfEx-Rqst ::= SEQUENCE {
      referencePositionEstimate UE-PositionEstimate,
       iE-Extensions
                                                                 ProtocolExtensionContainer { { RefPositionItem-InfEx-Rqst-
ExtIEs} } OPTIONAL,
}
RefPositionItem-InfEx-Rqst-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
Extension-InformationExchangeObjectType-InfEx-Rqst ::= ProtocolIE-Single-Container {{ Extension-
InformationExchangeObjectType-InfEx-RqstIE }}
{\tt Extension-InformationExchangeObjectType-InfEx-RqstIE\ PCAP-PROTOCOL-IES\ ::=\ \{a_{1}, a_{2}, a_{3}, a_{4}, a_{5}, a_
       PRESENCE
mandatory } |
      { ID id-CellId-MeasuredResultsSets CRITICALITY ignore TYPE CellId-MeasuredResultsSets PRESENCE
optional }
UC-ID-InfEx-Rqst ::= SEQUENCE {
                                                                  TIC-TD.
      referenceUC-ID
                                                                  ProtocolExtensionContainer { { UCIDItem-InfEx-Rqst-ExtIEs} }
       iE-Extensions
      OPTIONAL,
       . . .
}
UCIDItem-InfEx-Rqst-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ **********************
-- INFORMATION EXCHANGE INITIATION RESPONSE
__ **********************************
{\tt InformationExchangeInitiationResponse} \ ::= \ {\tt SEQUENCE} \ \big\{
     protocolIEs ProtocolIE-Container {{InformationExchangeInitiationResponse-IEs} protocolExtensions ProtocolExtensionContainer {{InformationExchangeInitiationResponse-
                                                                                               `{{InformationExchangeInitiationResponse-IEs}},
\verb|Extensions|| \} \qquad \qquad \verb|OPTIONAL|,
InformationExchangeInitiationResponse-IEs PCAP-PROTOCOL-IES ::= {
      { ID id-InformationExchangeID
                                                                                                 CRITICALITY ignore TYPE
                                                                                              PRESENCE mandatory } |
InformationExchangeID
       { ID id-InformationExchangeObjectType-InfEx-Rsp CRITICALITY ignore TYPE
{ ID id-CriticalityDiagnostics
CriticalityDiagnostics
                                                                                               PRESENCE optional
                                                                                                                                            },
InformationExchangeInitiationResponse-Extensions PCAP-PROTOCOL-EXTENSION ::= {
}
InformationExchangeObjectType-InfEx-Rsp ::= CHOICE {
      referencePosition
                                                                RefPosition-InfEx-Rsp,
RefPosition-InfEx-Rsp ::= SEQUENCE {
                                                                  RequestedDataValue,
       requestedDataValue
                                                                  ProtocolExtensionContainer { { RefPositionItem-InfEx-Rsp-
       iE-Extensions
                   OPTIONAL,
ExtIEs } }
       . . .
RefPositionItem-InfEx-Rsp-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
```

```
__ ********************************
-- INFORMATION EXCHANGE INITIATION FAILURE
Extensions}}
OPTIONAL,
}
InformationExchangeInitiationFailure-IEs PCAP-PROTOCOL-IES ::= {
  PRESENCE mandatory } |
  PRESENCE mandatory } | { ID id-Critical':
                            CRITICALITY ignore TYPE Cause
  PRESENCE optional },
}
InformationExchangeInitiationFailure-Extensions PCAP-PROTOCOL-EXTENSION ::= {
__ ********************************
-- POSITION INITIATION REQUEST
__ **********************
PositionInitiationRequest ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionInitiationRequestIEs} },
  protocolExtensions ProtocolExtensionContainer { {PositionInitiationRequestExtensions} }
  OPTIONAL,
}
PositionInitiationRequestIEs PCAP-PROTOCOL-IES ::= {
  PRESENCE
mandatory } |
  mandatory } |
  { ID id-UC-id
                         CRITICALITY reject TYPE UC-ID
                                                            PRESENCE
mandatory } |
  PRESENCE
optional } |
  { ID id-ResponseTime
                         CRITICALITY ignore TYPE ResponseTime
                                                            PRESENCE
optional }
  { ID id-PositioningPriority
                         CRITICALITY ignore TYPE PositioningPriority
                                                           PRESENCE
optional } |
  { ID id-ClientType
                         CRITICALITY ignore TYPE ClientType
                                                           PRESENCE
optional },
PositionInitiationRequestExtensions PCAP-PROTOCOL-EXTENSION ::= {
  { ID id-IncludeVelocity
                         CRITICALITY ignore EXTENSION IncludeVelocity
  PRESENCE optional }
  { ID id-PeriodicLocationInfo
                        CRITICALITY ignore EXTENSION PeriodicLocationInfo
  PRESENCE optional },
}
__ **********************
-- POSITION INITIATION RESPONSE
__ *****************
PositionInitiationResponse ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionInitiationResponseIEs} },
  protocolExtensions ProtocolExtensionContainer { {PositionInitiationResponseExtensions} }
  OPTIONAL.
```

```
}
PositionInitiationResponseIEs PCAP-PROTOCOL-IES ::= {
   PRESENCE mandatory } |
   { ID id-PositionData
                                CRITICALITY ignore TYPE PositionData
  PRESENCE mandatory }
   PRESENCE optional },
}
PositionInitiationResponseExtensions PCAP-PROTOCOL-EXTENSION ::= {
 { ID id-VelocityEstimate CRITICALITY ignore EXTENSION VelocityEstimate PRESENCE
optional },
}
__ *********************
-- POSITION INITIATION FAILURE
__ ********************************
PositionInitiationFailure ::= SEQUENCE {
 protocolIEs ProtocolIE-Container { {PositionInitiationFailureIEs} },
  protocolExtensions ProtocolExtensionContainer { {PositionInitiationFailureExtensions} }
  OPTIONAL.
PositionInitiationFailureIEs PCAP-PROTOCOL-IES ::= {
  PRESENCE
mandatory } |
  { ID id-CriticalityDiagnostics CRITICALITY ignore TYPE CriticalityDiagnostics
                                                                   PRESENCE
optional },
}
PositionInitiationFailureExtensions PCAP-PROTOCOL-EXTENSION ::= {
__ *********************************
-- POSITION ACTIVATION REQUEST
__ *********************
PositionActivationRequest ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionActivationRequestIEs} },
protocolExtensions ProtocolExtensionContainer { {PositionActivationRequestExtensions} }
OPTIONAL,
  . . .
PositionActivationRequestIEs PCAP-PROTOCOL-IES ::= {
   { ID id-PositioningMethod CRITICALITY reject TYPE PositioningMethod
   PRESENCE mandatory } |
   PRESENCE mandatory } |
   PRESENCE optional } |
   { ID id-EnvironmentCharacterisation CRITICALITY ignore TYPE EnvironmentCharacterisation
   PRESENCE optional } |
   { ID id-UTDOAPositioning
                             CRITICALITY reject TYPE UTDOAPositioning
   PRESENCE optional }
   { ID id-GPSPositioning
                             CRITICALITY reject TYPE GPSPositioning
   PRESENCE optional } |
   { ID id-OTDOAAssistanceData
                             CRITICALITY reject TYPE OTDOAAssistanceData
   PRESENCE optional },
}
PositionActivationRequestExtensions PCAP-PROTOCOL-EXTENSION ::= {
```

```
{ ID id-IncludeVelocity
                         CRITICALITY ignore EXTENSION IncludeVelocity
  PRESENCE optional } |
  PRESENCE optional } |
  { ID id-CellIDPositioning
                         CRITICALITY ignore EXTENSION CellIDPositioning
  PRESENCE optional } |
                      CRITICALITY reject EXTENSION GANSSPositioning
  { ID id-GANSSPositioning
  PRESENCE optional },
}
__ ***********************************
-- POSITION ACTIVATION RESPONSE
PositionActivationResponse ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {PositionActivationResponseIEs} }, protocolExtensions ProtocolExtensionContainer { {PositionActivationResponseExtensions} }
  protocolIEs
  OPTIONAL,
}
PositionActivationResponseIEs PCAP-PROTOCOL-IES ::= {
  PRESENCE optional } |
  PRESENCE optional } |
                            CRITICALITY reject TYPE CellId-MeasuredResultsSets
  { ID id-CellId-MeasuredResultsSets
  PRESENCE optional } |
  PRESENCE optional } |
  { ID id-UTDOA-Group
                            CRITICALITY reject TYPE UTDOA-Group
  PRESENCE optional },
}
PositionActivationResponseExtensions PCAP-PROTOCOL-EXTENSION ::= {
  { ID id-VelocityEstimate CRITICALITY ignore EXTENSION VelocityEstimate
  PRESENCE optional |
  { ID id-MeasInstructionsUsed
                            CRITICALITY ignore EXTENSION MeasInstructionsUsed
  PRESENCE optional |
  PRESENCE optional },
}
__ ********************
-- POSITION ACTIVATION FAILURE
__ *********************
PositionActivationFailure ::= SEQUENCE {
 protocolExtensions ProtocolExtensionContainer { {PositionActivationFailureExtensions} }
  OPTIONAL.
PositionActivationFailureIEs PCAP-PROTOCOL-IES ::= {
  PRESENCE
mandatory } |
  { ID id-CriticalityDiagnostics CRITICALITY ignore TYPE CriticalityDiagnostics
optional },
}
PositionActivationFailureExtensions PCAP-PROTOCOL-EXTENSION ::= {
}
__ **********************
```

```
-- INFORMATION REPORT
__ *********************************
InformationReport ::= SEQUENCE {
              ProtocolIE-Container {{InformationReport-IEs}},
  protocolIEs
                    ProtocolExtensionContainer {{InformationReport-Extensions}}
   protocolExtensions
   OPTIONAL,
InformationReport-IEs PCAP-PROTOCOL-IES ::= {
   { ID
        id-InformationExchangeID
                                             CRITICALITY ignore TYPE
                             PRESENCE mandatory } |
InformationExchangeID
  InformationExchangeObjectType-InfEx-Rprt PRESENCE mandatory },
}
InformationReport-Extensions PCAP-PROTOCOL-EXTENSION ::= {
InformationExchangeObjectType-InfEx-Rprt ::= CHOICE {
                           RefPosition-InfEx-Rprt,
  referencePosition
RefPosition-InfEx-Rprt ::= SEQUENCE {
   {\tt requestedDataValueInformation} \quad {\tt RequestedDataValueInformation},
   iE-Extensions
                           ProtocolExtensionContainer {{ RefPositionItem-InfEx-Rprt-ExtIEs
}}
   OPTIONAL,
}
RefPositionItem-InfEx-Rprt-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ ********************************
-- INFORMATION EXCHANGE TERMINATION REQUEST
__ *********************
InformationExchangeTerminationRequest ::= SEQUENCE {
              ProtocolIE-Container
                                           {{InformationExchangeTerminationRequest-
   protocolIEs
IEs}},
  protocolExtensions
                    Extensions}}
OPTIONAL,
InformationExchangeTerminationRequest-IEs PCAP-PROTOCOL-IES ::= {
                             CRITICALITY ignore TYPE InformationExchangeID
  { ID
       id-InformationExchangeID
         PRESENCE
                 mandatory,
}
__ **********************
-- INFORMATION EXCHANGE FAILURE INDICATION
__ *********************
InformationExchangeFailureIndication ::= SEQUENCE {
   protocolIEs
                    ProtocolIE-Container
                                          {{InformationExchangeFailureIndication-
IEs}},
  protocolExtensions
                    ProtocolExtensionContainer {{InformationExchangeFailureIndication-
Extensions}}
OPTIONAL,
```

```
}
InformationExchangeFailureIndication-IEs PCAP-PROTOCOL-IES ::= {
TYPE
                                                      TYPE Cause
         PRESENCE mandatory },
}
InformationExchangeFailureIndication-Extensions PCAP-PROTOCOL-EXTENSION ::= {
__ *******************************
-- ERROR INDICATION
__ *********************
ErrorIndication ::= SEQUENCE {
  protocolIEs ProtocolIE-Container { {ErrorIndicationIEs} },
  protocolExtensions ProtocolExtensionContainer { {ErrorIndicationExtensions} } OPTIONAL,
}
ErrorIndicationIEs PCAP-PROTOCOL-IES ::= {
 { ID id-Cause
                            CRITICALITY ignore TYPE Cause
                                                                   PRESENCE
optional } |
   PRESENCE
optional },
}
ErrorIndicationExtensions PCAP-PROTOCOL-EXTENSION ::= {
__ **********************************
-- POSITION PARAMETER MODIFICATION
__ *******************
PositionParameterModification ::= SEQUENCE {
    protocolIE-Container { {PositionParameterModificationIEs} },
  protocolExtensions ProtocolExtensionContainer { {PositionParameterModificationExtensions} }
  OPTIONAL,
  . . .
}
PositionParameterModificationIEs PCAP-PROTOCOL-IES ::= {
             CRITICALITY reject TYPE UC-ID
   { ID id-UC-id
                                                                   PRESENCE
optional }|
  { ID id-UTDOA-Group
                           CRITICALITY reject TYPE UTDOA-Group
                                                                   PRESENCE
optional },
PositionParameterModificationExtensions PCAP-PROTOCOL-EXTENSION ::= {
  optional },
}
__ ********************************
-- PRIVATE MESSAGE
PrivateMessage ::= SEQUENCE {
  privateIEs PrivateIE-Container {{PrivateMessage-IEs}},
PrivateMessage-IEs PCAP-PRIVATE-IES ::= {
```

```
}
__ ********************
-- ABORT
protocolExtensions ProtocolExtensionContainer { {AbortExtensions} } OPTIONAL,
AbortIEs PCAP-PROTOCOL-IES ::= {
  AbortExtensions PCAP-PROTOCOL-EXTENSION ::= {
__ *****************
-- POSITION PERIODIC REPORT
__ *******************
PositionPeriodicReport ::= SEQUENCE {
  protocolIEs ProtocolIE-Container {{PositionPeriodicReport-IEs}},
protocolExtensions ProtocolExtensionContainer {{PositionPeriodicReport-Extensions}}
  protocolIEs
  OPTIONAL,
}
PositionPeriodicReport-IEs PCAP-PROTOCOL-IES ::= {
  PRESENCE optional }
  { ID id-VelocityEstimate
                             CRITICALITY ignore TYPE VelocityEstimate
  PRESENCE optional } |
  PRESENCE optional } |
   { ID id-CellId-MeasuredResultsSets
                             CRITICALITY ignore TYPE CellId-MeasuredResultsSets
  PRESENCE optional } |
  PRESENCE optional } |
   { ID id-Cause
                              CRITICALITY ignore TYPE Cause
  PRESENCE optional } ,
{\tt PositionPeriodicReport-Extensions\ PCAP-PROTOCOL-EXTENSION\ ::=\ \{}
  { ID id-GANSS-MeasuredResultsList CRITICALITY ignore EXTENSION GANSS-MeasuredResultsList
  PRESENCE optional },
}
__ **********************
-- POSITION PERIODIC RESULT
__ *******************
PositionPeriodicResult ::= SEQUENCE {
  protocolIEs ProtocolIE-Container {{PositionPeriodicResult-IEs}},
protocolExtensions ProtocolExtensionContainer {{PositionPeriodicResult-Extensions}}
  OPTIONAL,
  . . .
}
PositionPeriodicResult-IEs PCAP-PROTOCOL-IES ::= {
  PRESENCE optional } |
```

```
{ ID id-VelocityEstimate
                                   CRITICALITY ignore TYPE VelocityEstimate
   PRESENCE optional } |
   { ID id-PositionData
                                    CRITICALITY ignore TYPE PositionData
   PRESENCE optional } |
   { ID id-AccuracyFulfilmentIndicator
                                    CRITICALITY ignore TYPE AccuracyFulfilmentIndicator
   PRESENCE optional } |
   { ID id-Cause
                                    CRITICALITY ignore TYPE Cause
   PRESENCE optional },
PositionPeriodicResult-Extensions PCAP-PROTOCOL-EXTENSION ::= {
__ *******************************
-- POSITION PERIODIC TERMINATION
__ *********************
PositionPeriodicTermination ::= SEQUENCE {
                                      {{PositionPeriodicTermination-IEs}},
   protocolIEs ProtocolIE-Container
   protocolExtensions ProtocolExtensionContainer {{PositionPeriodicTermination-Extensions}}
   OPTIONAL.
}
PositionPeriodicTermination-IEs PCAP-PROTOCOL-IES ::= {
   PRESENCE optional },
}
PositionPeriodicTermination-Extensions PCAP-PROTOCOL-EXTENSION ::= {
ÉND
```

9.3.4 Information Element Definitions

```
-- Information Element Definitions
__ ***********************************
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
umts-Access (20) modules (3) pcap(4) version1 (1) pcap-IEs (2) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
IMPORTS
   maxNrOfErrors,
   maxSat,
   maxSatAlmanac,
   maxNrOfLevels,
   maxNrOfMeasNCell,
   maxNrOfMeasurements,
   maxNrOfPoints,
   maxNrOfExpInfo,
   maxNrOfSets,
   maxRateMatching,
   maxNrOfTFs,
   maxTTI-count,
   maxTS-1.
   maxCCTrCH,
   maxTF,
   maxTFC.
   maxPRACH,
   maxTrCH,
```

}

}

```
maxTGPS,
   maxNoOfMeasurements,
   maxCellMeas,
   maxNrOfEDPCCH-PO-OUANTSTEPs,
   maxNrOfRefETFCI-PO-QUANTSTEPs,
   maxNrOfRefETFCIs,
   maxSet,
   maxGANSS.
   maxGANSSSat,
   maxGANSSSet,
   maxSgnType,
   id-UTRAN-GPSReferenceTime,
   id-UTRAN-GPSReferenceTimeResult,
   id-GPS-UTRAN-TRU,
   id-UTRAN-GPS-DriftRate,
   id-OTDOA-AddMeasuredResultsInfo,
   id-GPS-ReferenceLocation,
   id-rxTimingDeviation768Info,
   id-rxTimingDeviation384extInfo,
   id-MeasurementValidity,
   \verb"id-ExtendedRoundTripTime"
   id-roundTripTimeInfoWithType1,
   id-AddMeasurementInfo,
   id-Extended-RNC-ID,
   id-GANSS-CommonAssistanceData,
   id-GANSS-GenericAssistanceDataList,
   id-GANSS-PositioningDataSet,
   \verb"id-GNSS-PositioningMethod",\\
   id-NetworkAssistedGANSSSuport,
   id-TUTRANGANSSMeasurementValueInfo
FROM PCAP-Constants
   Criticality,
   ProcedureCode,
   ProtocolIE-ID,
   TransactionID,
   TriggeringMessage
FROM PCAP-CommonDataTypes
   ProtocolExtensionContainer{},
   PCAP-PROTOCOL-EXTENSION
FROM PCAP-Containers;
-- Accuracy Fulfilment Indicator
__ *******************
AccuracyFulfilmentIndicator ::= ENUMERATED{
   requested-Accuracy-Fulfilled,
   requested-Accuracy-Not-Fulfilled,
__ *********************************
-- Additional Method Type
__ *********************************
AdditionalMethodType ::= ENUMERATED {
   ue-assisted,
   ue-based,
   ue-based-preferred-but-ue-assisted-allowed,
   ue-assisted-preferred-but-ue-based-allowed,
```

```
__ ********************************
-- Almanac and Satellite Health SIB
__ **********************
AlmanacAndSatelliteHealthSIB ::= SEQUENCE {
   gpsAlmanacAndSatelliteHealth GPS-AlmanacAndSatelliteHealth,
   satMask
                                      BIT STRING (SIZE (1..32)),
   lsbTOW
                                      BIT STRING (SIZE (8)),
                                      ProtocolExtensionContainer { { AlmanacAndSatelliteHealthSIB-
   iE-Extensions
ExtIEs } } OPTIONAL,
AlmanacAndSatelliteHealthSIB-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ *********************************
__ **********************************
Cause ::= CHOICE {
                         CauseRadioNetwork,
   radioNetwork
                          CauseTransport,
   transport
   protocol
                          CauseProtocol,
   misc
                          CauseMisc,
{\tt CauseRadioNetwork ::= ENUMERATED } \{
    invalid-reference-information,
   information-temporarily-not-available,
   information-provision-not-supported-for-the-object,
   position-calculation-error-invalid-GPS-measured-results,
   position-calculation-error-invalid-CellID-measured-results,
   position-calculation-error-invalid-OTDOA-measured-results,
   \verb"position-calculation-error-AGPS-positioning-method-not-supported",
   \verb|position-calculation-error-CellID-positioning-method-not-supported|,\\
   \verb"position-calculation-error-OTDOA-positioning-method-not-supported",
   initial-UE-position-estimate-missing,
   position-caclulation-error-invalid-UTDOA-measured-results,
   \verb|position-calculation-error-UTDOA-positioning-method-not-supported|,\\
   position-calculation-error-UTDOA-not-supported-UTRAN-cell,
   positioning-method-not-supported,
   loss-of-contact-with-UE,
   {\tt sAS-unable-to-perform-UTDOA-positioning-within-response-time,}\\
   location-measurement-failure,
   ue-positioning-error-Not-enough-OTDOA-cells,
   ue-positioning-error-Not-enough-GPS-Satellites,
   ue-positioning-error-Reference-Cell-not-serving-cell,
   ue-positioning-error-Not-Accomplished-GPS-Timing-of-Cell-Frames,
   ue-positioning-error-Undefined-Error,
   position-calculation-error-invalid-Galileo-measured-results,
   position-calculation-error-AGalileo-positioning-method-not-supported,
   ue-positioning-error-Not-enough-Galileo-Satellites,
   \verb"ue-positioning-error-Not-Accomplished-Galileo-Timing-of-Cell-Frames"
}
CauseTransport ::= ENUMERATED {
   transport-resource-unavailable,
   unspecified,
}
CauseProtocol ::= ENUMERATED {
   transfer-syntax-error,
   abstract-syntax-error-reject,
   abstract-syntax-error-ignore-and-notify,
   message-not-compatible-with-receiver-state,
   semantic-error.
   unspecified,
```

```
abstract-syntax-error-falsely-constructed-message,
}
CauseMisc ::= ENUMERATED {
   processing-overload,
   hardware-failure,
   o-and-m-intervention,
   unspecified,
}
__ *********************
-- Cell Id Measured Results Sets
**************
CellId-MeasuredResultsSets ::=
                                    SEQUENCE (SIZE (1..maxNrOfMeasurements)) OF
   CellId-MeasuredResultsInfoList
CellId-MeasuredResultsInfoList ::=
                                    SEQUENCE (SIZE (1..maxNrOfMeasNCell)) OF
   CellId-MeasuredResultsInfo
CellId-MeasuredResultsInfo ::=
                                    SEQUENCE {
                                    UC-ID,
   uTRANAccessPointPositionAltitude
                                    UTRANAccessPointPositionAltitude,
                                    UE-PositionEstimate OPTIONAL,
RoundTripTimeInfo OPTIONAL, -- FDD only
RxTimingDeviationInfo OPTIONAL, -- 3.84Mcps TDD only
   ue-PositionEstimate
   roundTripTimeInfo
   rxTimingDeviationInfo
   rxTimingDeviationLCRInfo
                                   RxTimingDeviationLCRInfo OPTIONAL, -- 1.28Mcps TDD only
                                                              OPTIONAL,
   pathloss
                                    Pathloss
                                    ProtocolExtensionContainer { { CellId-MeasuredResultsInfo-
   iE-Extensions
ExtIEs } } OPTIONAL,
{\tt Cellid-MeasuredResultsInfo-ExtIEs} \ \ {\tt PCAP-PROTOCOL-EXTENSION} \ ::= \ \big\{
   PRESENCE optional } | -- 7.68Mcps TDD only
   { ID id-rxTimingDeviation384extInfo CRITICALITY reject EXTENSION RxTimingDeviation384extInfo
       PRESENCE optional } | -- 3.84Mcps TDD only
   { ID id-roundTripTimeInfoWithTypel CRITICALITY ignore EXTENSION RoundTripTimeInfoWithTypel
      PRESENCE optional } | -- FDD only
   { ID id-AddMeasurementInfo
                                    CRITICALITY ignore EXTENSION AddMeasurementInfo
      PRESENCE optional },
                                    SEQUENCE {
RoundTripTimeInfo ::=
   ue-RxTxTimeDifferenceType2 UE-RxTxTimeDifferenceType2 ue-PositioningMeasQuality UE-PositioningMeasQuality,
                                    UE-RxTxTimeDifferenceType2,
   roundTripTime
                                    RoundTripTime,
                                    ProtocolExtensionContainer { { RoundTripTimeInfo-ExtIEs } }
   iE-Extensions
      OPTIONAL,
}
RoundTripTimeInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional }, -- FDD only
}
                                  SEQUENCE {
RoundTripTimeInfoWithType1 ::=
   ue-RxTxTimeDifferenceTypel
                                    UE-RxTxTimeDifferenceType1,
                                   RoundTripTime,
   roundTripTime
                                    ExtendedRoundTripTime OPTIONAL, -- FDD only
   extendedRoundTripTime
                                    ProtocolExtensionContainer { { RoundTripTimeInfoWithType1-
   iE-Extensions
ExtIEs } } OPTIONAL,
   . . .
}
RoundTripTimeInfoWithType1-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
```

```
UE-RxTxTimeDifferenceType2 ::=
                                     INTEGER (0..8191)
UE-RxTxTimeDifferenceType1 ::=
                                     INTEGER (768..1280)
UE-PositioningMeasQuality ::=
                                     SEQUENCE {
                                    BIT STRING (SIZE (2)),
   stdResolution
                                    BIT STRING (SIZE (3)),
BIT STRING (SIZE (5)),
   numberOfMeasurements
   stdOfMeasurements
   iE-Extensions
                                     ProtocolExtensionContainer { { UE-PositioningMeasQuality-
ExtIEs } } OPTIONAL,
   . . .
}
UE-PositioningMeasQuality-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RoundTripTime ::=
                                      INTEGER (0..32766)
-- Actual value RoundTripTime = IE value * 0.0625 + 876
ExtendedRoundTripTime ::=
                                              INTEGER (32767..103041)
-- Actual value RoundTripTime = IE value * 0.0625 + 876
UTRANAccessPointPositionAltitude ::=
                                    SEQUENCE {
   geographicalCoordinates
                                      GeographicalCoordinates,
   ga-AltitudeAndDirection
                                      GA-AltitudeAndDirection
                         OPTIONAL,
   iE-Extensions
                                      ProtocolExtensionContainer { {
UTRANAccessPointPositionAltitude-ExtIEs } }
UTRANAccessPointPositionAltitude-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
RxTimingDeviationInfo ::=
                                     SEQUENCE {
                                      RxTimingDeviation,
   rxTimingDeviation
   timingAdvance
                                      TimingAdvance,
   iE-Extensions
                                     ProtocolExtensionContainer { { RxTimingDeviationInfo-ExtIEs
} } OPTIONAL,
}
RxTimingDeviationInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
                                   SEQUENCE {
RxTimingDeviationLCR,
RxTimingDeviationLCRInfo ::=
   rxTimingDeviationLCR
   timingAdvanceLCR
                                      TimingAdvanceLCR,
                                     ProtocolExtensionContainer { { RxTimingDeviationLCRInfo-
   iE-Extensions
ExtIEs } } OPTIONAL,
}
RxTimingDeviationLCRInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RxTimingDeviation768Info ::=
                                    SEQUENCE {
   rxTimingDeviation768
                                      RxTimingDeviation768,
   timingAdvance768
                                      TimingAdvance768,
                                      ProtocolExtensionContainer { { RxTimingDeviation768Info-
   iE-Extensions
ExtIEs } } OPTIONAL,
RxTimingDeviation768Info-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RxTimingDeviation384extInfo ::=
                                    SEQUENCE {
   rxTimingDeviation384ext
                                      RxTimingDeviation384ext,
   timingAdvance384ext
                                      TimingAdvance384ext,
                                      ProtocolExtensionContainer { { RxTimingDeviation384extInfo-
   iE-Extensions
            OPTIONAL,
ExtIEs } }
```

```
}
{\tt RxTimingDeviation384extInfo-ExtIEs} \ {\tt PCAP-PROTOCOL-EXTENSION} \ ::= \ \{
AddMeasurementInfo ::=
                                      SEQUENCE {
   cpich-RSCP CPICH-RSCP cpich-EcNo CPICH-EcNo
                                                                                      OPTIONAL,
                                                                                      OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { { AddMeasurementInfo-ExtIEs } }
                                                                                     OPTIONAL,
}
AddMeasurementInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RxTimingDeviation ::=
                                      INTEGER (0..8191)
RxTimingDeviationLCR ::=
                                     INTEGER (0..511)
RxTimingDeviation768 ::=
                                     INTEGER (0..65535)
RxTimingDeviation384ext ::=
                                      INTEGER (0..32767)
TimingAdvance ::=
                                      INTEGER (0..63)
TimingAdvanceLCR ::=
                                      INTEGER (0..2047)
TimingAdvance768 ::=
                                      INTEGER (0..511)
TimingAdvance384ext ::=
                                      INTEGER (0..255)
Pathloss ::=
                                      INTEGER (46..158)
 -- Unit: dB; as defined in [4] subclause 10.3.7.3
                                      INTEGER (0..49)
CPICH-EcNo ::=
-- According to CPICH_Ec/No in [13]
CPICH-RSCP ::=
                                      INTEGER (-5..91)
-- According to CPICH_RSCP in [13]
__ *********************************
-- Cell-ID Positioning (Position Activation Request Message)
__ ********************************
CellIDPositioning ::= SEQUENCE {
   requestedCellIDMeasurements
                                  RequestedCellIDMeasurements,
                                  ProtocolExtensionContainer { { CellIDPositioning-ExtIEs } }
   iE-Extensions
OPTIONAL,
CellIDPositioning-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
RequestedCellIDMeasurements ::= CHOICE {
                                       SEQUENCE {
       roundTripTimeInfoWanted
                                          BOOLEAN,
       pathlossWanted
                                          BOOLEAN,
       roundTripTimeInfoWithTypelWanted BOOLEAN,
       cpichRSCPWanted
                                          BOOLEAN.
       cpicEcNoWanted
                                          BOOLEAN,
                                          ProtocolExtensionContainer { {
       iE-Extensions
RequestedCellIDMeasurementsFDD-ExtIEs } } OPTIONAL,
   tdd
       rxTimingDeviationInfoWanted BOOLEAN,
                                      SEQUENCE {
       pathlossWanted
                                          BOOLEAN.
       rxTimingDeviationLCRInfoWanted
                                          BOOLEAN,
```

```
rxTimingDeviation768InfoWanted BOOLEAN,
      rxTimingDeviation384extInfoWanted
                                     BOOLEAN,
      iE-Extensions
                                      ProtocolExtensionContainer { {
RequestedCellIDMeasurementsTDD-ExtIEs } } OPTIONAL,
       },
}
RequestedCellIDMeasurementsFDD-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RequestedCellIDMeasurementsTDD-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ **********************
-- Client Type
__ ********************
ClientType ::= ENUMERATED {
   emergency-services,
   value-added-services
   plmn-operator-services,
   lawful-intercept-services,
   plmn-operator-broadcast-services,
   plmn-operator-oam,
   plmn-operator-anonymous-statistics,
   plmn-operator-target-ms-service-support,
}
__ ********************************
-- CriticalityDiagnostics
__ **********************
CriticalityDiagnostics ::= SEQUENCE {
   procedureCode
                           ProcedureCode
   OPTIONAL,
   triggeringMessage
                           TriggeringMessage
   OPTIONAL.
   procedureCriticality
                           Criticality
   OPTIONAL,
   transactionID
                           TransactionID
   OPTIONAL,
   iE-Extensions
                          ProtocolExtensionContainer { (CriticalityDiagnostics-ExtIEs) }
   OPTIONAL,
   . . .
}
CriticalityDiagnostics-IE-List ::= SEQUENCE (SIZE (1..maxNrOfErrors)) OF
   SEQUENCE {
      iECriticality
                           Criticality,
                           ProtocolIE-ID,
       iE-ID
      repetitionNumber
                           CriticalityDiagnosticsRepetition
      OPTIONAL,
      messageStructure
                           MessageStructure
      OPTIONAL,
       typeOfError
                           TypeOfError,
                           ProtocolExtensionContainer { {CriticalityDiagnostics-IE-List-ExtIEs}
       iE-Extensions
   OPTIONAL,
CriticalityDiagnostics-IE-List-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
CriticalityDiagnostics-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
CriticalityDiagnosticsRepetition ::= INTEGER (0..255)
TypeOfError ::= ENUMERATED {
  not-understood,
   missing,
}
__ *********************
-- DGPSCorrections
__ ***********************************
DGPSCorrections ::=
                               SEQUENCE {
                                  INTEGER (0..604799),
  gps-TOW-sec
                                  DiffCorrectionStatus,
   statusHealth
   dgps-CorrectionSatInfoList
                                  DGPS-CorrectionSatInfoList
   OPTIONAL,
   -- not included if satelliteHealth is equal to noData or invalidData
                                  ProtocolExtensionContainer { { DGPSCorrections-ExtIEs } }
   iE-Extensions
   OPTTONAL.
}
DGPSCorrections-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
DiffCorrectionStatus ::=
                               ENUMERATED {
                                  udre-1-0, udre-0-75, udre-0-5, udre-0-3,
                                  udre-0-2, udre-0-1, noData, invalidData }
DGPS-CorrectionSatInfoList ::=
                               SEQUENCE (SIZE (1..maxSat)) OF
                                  DGPS-CorrectionSatInfo
DGPS-CorrectionSatInfo ::=
                               SEQUENCE {
                                  INTEGER (0..63),
   satID
                                   INTEGER (0..255),
   iode
   udre
                                  UDRE,
                                  PRC,
   prc
                                  RRC.
   rrc
                                  iE-Extensions
} } OPTIONAL,
}
DGPS-CorrectionSatInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
UDRE ::=
                               ENUMERATED {
                                  lessThan1,
                                   between1-and-4,
                                  between4-and-8.
                                  over8 }
PRC ::=
                               INTEGER (-2047..2047)
                              INTEGER (-127..127)
RRC ::=
__ *********************************
-- UE-PositionEstimate (i.e., Geographical Area)
__ ***********************************
-- UE-PositionEstimate is based on Geographical Area Description in 23.032
```

```
UE-PositionEstimate ::= CHOICE {
                               GA-Point,
   point
   pointWithUnCertainty
                               GA-PointWithUnCertainty,
                               GA-Polygon,
   polygon
   pointWithUncertaintyEllipse GA-PointWithUnCertaintyEllipse,
                              GA-PointWithAltitude,
   pointWithAltitude
   pointWithAltitudeAndUncertaintyEllipsoid
                                                  GA-PointWithAltitudeAndUncertaintyEllipsoid,
    {\tt ellipsoidArc}
                               GA-EllipsoidArc,
}
GeographicalCoordinates ::= SEQUENCE {
    latitudeSign ENUMERATED {north, south},
    latitude
                           INTEGER (0..8388607),
                           INTEGER (-8388608..8388607),
   longitude
    iE-Extensions
                         ProtocolExtensionContainer { GeographicalCoordinates-ExtIEs} }
OPTIONAL,
}
GeographicalCoordinates-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GA-AltitudeAndDirection ::= SEQUENCE {
   directionOfAltitude ENUMERATED {height, depth},
                           INTEGER (0..32767),
    altitude
}
GA-EllipsoidArc ::= SEQUENCE {
    geographicalCoordinates
                               GeographicalCoordinates,
    innerRadius
                               INTEGER (0..65535),
                         INTEGER (0..127),
INTEGER (0..179),
INTEGER (0..179),
    uncertaintyRadius
    offsetAngle
    includedAngle
    confidence
                               INTEGER (0..100),
                               ProtocolExtensionContainer { { GA-EllipsoidArc-ExtIEs} } OPTIONAL,
   iE-Extensions
}
GA-EllipsoidArc-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GA-Point ::= SEQUENCE {
   geographicalCoordinates
                            GeographicalCoordinates,
    iE-Extensions
                               ProtocolExtensionContainer { GA-Point-ExtIEs} } OPTIONAL,
    . . .
}
GA-Point-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GA-PointWithAltitude ::= SEQUENCE {
   geographicalCoordinates GeographicalCoordinates,
   altitudeAndDirection
                              GA-AltitudeAndDirection,
                              iE-Extensions
OPTIONAL,
GA-PointWithAltitude-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GA-PointWithAltitudeAndUncertaintyEllipsoid ::= SEQUENCE {
   geographicalCoordinates GeographicalCoordinates,
altitudeAndDirection GA-AltitudeAndDirection,
    altitudeAndDirection
   uncertaintyEllipse
                              GA-UncertaintyEllipse,
                              INTEGER (0..127),
   uncertaintyAltitude
                              INTEGER (0..100),
    confidence
    iE-Extensions
                               ProtocolExtensionContainer { { GA-
PointWithAltitudeAndUncertaintyEllipsoid-ExtIEs} } OPTIONAL,
```

```
GA-PointWithAltitudeAndUncertaintyEllipsoid-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GA-PointWithUnCertainty ::=SEQUENCE {
   geographicalCoordinates
uncertaintyCode GeographicalCoordinates,
INTEGER (0..127),
    uncertaintyCode
                              ProtocolExtensionContainer { GA-PointWithUnCertainty-ExtIEs} }
    iE-Extensions
OPTIONAL,
   ...}
GA-PointWithUnCertainty-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GA-PointWithUnCertaintyEllipse ::= SEQUENCE {
   geographicalCoordinates
uncertaintyEllipse
GeographicalCoordinates,
GA-UncertaintyEllipse,
   uncertaintyEllipse
                               INTEGER (0..100),
   confidence
                              ProtocolExtensionContainer { { GA-PointWithUnCertaintyEllipse-
    iE-Extensions
ExtIEs } OPTIONAL,
   . . .
}
GA-PointWithUnCertaintyEllipse-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt GA-Polygon} ::= {\tt SEQUENCE} ({\tt SIZE} (1..maxNrOfPoints)) {\tt OF}
    SEQUENCE {
       geographicalCoordinates GeographicalCoordinates,
        iE-Extensions
                                 ProtocolExtensionContainer { {GA-Polygon-ExtIEs} } OPTIONAL,
GA-Polygon-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GA-UncertaintyEllipse ::= SEQUENCE {
   uncertaintySemi-major INTEGER (0..127),
                              INTEGER (0..127),
INTEGER (0..89),
    uncertaintySemi-minor
   orientationOfMajorAxis
}
__ ***********************************
-- UE-PositionEstimateInfo
__ ***********************************
UE-PositionEstimateInfo ::= SEQUENCE {
   referenceTimeChoice ReferenceTimeChoice,
                               UE-PositionEstimate,
   ue-positionEstimate
   iE-Extensions
                               ProtocolExtensionContainer { { UE-PositionEstimateInfo-ExtIEs } }
OPTIONAL,
}
UE-PositionEstimateInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
ReferenceTimeChoice ::= CHOICE {
                                       UTRAN-GPSReferenceTimeResult,
   utran-GPSReferenceTimeResult
   gps-ReferenceTimeOnly
                                       INTEGER (0..604799999, ...),
   cell-Timing
                                       Cell-Timing,
Cell-Timing ::= SEQUENCE {
           INTEGE:
UC-ID,
                       INTEGER (0..4095),
   iE-Extensions ProtocolExtensionContainer { { Cell-Timing-ExtIEs } } OPTIONAL,
```

```
}
Cell-Timing-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ **************
__ **************
PositionData ::= SEQUENCE {
  positioningDataDiscriminator
                            PositioningDataDiscriminator,
                              PositioningDataSet
                                                   OPTIONAL,
   positioningDataSet
-- This IE shall be present if the PositioningDataDiscriminator IE is set to the value "0000" --
  iE-Extensions ProtocolExtensionContainer { {PositionData-ExtIEs} } OPTIONAL,
}
PRESENCE optional },
PositioningDataSet
}
GANSS-PositioningDataSet ::= SEQUENCE(SIZE(1..maxGANSSSet)) OF GANSS-PositioningMethodAndUsage
GANSS-PositioningMethodAndUsage ::= OCTET STRING (SIZE(1))
PositioningDataDiscriminator ::= BIT STRING (SIZE(4))
PositioningDataSet ::= SEQUENCE(SIZE(1..maxSet)) OF PositioningMethodAndUsage
PositioningMethodAndUsage ::= OCTET STRING (SIZE(1))
__ **********************
-- GPS-AcquisitionAssistance:
__ ********************************
GPS-AcquisitionAssistance ::= SEQUENCE {
   gps-TOW-1msec
ExtIEs } } OPTIONAL,
}
GPS-AcquisitionAssistance-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
  PRESENCE optional },
AcquisitionSatInfoList ::= SEQUENCE (SIZE (1..maxSat)) OF
                              AcquisitionSatInfo
AcquisitionSatInfo ::=
                           SEQUENCE {
                             INTEGER (0..63),
  satID
   doppler0thOrder
                              INTEGER (-2048..2047),
   extraDopplerInfo
                              ExtraDopplerInfo
      OPTIONAL,
   codePhase
                              INTEGER (0..1022),
   integerCodePhase
                              INTEGER (0..19),
   gps-BitNumber
                              INTEGER (0..3),
   codePhaseSearchWindow
                              CodePhaseSearchWindow,
   azimuthAndElevation
                             AzimuthAndElevation
     OPTIONAL,
                             ProtocolExtensionContainer { { AcquisitionSatInfo-ExtIEs } }
   iE-Extensions
     OPTIONAL,
}
```

```
AcquisitionSatInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
ExtraDopplerInfo ::=
                                 SEQUENCE {
                                  INTEGER (-42..21),
DopplerUncertainty,
   doppler1st0rder
   dopplerUncertainty
                                      ProtocolExtensionContainer { { ExtraDopplerInfo-ExtIEs } }
   iE-Extensions
   OPTIONAL,
   . . .
}
ExtraDopplerInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
DopplerUncertainty ::=
                                  ENUMERATED {
                                      hz12-5, hz25, hz50, hz100, hz200, ...}
CodePhaseSearchWindow ::=
                                  ENUMERATED {
                                      w1023, w1, w2, w3, w4, w6, w8,
                                      w12, w16, w24, w32, w48, w64,
                                      w96, w128, w192 }
AzimuthAndElevation ::=
                                  SEQUENCE {
                                  INTEGER (0..31),
INTEGER (0..7),
   azimuth
   elevation
                                      ProtocolExtensionContainer { { AzimuthAndElevation-ExtIEs }
   iE-Extensions
  OPTIONAL,
   . . .
}
AzimuthAndElevation-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ ********************************
-- GANSS Elements
__ *******************
DGANSS-Corrections ::= SEQUENCE {
   dGANSS-ReferenceTime INTEGER(0..119),
dGANSS-Information DGANSS-Information,
ie-Extensions ProtocolExtensionCo
                                 ProtocolExtensionContainer { { DGANSS-Corrections-ExtIEs } }
      OPTIONAL,
}
DGANSS-Corrections-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
DGANSS-Information ::= SEQUENCE (SIZE (1..maxSgnType)) OF DGANSS-InformationItem
DGANSS-InformationItem ::= SEQUENCE {
                                      INTEGER(0..3,...)
   gANSS-SignalId
   OPTIONAL,
   gANSS-StatusHealth
                                      GANSS-StatusHealth,
   -- The following IE shall be present if the Status/Health IE value is not equal to "no data" or
"invalid data"
   dGANSS-SignalInformation
                                      DGANSS-SignalInformation
   OPTIONAL,
   ie-Extensions
                                      } } OPTIONAL,
DGANSS-InformationItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
DGANSS-SignalInformation ::= SEQUENCE (SIZE (1..maxGANSSSat)) OF DGANSS-SignalInformationItem
```

```
DGANSS-SignalInformationItem ::= SEQUENCE {
   satId
                                        INTEGER(0..63),
    gANSS-iod
                                        BIT STRING (SIZE (10)),
    udre
                                        INTEGER(-2047..2047),
   ganss-prc
                                        INTEGER (-127..127),
   ganss-rrc
   ie-Extensions
                                        ProtocolExtensionContainer { { DGANSS-SignalInformationItem-
ExtIEs } } OPTIONAL,
    . . .
}
DGANSS-SignalInformationItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-AlmanacAndSatelliteHealth ::= SEQUENCE {
                            INTEGER(0..255),
   weekNumber
                            BIT STRING (SIZE (36)),
    ganss-sat-id
   gANSS-AlmanacModel
                            GANSS-AlmanacModel,
   ie-Extensions
                           ProtocolExtensionContainer { { GANSS-AlmanacAndSatelliteHealth-ExtIEs }
}
           OPTIONAL,
}
GANSS-AlmanacAndSatelliteHealth-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-AlmanacModel ::= CHOICE {
   qANSS-keplerianParameters
                                      GANSS-KeplerianParametersAlm,
}
GANSS-AzimuthAndElevation ::= SEQUENCE {
   azimuth
                               INTEGER(0..31),
    elevation
                                INTEGER(0..75),
                                ProtocolExtensionContainer { GANSS-AzimuthAndElevation-ExtIEs } }
   ie-Extensions
}
GANSS-AzimuthAndElevation-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
{\tt GANSS-Clock-Model} \ ::= \ {\tt SEQUENCE} \ ({\tt SIZE} \ (1..4)) \ {\tt OF} \ {\tt GANSS-SatelliteClockModelItem}
GANSS-CommonAssistanceData ::= SEQUENCE {
   ganss-Reference-Time
                                        GANSS-Reference-Time
                                                                             OPTIONAL,
   ganss-Ionospheric-Model
                                        GANSS-Ionospheric-Model
                                                                             OPTIONAL,
   ganss-Reference-Location
                                       GANSS-Reference-Location
                                                                             OPTIONAL,
   ie-Extensions
                                       ProtocolExtensionContainer { { GANSS-CommonAssistanceData-
ExtIEs } } OPTIONAL,
}
GANSS-CommonAssistanceData-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-ExtraDoppler ::= SEQUENCE {
    dopplerFirstOrder
                                INTEGER(-42..21),
   dopplerUncertainty
                               ENUMERATED{dH40,dH20,dH10,dH5,dH2-5},
   ie-Extensions
                               ProtocolExtensionContainer { { GANSS-ExtraDoppler-ExtIEs } }
   OPTIONAL,
    . . .
}
```

```
GANSS-ExtraDoppler-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-GenericAssistanceDataList ::= SEQUENCE (SIZE (1..maxGANSS)) OF GANSSGenericAssistanceData
GANSSGenericAssistanceData ::= SEQUENCE{
    ganssId
                                         INTEGER(0..7)
                                                                             OPTIONAL,
    ganss-Real-Time-Integrity
                                         GANSS-Real-Time-Integrity
                                                                             OPTIONAL,
    dganss-Corrections
                                        DGANSS-Corrections
                                                                             OPTIONAL,
    ganss-AlmanacAndSatelliteHealth
ganss-ReferenceMeasurementInfo
                                        GANSS-AlmanacAndSatelliteHealth
                                                                              OPTIONAL,
                                        GANSS-ReferenceMeasurementInfo
                                                                              OPTIONAL,
    ganss-UTC-Model
                                        GANSS-UTC-Model
                                                                              OPTIONAL,
    ganss-Time-Model
                                         GANSS-Time-Model
    ganss-Navigation-Model
                                        GANSS-Navigation-Model
                                                                              OPTIONAL,
                                        ProtocolExtensionContainer { { GANSSGenericAssistance-ExtIEs
    ie-Extensions
} } OPTIONAL,
    . . .
GANSSGenericAssistance-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-GenericMeasurementInfo ::= SEQUENCE(SIZE(1..maxGANSS)) OF SEQUENCE {
    ganssSignalId
                               INTEGER(0..7) OPTIONAL, INTEGER(0..3,...) OPTIONAL,
    ganssMeasurementParameters GANSS-MeasurementParameters,
                                ProtocolExtensionContainer { { GANSS-GenericMeasurementInfo-ExtIEs }
    ie-Extensions
} OPTIONAL,
}
GANSS-GenericMeasurementInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-Ionospheric-Model ::= SEQUENCE {
    alpha-zero-ionos
                                         BIT STRING (SIZE (12)),
    alpha-one-ionos
                                         BIT STRING (SIZE (12)),
                                         BIT STRING (SIZE (12)),
    alpha-two-ionos
    {\tt gANSS-Ionosphere Regional Storm Flags} \quad {\tt GANSS-Ionosphere Regional Storm Flags}
    OPTIONAL,
   ie-Extensions
                                        ProtocolExtensionContainer { { GANSS-Ionospheric-Model-
ExtIEs } } OPTIONAL,
}
GANSS-Ionospheric-Model-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-IonosphereRegionalStormFlags ::= SEQUENCE {
    storm-flag-one
                                        BOOLEAN,
    storm-flag-two
    storm-flag-three
                                         BOOLEAN,
    storm-flag-four
                                         BOOLEAN.
    storm-flag-five
                                         BOOLEAN,
    ie-Extensions
                                         ProtocolExtensionContainer { GANSS-
IonosphereRegionalStormFlags-ExtIEs } } OPTIONAL,
}
GANSS-IonosphereRegionalStormFlags-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-KeplerianParametersAlm ::= SEQUENCE {
                                        INTEGER(0..255),
    t-oa
    iod-a
                                         INTEGER(0...3),
    gANSS-SatelliteInformationKP GANSS-SatelliteInformationKP,
```

```
ie-Extensions
                                          ProtocolExtensionContainer { { GANSS-KeplerianParametersAlm-
ExtIEs } } OPTIONAL,
}
GANSS-KeplerianParametersAlm-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-KeplerianParametersOrb ::= SEQUENCE {
    toe-lsb-nav
                                          INTEGER (0..511),
    ganss-omega-nav
                                           BIT STRING (SIZE (32)),
    delta-n-nav
                                           BIT STRING (SIZE (16)),
   m-zero-nav
                                          BIT STRING (SIZE (32)),
    omegadot-nav
                                          BIT STRING (SIZE (24)),
    ganss-e-lsb-nav
                                           INTEGER(0..33554431),
                                         BIT STRING (SIZE (14)),
    idot-nav
    a-sqrt-lsb-nav
                                          INTEGER(0..67108863),
                                          BIT STRING (SIZE (32)),
    i-zero-nav
    omega-zero-nav
                                          BIT STRING (SIZE (32)),
    c-rs-nav
                                          BIT STRING (SIZE (16)),
                                          BIT STRING (SIZE (16)),
    c-is-nav
    c-us-nav
                                          BIT STRING (SIZE (16)),
                                          BIT STRING (SIZE (16)),
    c-rc-nav
    c-ic-nav
                                          BIT STRING (SIZE (16)),
                                          BIT STRING (SIZE (16)),
                                          ProtocolExtensionContainer { GANSS-KeplerianParametersOrb-
    ie-Extensions
ExtIEs } } OPTIONAL,
    . . .
}
GANSS-KeplerianParametersOrb-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
{\tt GANSS-MeasurementParameters} \ ::= \ {\tt SEQUENCE(SIZE(1..maxGANSSSat))} \ \ {\tt OF} \ \ {\tt GANSS-MeasurementParametersItem}
GANSS-MeasurementParametersItem ::= SEQUENCE {
                             INTEGER(0..63),
INTEGER(0..63),
    satId
    cSurNzero
    multipathIndicator
                                  ENUMERATED{nM,low,medium,high},
                          tion BIT STRING(SIZE(Z),
INTEGER(0..2097151),
INTEGER(0..63) OPTIONAL,
INTEGER(0..63),
INTEGER(-32768..32767),
INTEGER(0..33554431) OPTIONAL,
    carrierQualityIndication BIT STRING(SIZE(2)) OPTIONAL,
    codePhase
    integerCodePhase
    codePhaseRmsError
    doppler
    adr
                                 ProtocolExtensionContainer { { GANSS-MeasurementParametersItem-
    ie-Extensions
ExtIEs } } OPTIONAL,
}
GANSS-MeasurementParametersItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-MeasuredResultsList ::= SEQUENCE (SIZE (1..maxNrOfSets)) OF GANSS-MeasuredResults
GANSS-MeasuredResults ::= SEQUENCE {
   referenceTime CHOICE {
                                  UTRAN-GANSSReferenceTimeUL,
        utranReferenceTime
        ganssReferenceTimeOnly GANSS-ReferenceTimeOnly,
    ganssGenericMeasurementInfo GANSS-GenericMeasurementInfo,
ie-Extensions ProtocolExtensionContainer { { GANSS-MeasuredResults-ExtIEs } }
OPTIONAL,
    . . .
}
GANSS-MeasuredResults-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
}
GANSS-Navigation-Model ::= SEQUENCE {
   -- The three following IEs shall be present if the GANSS Orbit Model IE indicates "Keplerian
Parameters
                             INTEGER(0..31)
                                                    OPTIONAL,
   toe-c-msb
                            INTEGER(0..127)
                                                    OPTIONAL
   e-msb
   sqrtA-msb
                              INTEGER(0..63)
                                                     OPTIONAL,
   ganssSatInfoNav
                             GANSS-Sat-Info-Nav,
                             ProtocolExtensionContainer { GANSS-Navigation-Model-ExtIEs } }
   ie-Extensions
OPTIONAL,
   . . .
GANSS-Navigation-Model-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-Orbit-Model ::= CHOICE {
                              GANSS-KeplerianParametersOrb,
   gANSS-keplerianParameters
}
GANSS-Real-Time-Integrity ::= SEQUENCE (SIZE (1..maxGANSSSat)) OF GANSS-RealTimeInformationItem
GANSS-RealTimeInformationItem ::= SEQUENCE {
  bad-ganss-satId
                                     INTEGER(0..63),
   bad-ganss-signalId
                                     INTEGER(0..4,...)
   OPTIONAL,
                                     ProtocolExtensionContainer { { GANSS-
   ie-Extensions
RealTimeInformationItem-ExtIEs } } OPTIONAL,
GANSS-RealTimeInformationItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-Reference-Location ::=
                                     SEQUENCE {
                                     UE-PositionEstimate,
   ue-PositionEstimate
                                     ProtocolExtensionContainer { { GANSS-Reference-Location-
   iE-Extensions
ExtIEs } } OPTIONAL,
GANSS-Reference-Location-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-ReferenceMeasurementInfo ::= SEQUENCE {
   ganssSignalId INTEGER(0..3,...)
satelliteInformation GANSS-SatelliteInformation,
                                                           OPTIONAL,
                             ProtocolExtensionContainer { { GANSS-ReferenceMeasurementInfo-ExtIEs
   ie-Extensions
} } OPTIONAL,
   . . .
}
GANSS-ReferenceMeasurementInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-Reference-Time ::= SEQUENCE {
             INTEGER(0..8191)
                                                       OPTIONAL,
   ganssDay
                         INTEGER(0..86399),
INTEGER(0..127)
   ganssTod
                                                        OPTIONAL,
   ganssTodUncertainty
   ganssTimeId
                             INTEGER(0..7)
                                                        OPTIONAL,
```

```
utran-ganssreferenceTimeUTRAN-GANSSReferenceTimeDLOPTIONAL,tutran-ganss-driftRateTUTRAN-GANSS-DriftRateOPTIONAL,
        ie-Extensions
                                                                    ProtocolExtensionContainer { { GANSS-Reference-Time-ExtIEs } }
        OPTIONAL,
         . . .
}
GANSS-Reference-Time-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSS-ReferenceTimeOnly ::= SEQUENCE {
                                      INTEGER(0..3599999),
        gANSS-tod
        gANSS-timeId
                                                                      INTEGER(0..7)
                                                                                                        OPTIONAL,
        gANSS-timeId INTEGER(0..., OITCLE, gANSS-TimeUncertainty INTEGER(0..127) OPTIONAL, ie-Extensions ProtocolExtensionContainer { { GANSS-ReferenceTimeOnly-ExtIEs } }
OPTIONAL,
        . . .
}
GANSS-ReferenceTimeOnly-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-SatelliteClockModelItem ::= SEQUENCE {
        t-oc-lsb
                                                                                         INTEGER(0..511),
        a-i2
                                                                                         BIT STRING (SIZE(12)),
       a-i1
                                                                                         BIT STRING (SIZE(18)).
        a-i0
                                                                                         BIT STRING (SIZE(28)),
                                                                                         BIT STRING (SIZE(10)),
        t-qd
       model-id
                                                                                                                                                                OPTIONAL,
                                                                                         INTEGER(0..1)
                                                                                         ProtocolExtensionContainer { { GANSS-
        ie-Extensions
SatelliteClockModelItem-ExtIEs } } OPTIONAL,
GANSS-SatelliteClockModelItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt GANSS-SatelliteInformation} ::= {\tt SEQUENCE}({\tt SIZE}(1..max{\tt GANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationItem} \\
GANSS-SatelliteInformationItem ::= SEOUENCE {
        ganssSatId
                                                                     INTEGER(0..63),
         dopplerZeroOrder
                                                                     REAL(-2048..2047),
                                                                      GANSS-ExtraDoppler
                                                                                                                                              OPTIONAL,
        extraDoppler
        codePhase
                                                                    INTEGER(0..1023),
        integerCodePhase
codePhaseSearchWindow
INTEGER(0..31),
GANSS-AzimuthAndElevation
GANSS-AzimuthAndElevation
                                                                    INTEGER(0..127),
        azimuthAndElevation
                                                                                                                                       OPTIONAL,
                                                                    ProtocolExtensionContainer { GANSS-SatelliteInformationItem-ExtIEs
        ie-Extensions
} } OPTIONAL,
         . . .
}
GANSS-SatelliteInformationItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt SIZE} \ ({\tt 1..maxGANSSSat})) \ {\tt OF} \ {\tt GANSS-SatelliteInformationKP} ::= {\tt SEQUENCE} \ ({\tt 1..maxGANSSSat}) \ {\tt OF} \ {\tt CANSS-SatelliteInformationKP} ::= {\tt CANSS-SatelliteInformatio
SatelliteInformationKPItem
GANSS-SatelliteInformationKPItem ::= SEOUENCE {
        ganss-e-alm
                                                                                        BIT STRING (SIZE (11)),
        ganss-delta-I-alm
                                                                                        BIT STRING (SIZE (11)),
                                                                                        BIT STRING (SIZE (11)),
         ganss-omegadot-alm
        ganss-svhealth-alm
                                                                                       BIT STRING (SIZE (4)),
         ganss-delta-a-sqrt-alm
                                                                                       BIT STRING (SIZE (17)),
         ganss-omegazero-alm
                                                                                        BIT STRING (SIZE (16)),
                                                                                        BIT STRING (SIZE (16)),
         ganss-m-zero-alm
```

```
ganss-omega-alm
                                        BIT STRING (SIZE (16)),
    ganss-af-zero-alm
                                        BIT STRING (SIZE (14)),
                                        BIT STRING (SIZE (11)),
   ganss-af-one-alm
                                        ProtocolExtensionContainer { { GANSS-
    ie-Extensions
SatelliteInformationKPItem-ExtIEs } } OPTIONAL,
}
GANSS-SatelliteInformationKPItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-Sat-Info-Nav ::= SEQUENCE (SIZE(1..maxGANSSSat)) OF SEQUENCE {
                      INTEGER(0..63),
                               BIT STRING (SIZE(5)),
BIT STRING (SIZE(10)),
    svHealth
    iod
   ganssClockModel
                               GANSS-Clock-Model,
    ganssOrbitModel
                               GANSS-Orbit-Model,
    ie-Extensions
                               ProtocolExtensionContainer { { GANSS-Sat-Info-Nav-ExtIEs } }
OPTIONAL,
    . . .
}
GANSS-Sat-Info-Nav-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-StatusHealth ::= ENUMERATED {
  udre-scale-1dot0,
  udre-scale-0dot75,
  udre-scale-0dot5,
  udre-scale-0dot3,
  udre-scale-Odot2,
  udre-scale-0dot1,
  no-data,
  invalid-data
}
GANSS-Time-Model ::= SEQUENCE {
   ganss-time-model
                                        INTEGER(0..65535),
                                        INTEGER(-2147483648..2147483647),
    ganss-t-a0
   ganss-t-a1
                                        INTEGER(-8388608..8388607)
                                        INTEGER (-64..63)
   ganss-t-a2
                                        INTEGER(0..7),
   ganss-to-id
                                        INTEGER(0..8191)
   ganss-wk-number
   ie-Extensions
                                       ProtocolExtensionContainer { { GANSS-Time-Model-ExtIEs } }
}
GANSS-Time-Model-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-UTRAN-TimeRelationshipUncertainty ::= ENUMERATED {
   gANSS-UTRAN-TRU-50nano,
   gANSS-UTRAN-TRU-500nano,
   gANSS-UTRAN-TRU-1micro,
   gANSS-UTRAN-TRU-10micro,
   gANSS-UTRAN-TRU-1milli,
   gANSS-UTRAN-TRU-10milli,
   gANSS-UTRAN-TRU-100milli,
   gANSS-UTRAN-TRU-unreliable,
}
GANSS-UTRAN-TRU ::= SEQUENCE {
   gANSS-UTRAN-TimeRelationshipUncertainty
                                                GANSS-UTRAN-TimeRelationshipUncertainty,
                                                INTEGER(0..7)
    ganssId
                                                                    OPTIONAL,
```

```
ie-Extensions
                                                      ProtocolExtensionContainer { { GANSS-UTRAN-TRU-
ExtIEs } } OPTIONAL,
}
GANSS-UTRAN-TRU-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-UTC-Model ::= SEQUENCE {
                                            BIT STRING (SIZE (24)),
    a-one-utc
    a-zero-utc
                                            BIT STRING (SIZE (32)),
                                            BIT STRING (SIZE (8)),
    t-ot-utc
                                            BIT STRING (SIZE (8)),
    w-n-t-utc
    delta-t-ls-utc
                                            BIT STRING (SIZE (8)),
    w-n-lsf-utc
                                           BIT STRING (SIZE (8)),
    dn-utc
                                            BIT STRING (SIZE (8)),
    delta-t-lsf-utc
                                           BIT STRING (SIZE (8)),
    ie-Extensions
                                            ProtocolExtensionContainer { GANSS-UTC-Model-ExtIEs } }
}
GANSS-UTC-Model-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
TUTRAN-GANSS-DriftRate ::= ENUMERATED {
   utran-ganssdrift0, utran-ganssdrift1, utran-ganssdrift2, utran-ganssdrift5, utran-ganssdrift10, utran-ganssdrift15, utran-ganssdrift15, utran-ganssdrift25, utran-ganssdrift50, utran-ganssdrift-1, utran-ganssdrift-2, utran-ganssdrift-5, utran-ganssdrift-10, utran-ganssdrift-15, utran-ganssdrift-25, utran-ganssdrift-50,
}
UTRAN-GANSSReferenceTimeDL ::= SEQUENCE {
    ue-GANSSTimingOfCellFrames INTEGER(0..345599999999),
    mode CHOICE {
       fdd SEQUENCE {
            primary-CPICH-Info
                                               PrimaryScramblingCode
         tdd SEQUENCE {
            cellParameters
                                                 CellParameterID
         }
           OPTIONAL,
                                  INTEGER(0..4095),
    referenceSfn
                                     ProtocolExtensionContainer { { UTRAN-GANSSReferenceTimeDL-ExtIEs
    ie-Extensions
} } OPTIONAL,
}
UTRAN-GANSSReferenceTimeDL-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
UTRAN-GANSSReferenceTimeUL ::= SEQUENCE {
    ue-GANSSTimingOfCellFrames INTEGER(0..345599999999),
                             INTEGER(0..7) OPTIONAL,
INTEGER(0..127) OPTIONAL,
    gANSS-TimeId
    gANSS-TimeUncertainty
            CHOICE {
    mode
        fdd SEOUENCE {
           primary-CPICH-Info
                                               PrimaryScramblingCode
         tdd
                SEQUENCE {
             cellParameters
                                                 CellParameterID
         }
    ie-Extensions
OPTIONAT
                                  INTEGER(0..4095),
                                     ProtocolExtensionContainer { { UTRAN-GANSSReferenceTimeUL-ExtIEs
} } OPTIONAL,
}
```

```
UTRAN-GANSSReferenceTimeUL-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ ********************************
-- GPS Almanac and Satellite Health
__ *******************
GPS-AlmanacAndSatelliteHealth ::= SEQUENCE {
                                    BIT STRING (SIZE (8)),
   almanacSatInfoList
                                    AlmanacSatInfoList,
                                    BIT STRING (SIZE (364)) OPTIONAL,
   svGlobalHealth
   iE-Extensions
                                    ProtocolExtensionContainer { { GPS-
AlmanacAndSatelliteHealth-ExtIEs } }
                                       OPTIONAL,
}
GPS-AlmanacAndSatelliteHealth-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
                               SEQUENCE (SIZE (1..maxSatAlmanac)) OF
AlmanacSatInfoList ::=
                                   AlmanacSatInfo
AlmanacSatInfo ::=
                                SEQUENCE {
   dataID
                                   BIT STRING (SIZE (2)),
   satID
                                    INTEGER (0..63),
                                    BIT STRING (SIZE (16)),
   t-oa
                                    BIT STRING (SIZE (8)),
                                   BIT STRING (SIZE (16)),
   deltaI
   omegaDot
                                    BIT STRING (SIZE (16)),
                                   BIT STRING (SIZE (8)),
   satHealth
   a-Sgrt
                                   BIT STRING (SIZE (24)),
   omega0
                                    BIT STRING (SIZE (24)),
                                   BIT STRING (SIZE (24)),
   m0
                                    BIT STRING (SIZE (24)),
   omega
                                   BIT STRING (SIZE (11)),
   af0
   af1
                                   BIT STRING (SIZE (11)),
   iE-Extensions
                                    ProtocolExtensionContainer { { AlmanacSatInfo-ExtIEs } }
   OPTIONAL,
}
AlmanacSatInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ *******************************
-- GPS Clock And Ephemeris Parameters
__ *****************
GPS-ClockAndEphemerisParameters ::= SEQUENCE {
                                   BIT STRING (SIZE (2)),
   uraIndex
                                    BIT STRING (SIZE (4)),
   satHealth
                                    BIT STRING (SIZE (6)),
   iodc
                                    BIT STRING (SIZE (10)),
   12Pflag
                                    BIT STRING (SIZE (1)),
   sf1Revd
                                    SubFrame1Reserved,
                                    BIT STRING (SIZE (8)),
   t-GD
   t-oc
                                    BIT STRING (SIZE (16)),
   af2
                                    BIT STRING (SIZE (8)),
   af1
                                    BIT STRING (SIZE (16)),
                                    BIT STRING (SIZE (22)),
   af0
                                    BIT STRING (SIZE (16)),
   c-rs
   delta-n
                                    BIT STRING (SIZE (16)),
   m0
                                    BIT STRING (SIZE (32)),
   c-uc
                                    BIT STRING (SIZE (16)),
                                    BIT STRING (SIZE (32)),
```

```
c-us
                                     BIT STRING (SIZE (16)),
   a-Sgrt
                                     BIT STRING (SIZE (32)),
                                    BIT STRING (SIZE (16)),
   t-oe
   fitInterval
                                     BIT STRING (SIZE (1)),
   aodo
                                     BIT STRING (SIZE (5)),
                                    BIT STRING (SIZE (16)),
   c-ic
                                     BIT STRING (SIZE (32)),
   omega 0
                                     BIT STRING (SIZE (16)),
   c-is
   i0
                                     BIT STRING (SIZE (32)),
   c-rc
                                     BIT STRING (SIZE (16)),
                                     BIT STRING (SIZE (32)),
   omega
   omegaDot
                                     BIT STRING (SIZE (24)),
   i Dot
                                     BIT STRING (SIZE (14)),
   iE-Extensions
                                     ProtocolExtensionContainer { GPS-
ClockAndEphemerisParameters-ExtIEs } }
                                       OPTIONAL,
GPS-ClockAndEphemerisParameters-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
SubFrame1Reserved ::=
                                 SEQUENCE {
                                     BIT STRING (SIZE (23)),
   reserved1
                                     BIT STRING (SIZE (24)),
   reserved2
   reserved3
                                    BIT STRING (SIZE (24)),
                                     BIT STRING (SIZE (16))
   reserved4
}
__ *****************
-- GPS Ionospheric Model
__ *********************
GPS-Ionospheric-Model ::=
                                 SEQUENCE {
   alfa0
                                     BIT STRING (SIZE (8)),
   alfa1
                                     BIT STRING (SIZE (8)),
   alfa2
                                     BIT STRING (SIZE (8)),
   alfa3
                                     BIT STRING (SIZE (8)),
   beta0
                                     BIT STRING (SIZE (8)),
   beta1
                                    BIT STRING (SIZE (8)),
   beta2
                                     BIT STRING (SIZE (8)),
                                    BIT STRING (SIZE (8)).
   beta3
   iE-Extensions
                                    ProtocolExtensionContainer { { GPS-Ionospheric-Model-ExtIEs
} } OPTIONAL,
}
GPS-Ionospheric-Model-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   . . .
}
__ **********************
-- GPS Measured Results
__ **********************************
MeasuredResultsList ::=
                               SEQUENCE (SIZE (1..maxNrOfSets)) OF
   GPS-MeasuredResults
GPS-MeasuredResults ::=
                               SEQUENCE {
   gps-TOW-1msec INTEGER (0..604799999),
gps-MeasurementParamList GPS-MeasurementParamList,
iE-Extensions ProtocolExtensionContainer { GPS-MeasuredResults-ExtlEs }
  gps-TOW-1msec
}
  OPTIONAL,
   . . .
}
GPS-MeasuredResults-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   {ID id-UTRAN-GPSReferenceTimeResult CRITICALITY ignore EXTENSION UTRAN-GPSReferenceTimeResult
   PRESENCE optional },
```

```
. . .
}
GPS-MeasurementParamList ::=
                               SEQUENCE (SIZE (1..maxSat)) OF
                                    GPS-MeasurementParam
GPS-MeasurementParam ::=
                                SEQUENCE {
                                    INTEGÈR (0..63),
   satelliteID
   c-N0
                                    INTEGER (0..63),
                                    INTEGER (-32768..32768),
   doppler
                                    INTEGER (0..1022),
   wholeGPS-Chips
   fractionalGPS-Chips
                                    INTEGER (0..1023),
                                  MultipathIndicator,
   multipathIndicator
   pseudorangeRMS-Error
                                   INTEGER (0..63),
   iE-Extensions
                                    ProtocolExtensionContainer { GPS-MeasurementParam-ExtIEs }
  OPTIONAL,
}
                                ENUMERATED {
MultipathIndicator ::=
                                    nm,
                                    low,
                                    medium,
                                    high }
GPS-MeasurementParam-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ ***********************************
-- GPS Navigation Model
__ **********************************
GPS-NavigationModel ::= SEQUENCE (SIZE (1..maxSat)) OF
                                   NavigationModelSatInfo
{\tt NavigationModelSatInfo} ::= \\ {\tt SEQUENCE} \ \{
                                   INTEGER (0..63),
   satID
   satelliteStatus
                                    SatelliteStatus,
   gps-clockAndEphemerisParms
                                GPS-ClockAndEphemerisParameters
          OPTIONAL,
   -- This IE is not present if satelliteStatus is es-SN
                                    ProtocolExtensionContainer { { NavigationModelSatInfo-ExtIEs
   iE-Extensions
} } OPTIONAL,
NavigationModelSatInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
SatelliteStatus ::=
                                ENUMERATED {
                                    ns-NN,
                                    es-SN,
                                    es-NN.
                                    rev2,
                                    rev }
__ **********************
-- GPS Real Time Integrity
__ *****************
GPS-RealTimeIntegrity ::= CHOICE {
   badSatellites BadSatList,
noBadSatellites NoBadSatellites,
   . . .
}
```

```
BadSatList ::=
                            SEQUENCE (SIZE (1..maxSat)) OF
                                INTEGER (0..63)
NoBadSatellites ::= NULL
__ *********************
-- GPS Reference Location
__ **********************
GPS-ReferenceLocation ::= ue-PositionEstimate
                           SEQUENCE {
                               UE-PositionEstimate,
   iE-Extensions
                                ProtocolExtensionContainer { { GPS-ReferenceLocation-ExtIEs
} } OPTIONAL,
GPS-ReferenceLocation-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ *********************************
-- GPS Reference Time
GPS-ReferenceTime ::=
                            SEOUENCE {
                              INTEGER (0..1023),
  gps-Week
   gps-TOW-1msec
                                INTEGER (0..604799999),
   gps-TOW-AssistList
                               GPS-TOW-AssistList
   OPTIONAL.
                               ProtocolExtensionContainer { GPS-ReferenceTime-ExtIEs } }
   iE-Extensions
   OPTIONAL,
}
GPS-ReferenceTime-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional}
   {ID id-GPS-UTRAN-TRU
                              CRITICALITY ignore EXTENSION GPS-UTRAN-TRU
   PRESENCE optional |
   PRESENCE optional },
}
GPS-TOW-AssistList ::=
                            SEQUENCE (SIZE (1..maxSat)) OF
                                GPS-TOW-Assist
GPS-TOW-Assist ::=
                            SEQUENCE {
                                INTEGER (0..63),
   satID
                                BIT STRING (SIZE (14)),
   tlm-Message
   antiSpoof
                               BOOLEAN,
   alert
                                BOOLEAN,
   tlm-Reserved
                               BIT STRING (SIZE (2)),
                               ProtocolExtensionContainer { { GPS-TOW-Assist-ExtIEs } }
   iE-Extensions
   OPTIONAL,
}
GPS-TOW-Assist-Extles PCAP-PROTOCOL-EXTENSION ::= \{
}
UTRAN-GPS-DriftRate ::=
                             ENUMERATED {
                             utran-GPSDrift0, utran-GPSDrift1, utran-GPSDrift2,
                             utran-GPSDrift5, utran-GPSDrift10, utran-GPSDrift15,
                             utran-GPSDrift25, utran-GPSDrift50, utran-GPSDrift-1,
                             utran-GPSDrift-2, utran-GPSDrift-5, utran-GPSDrift-10,
                             utran-GPSDrift-15, utran-GPSDrift-25, utran-GPSDrift-50,
                             . . . }
```

```
__ *********************
-- GPS Transmission TOW
GPS-Transmission-TOW ::= INTEGER (0..604799)
__ **********************
-- GPS UTC Model
__ ********************************
GPS-UTC-Model ::=
                             SEQUENCE {
  a1
                                BIT STRING (SIZE (24)),
                                BIT STRING (SIZE (32)),
  a0
                                BIT STRING (SIZE (8)),
  t-ot
                               BIT STRING (SIZE (8)),
  delta-t-LS
  wn-t
                               BIT STRING (SIZE (8)),
   wn-lsf
                                BIT STRING (SIZE (8)),
  dn
                               BIT STRING (SIZE (8)),
   delta-t-LSE
                              BIT STRING (SIZE (8)),
                               ProtocolExtensionContainer { { GPS-UTCmodel-ExtIEs } }
   iE-Extensions
  OPTIONAL,
}
GPS-UTCmodel-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ **********************
-- GPS UTRAN Time Relationship Uncertainty
-- nsec=nanosecond, usec=microsecond, msec=millisecond, sec=second
__ ******************************
GPS-UTRAN-TRU ::= ENUMERATED {
                  nsec-50,
                   nsec-500,
                   usec-1.
                   usec-10,
                   msec-1,
                   msec-10,
                   msec-100,
                   unreliable,
                   . . . }
__ *******************************
-- Information Exchange ID
__ **********************************
InformationExchangeID ::= INTEGER (0..1048575)
-- Information Report Characteristics
__ *********************************
InformationReportCharacteristics ::= SEQUENCE {
  type InformationReportCharacteristicsType, periodicity InformationReportPeriodicity OPTIONAL,
  type
   -- present if type indicates periodic
InformationReportCharacteristicsType ::= ENUMERATED {
```

```
onDemand,
       periodic,
       onModification,
InformationReportPeriodicity ::= CHOICE {
                                     INTEGER (1..60, ...),
-- Unit min, Step 1min
                                    INTEGER (1..24, ...),
       hour
-- Unit hour, Step 1hour
__ ********************************
-- Information Type
__ **********************************
InformationType ::= CHOICE {
                                                      MethodType,
ExplicitInformationList,
        implicitInformation
        explicitInformation
}
ExplicitInformationList ::= SEQUENCE (SIZE (1..maxNrOfExpInfo)) OF ExplicitInformation
ExplicitInformation ::= CHOICE {
        almanacAndSatelliteHealth
                                                                                  AlmanacAndSatelliteHealth,
        ut.cModel
                                                                                  Ut.cModel.
        ionosphericModel
                                                                                  IonosphericModel,
        navigationModel
                                                                                  NavigationModel,
       dgpsCorrections
                                                                                  DgpsCorrections,
                                                                                  ReferenceTime,
       referenceTime
       acquisitionAssistance
                                                                                  AcquisitionAssistance,
       realTimeIntegrity
almanacAndSatelliteHealthSIB
                                                                               RealTimeIntegrity,
                                                                                 AlmanacAndSatelliteHealthSIB-InfoType,
                                                                               ReferenceLocation,
       referenceLocation
        ganss-Common-DataReq
                                                                                  GANSSCommonDataReq,
                                                                 GANSSGenericDataList
        ganss-Generic-DataList
}
DganssCorrectionsReq := SEQUENCE {
    transmissionGanssTimeIndicator TransmissionGanssTimeIndicator OPTIONAL,
                                                                 ProtocolExtensionContainer { { DganssCorrectionsReq-ExtIEs} }
        iE-Extensions
OPTIONAL,
{\tt DganssCorrectionsReq-ExtIEs\ PCAP-PROTOCOL-EXTENSION\ ::=\ \{}
Ganss-almanacAndSatelliteHealthReq ::= SEQUENCE {
        transmission {\tt GanssTimeIndicator} \quad {\tt Transmission GanssTimeIndicator} \quad {\tt OPTIONAL},
                                            {\tt ProtocolExtensionContainer} \ \{ \ \{ \ {\tt Ganss-almanacAndSatelliteHealthReq-tensionContainer} \ \} \ \ \{ \ {\tt Canss-almanacAndSatelliteHealthReq-tensionContainer} \ \} \ \ \{ \ {\tt Canss-almanacAndSatelliteHea
        iE-Extensions
ExtIEs } OPTIONAL,
}
Ganss-almanacAndSatelliteHealthReq-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GANSSCommonDataReq ::= SEQUENCE{
       ganss-ReferenceTime
                                                                          ENUMERATED {requested, not-requested}
                                                                                                                                                             OPTIONAL,
                                                                      ENUMERATED \{requested, not-requested\}
        ganss-IonosphericModel
                                                                                                                                                             OPTIONAL,
       ganss-ReferenceLocation
                                                                       ENUMERATED {requested, not-requested} OPTIONAL,
       ie-Extensions
                                                                        ProtocolExtensionContainer { { GANSSCommonDataReq-ExtIEs } }
}
```

```
GANSSCommonDataReq-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSSGenericDataList ::= SEQUENCE (SIZE(1..maxGANSS)) OF GANSSGenericDataReq
GANSSGenericDataReq ::= SEQUENCE {
   ganssID
                                                                                  OPTIONAL.
                                        INTEGER(0..7)
    ganss-realTimeIntegrity
                                         Ganss-realTimeIntegrityReq
                                                                                  OPTIONAL,
   dganssCorrections
                                        DganssCorrectionsReq
                                                                                 OPTIONAL,
   ganss-almanacAndSatelliteHealth
ganss-referenceMeasurementInfo
                                        Ganss-almanacAndSatelliteHealthReq
                                                                                 OPTIONAL,
                                        Ganss-referenceMeasurementInfoReq
                                                                                 OPTIONAL,
   ganss-utcModel
                                        Ganss-utcModelReq
                                                                                 OPTIONAL,
    ganss-TimeModel-Ganss-Ganss
                                        Ganss-TimeModel-Ganss-Ganss
                                                                                 OPTIONAL,
   navigationModel
                                        NavigationModelGANSS
                                                                                 OPTIONAL,
}
Ganss-utcModelReq ::= SEQUENCE {
    transmissionGanssTimeIndicator TransmissionGanssTimeIndicator OPTIONAL,
                                ProtocolExtensionContainer { { Ganss-utcModelReq-ExtIEs} } OPTIONAL,
    iE-Extensions
}
Ganss-utcModelReq-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
Ganss-realTimeIntegrityReg ::= SEOUENCE {
    transmissionGanssTimeIndicator TransmissionGanssTimeIndicator OPTIONAL,
                               ProtocolExtensionContainer { { Ganss-realTimeIntegrityReq-ExtIEs} }
OPTIONAL,
    . . .
Ganss-realTimeIntegrityReq-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt Ganss-referenceMeasurementInfoReq ::= SEQUENCE } \{
   transmissionGanssTimeIndicator TransmissionGanssTimeIndicator OPTIONAL,
                               ProtocolExtensionContainer { { Ganss-referenceMeasurementInfoReq-
    iE-Extensions
ExtIEs } OPTIONAL,
   . . .
Ganss-referenceMeasurementInfoReq-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
Ganss-TimeModel-Ganss-Ganss ::= SEQUENCE{
   ganssTimeModelGnssGnssExt BIT STRING (SIZE(9)),
    {\tt transmissionGanssTimeIndicator} \quad {\tt TransmissionGanssTimeIndicator} \quad {\tt OPTIONAL},
                                    ProtocolExtensionContainer { { Ganss-TimeModel-Ganss-Ganss-
    iE-Extensions
ExtIEs } OPTIONAL,
Ganss-TimeModel-Ganss-Ganss-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
TransmissionGanssTimeIndicator ::= INTEGER(0..7)
AlmanacAndSatelliteHealth ::= NULL
UtcModel ::= SEQUENCE {
    transmissionTOWIndicator TransmissionTOWIndicator,
                                ProtocolExtensionContainer { { UtcModel-ExtIEs } } OPTIONAL,
    iE-Extensions
}
UtcModel-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
```

```
IonosphericModel ::= SEQUENCE {
    transmissionTOWIndicator
                                TransmissionTOWIndicator,
    iE-Extensions
                                ProtocolExtensionContainer { { IonosphericModel-ExtIEs } } OPTIONAL,
IonosphericModel-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
NavigationModel ::= SEQUENCE {
                                TransmissionTOWIndicator,
    transmissionTOWIndicator
                                                                  OPTIONAL
   navModelAdditionalData
                                    NavModelAdditionalData
    iE-Extensions
                                ProtocolExtensionContainer { { NavigationModel-ExtIEs } }
   OPTIONAL,
    . . .
}
NavigationModel-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
NavModelAdditionalData ::= SEQUENCE {
                                INTEGER (0..1023),
   gps-Week
    gps-TOE
                                INTEGER (0..167),
                            INTEGER (0..10),
SatelliteRelatedDataList,
ProtocolExtensionContainer { { NavModelAdditionalData-ExtIEs } }
    t-TOE-limit
    satRelatedDataList
    iE-Extensions
OPTIONAL,
NavModelAdditionalData-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
SatelliteRelatedDataList ::= SEQUENCE (SIZE (0..maxSat)) OF SatelliteRelatedData
SatelliteRelatedData ::= SEQUENCE {
                                INTEGER (0..63),
                                INTEGER (0..255).
    iode
    iE-Extensions
                                ProtocolExtensionContainer { { SatelliteRelatedData-ExtIEs } }
OPTIONAL,
   . . .
}
SatelliteRelatedData-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
NavigationModelGANSS ::= SEQUENCE {
               INTEGER(0..4095),
    ganssT0E
                                INTEGER(0..167),
                               INTEGER(0..10),
    t-toe-limit
   satRelatedDataListGANSS SatelliteRelatedDataListGANSS,
iE-Extensions ProtocolExtensionContainer { { NavigationModelGANSS-ExtIEs } }
OPTIONAL,
}
NavigationModelGANSS-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
SatelliteRelatedDataListGANSS ::= SEQUENCE (SIZE (0..maxGANSSSat)) OF SatelliteRelatedDataGANSS
SatelliteRelatedDataGANSS ::= SEQUENCE {
                                INTEGER (0..63),
    satID
    iod
                                BIT STRING (SIZE(10)),
    iE-Extensions
                                ProtocolExtensionContainer { { SatelliteRelatedDataGANSS-ExtIEs } }
OPTIONAL,
SatelliteRelatedDataGANSS-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
DgpsCorrections ::= NULL
ReferenceTime ::= NULL
AcquisitionAssistance ::= NULL
RealTimeIntegrity ::= NULL
AlmanacAndSatelliteHealthSIB-InfoType ::= SEQUENCE {
  transmissionTOWIndicator TransmissionTOWIndicator,
                       ProtocolExtensionContainer { { AlmanacAndSatelliteHealthSIB-
   iE-Extensions
InfoType-ExtIEs } } OPTIONAL,
}
AlmanacAndSatelliteHealthSIB-InfoType-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt ReferenceLocation} \; ::= \; {\tt NULL} \;
TransmissionTOWIndicator ::= ENUMERATED {
  requested,
  not-Requested
}
__ *********************
-- Message Structure
__ *********************
MessageStructure ::= SEQUENCE (SIZE (1..maxNrOfLevels)) OF
   SEQUENCE {
     iE-ID
                        ProtocolIE-ID,
     repetitionNumber
                       MessageStructureRepetition
  OPTIONAL,
     iE-Extensions
                      ProtocolExtensionContainer { {MessageStructure-ExtIEs} }
OPTIONAL,
MessageStructureRepetition ::= INTEGER (1..256)
MessageStructure-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ *******************
-- Measurement Instructions Used
__ *********************
MeasInstructionsUsed ::= SEQUENCE {
  OPTIONAL,
}
MeasInstructionsUsed-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
 ******************
-- Measurement Validity
__ ***********************************
MeasurementValidity ::= SEQUENCE {
                 ENUMERATED { cell-DCH, all-States-Except-Cell-DCH, all-States, ... },
  ue-State
  }
```

```
MeasurementValidity-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
__ **********************
-- Method Type
__ *******************
MethodType ::= ENUMERATED {
    ue-assisted,
    ue-based
}
__ *****************
-- OTDOA Measurement Group
__ *********************
OTDOA-MeasurementGroup ::= SEQUENCE {
    otdoa-ReferenceCellInfo OTDOA-ReferenceCellInfo,
    otdoa-NeighbourCellInfoList OTDOA-NeighbourCellInfoL
    otdoa-MeasuredResultsSets OTDOA-MeasuredResultsSets
    iE-Extensions ProtocolExtensionContain
                                       OTDOA-NeighbourCellInfoList,
                                       OTDOA-MeasuredResultsSets,
                                      ProtocolExtensionContainer { { OTDOA-MeasurementGroup-ExtIEs
    iE-Extensions
} } OPTIONAL,
}
OTDOA-MeasurementGroup-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
                                        SEQUENCE {
OTDOA-ReferenceCellInfo ::=
                                       UC-ID,
   uTRANAccessPointPositionAltitude UTRANAccessPointPositionAltitude, tUTRANGPSMeasurementValueInfo TUTRANGPSMeasurementValueInfo
    tUTRANGPSMeasurementValueInfo
               OPTIONAL,
    iE-Extensions
                                       ProtocolExtensionContainer { { OTDOA-ReferenceCellInfo-
ExtIEs } } OPTIONAL,
OTDOA-ReferenceCellInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional },
TUTRANGANSSMeasurementValueInfo
}
OTDOA-NeighbourCellInfoList ::=
                                      SEQUENCE (SIZE (1..maxNrOfMeasNCell)) OF
   OTDOA-NeighbourCellInfo
                                       SEQUENCE {
OTDOA-NeighbourCellInfo ::=
    uC-ID
                                        UC-ID,
   uTRANAccessPointPositionAltitude UTRANAccessPointPositionAltit relativeTimingDifferenceInfo RelativeTimingDifferenceInfo,
                                        UTRANAccessPointPositionAltitude,
                                       ProtocolExtensionContainer { { OTDOA-NeighbourCellInfo-
    iE-Extensions
ExtIEs } } OPTIONAL,
OTDOA-NeighbourCellInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
OTDOA-MeasuredResultsSets ::=
                                        SEQUENCE (SIZE (1..maxNrOfMeasurements)) OF
    OTDOA-MeasuredResultsInfoList
OTDOA-MeasuredResultsInfoList ::=
                                       SEQUENCE (SIZE (1..maxNrOfMeasNCell)) OF
   OTDOA-MeasuredResultsInfo
OTDOA-MeasuredResultsInfo ::=
                                        SEQUENCE {
                                        UC-ID,
    ue-SFNSFNTimeDifferenceType2Info UE-SFNSFNTimeDifferenceType2Info,
    iE-Extensions
                                       ProtocolExtensionContainer { { OTDOA-MeasuredResultsInfo-
               OPTIONAL,
ExtIEs } }
```

```
}
OTDOA-MeasuredResultsInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
    {ID id-OTDOA-AddMeasuredResultsInfo CRITICALITY ignore EXTENSION OTDOA-AddMeasuredResultsInfo
    PRESENCE optional },
}
OTDOA-AddMeasuredResultsInfo ::= SEQUENCE {
   primaryCPICH-Info PrimaryScramblingCode,
    iE-Extensions
                           ProtocolExtensionContainer { { OTDOA-AddMeasuredResultsInfo-ExtIEs } }
       OPTIONAL,
}
OTDOA-AddMeasuredResultsInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
{\tt UE-SFNSFNTimeDifferenceType2Info} ::= \\ {\tt SEQUENCE} \ \{
   ue-SFNSFNTimeDifferenceType2INTEGER (0..40961),ue-PositioningMeasQualityUE-PositioningMeasQmeasurementDelayINTEGER (0..65535),
                                       UE-PositioningMeasQuality,
                                       INTEGER (0..65535),
                                       ProtocolExtensionContainer { { UE-SFNSFNTimeDifferenceInfo-
   iE-Extensions
ExtIEs } } OPTIONAL,
UE-SFNSFNTimeDifferenceInfo-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
UC-ID ::=
                                       SEQUENCE {
   rNC-ID
                                       INTEGER (0..4095),
    c-ID
                                        INTEGER (0..65535),
                                      ProtocolExtensionContainer { { UC-ID-ExtIEs } }
   iE-Extensions
   OPTIONAL,
}
UC-ID-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   optional},
   . . .
}
Extended-RNC-ID ::= INTEGER (4096..65535)
RelativeTimingDifferenceInfo ::= CHOICE {
   sFNSFNMeasurementValueInfo SFNSFNMeasurementValueInfo, tUTRANGPSMeasurementValueInfo TUTRANGPSMeasurementValueIn
                                       TUTRANGPSMeasurementValueInfo,
   tUTRANGANSSMeasurementValueInfo TUTRANGANSSMeasurementValueInfo
}
SFNSFNMeasurementValueInfo ::= SEQUENCE {
   sFNSFNValue
                                        SFNSFNValue,
   sFNSFNOuality
                                        SFNSFNOuality
       OPTIONAL,
    sFNSFNDriftRate
                                        SFNSFNDriftRate,
   sFNSFNDriftRateQuality
                                       SFNSFNDriftRateQuality
       OPTIONAL,
                                      ProtocolExtensionContainer { { SFNSFNMeasurementValueInfo-
   iE-Extensions
ExtIEs } } OPTIONAL,
SFNSFNMeasurementValueInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
SFNSFNValue ::=
                                        INTEGER (0..614399)
SFNSFNQuality ::=
                                        INTEGER (0..255)
-- Unit chip, Step 1/16 chip, Range 0.. 255/16 chip
```

```
SFNSFNDriftRate ::=
                                        INTEGER (-100..100)
-- Unit chip/s, Step 1/256 chip/s, Range -100/256..+100/256 chip/s
SFNSFNDriftRateQuality ::=
                                        INTEGER (0..100)
-- Unit chip/s, Step 1/256 chip/s, Range 0..100/256 chip/s
TUTRANGPSMeasurementValueInfo ::= SEQUENCE {
    sFN
    tUTRANGPS
                                         TUTRANGPS,
    tUTRANGPSQuality
                                         TUTRANGPSQuality
           OPTIONAL,
    tUTRANGPSDriftRate
                                         TUTRANGPSDriftRate.
                                   TUTRANGPSDriftRateQuality
    tUTRANGPSDriftRateQuality
           OPTIONAL,
   iE-Extensions
                                         ProtocolExtensionContainer { {
TUTRANGPSMeasurementValueInfo-ExtIEs } } OPTIONAL,
}
TUTRANGPSMeasurementValueInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
SFN ::=
                                         INTEGER (0..4095)
TUTRANGPS ::=
                                         SEQUENCE {
                                         INTEGER (0..16383),
   ms-part
   ls-part
                                         INTEGER (0..4294967295)
TUTRANGPSQuality ::=
                                         INTEGER (0..255)
-- Unit chip, Step 1/16 chip, Range 0.. 255/16 chip
TUTRANGPSDriftRate ::=
                                        INTEGER (-50..50)
-- Unit chip/s, Step 1/256 chip/s, Range -50/256..+50/256 chip/s
TUTRANGPSDriftRateQuality ::=
                                        INTEGER (0..50)
-- Unit chip/s, Step 1/256 chip/s, Range 0..50/256 chip/s
TUTRANGANSSMeasurementValueInfo ::= SEQUENCE {
   ganssID
                                     INTEGER(0..7)
    sFN
                                    SFN.
                                   TUTRANGANSS,
INTEGER(0..255)
    tUTRANGANSS
    tUTRANGANSSQuality INTEGER(0..255)
tUTRANGANSSDriftRate INTEGER(-50..50),
tUTRANGANSSDriftRateQuality INTEGER(0..50)
                                                             OPTIONAL,
                                                              OPTIONAL,
    iE-Extensions
                                        ProtocolExtensionContainer { {
TUTRANGANSSMeasurementValueInfo-ExtIEs } } OPTIONAL,
}
TUTRANGANSSMeasurementValueInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
TUTRANGANSS ::=
                                             SEQUENCE {
   ms-part
                                         INTEGER (0..16383),
                                         INTEGER (0..4294967295)
}
__ ********************************
-- Periodic Position Calculation Info
__ *********************
PeriodicPosCalcInfo ::= SEQUENCE {
   referenceNumber INTEGER (0..32767, ...),
   amountOutstandingRequests INTEGER (1..8639999, ...),
reportingInterval INTEGER (1..8639999, ...),
iE-Extensions ProtocolExtensionContainer { { PeriodicPosCalcInfo-ExtIEs } }
   OPTIONAL,
}
PeriodicPosCalcInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
__ ********************
-- Periodic Location Info
__ **********************************
PeriodicLocationInfo ::= SEQUENCE {
   reportingAmount INTEGER (1..8639999, ...), reportingInterval INTEGER (1..8639999, ...), iE-Extensions ProtocolExtension
   reportingAmount
                           ProtocolExtensionContainer { { PeriodicLocationInfo-ExtIEs } }
   OPTIONAL,
}
PeriodicLocationInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ *******************
-- Periodic Termination Cause
__ ********************************
PeriodicTerminationCause ::= ENUMERATED {
                 rrc-state-transition,
                 cancelled-by-srnc,
                  cancelled-by-sas,
                  undefined,
                  }
__ **********************************
-- Positioning Method
PositioningMethod ::= SEQUENCE {
  additionalMethodType AdditionalMethodType,
selectedPositionMethod SelectedPositionMethod,
iE-Extensions ProtocolExtensionContainer { { PositioningMethod-ExtIEs } }
   OPTIONAL,
   . . .
}
PositioningMethod-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
-- The following IE shall be present if the Selected Position Method IE value is set to "GNSS" or
   { ID id-GNSS-PositioningMethod CRITICALITY ignore EXTENSION GNSS-PositioningMethod
conditional },
GNSS-PositioningMethod ::= BIT STRING (SIZE(9))
SelectedPositionMethod ::= ENUMERATED {
   oTDOA,
   gPS,
   oTDOA-or-GPS,
   cell-id,
   uTDOA,
   gNSS,
   oTDOA-or-GNSS
}
__ ********************************
-- Positioning Priority
__ ***********************************
PositioningPriority ::= ENUMERATED {
   high-priority,
```

```
normal-priority,
}
__ **********************************
-- RRC State Change
__ *******************
RRCstateChange ::= SEQUENCE {
   new-ue-State ENUMERATED { cell-DCH, cell-FACH, cell-PCH, ura-PCH, ... }, iE-Extensions ProtocolExtensionContainer { { RRCstateChange-ExtlEs } } OPTIONAL,
}
RRCstateChange-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ *********************
-- Requested Data Value
__ ********************************
RequestedDataValue ::= SEQUENCE {
   gpsAlmanacAndSatelliteHealth
                                   GPS-AlmanacAndSatelliteHealth
   OPTIONAL,
   gps-UTC-Model
                                     GPS-UTC-Model
   OPTIONAL,
   gps-Ionospheric-Model
                                    GPS-Ionospheric-Model
   OPTIONAL,
   qps-NavigationModel
                                     GPS-NavigationModel
   OPTIONAL,
   dgpsCorrections
                                     DGPSCorrections
   OPTIONAL,
   referenceTime
                                     GPS-ReferenceTime
   OPTIONAL,
   gps-AcquisitionAssistance
                                     GPS-AcquisitionAssistance
   OPTIONAL,
   gps-RealTime-Integrity
                                     GPS-RealTimeIntegrity
   OPTIONAL,
   almanacAndSatelliteHealthSIB
                                    AlmanacAndSatelliteHealthSIB
   OPTIONAL,
   gps-Transmission-TOW
                                     GPS-Transmission-TOW
   OPTIONAL.
   iE-Extensions
                                     ProtocolExtensionContainer { { RequestedDataValue-ExtIEs} }
   OPTIONAL,
   . . .
}
--at least one of the above IEs shall be present in the requested data value
RequestedDataValue-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
    \{ \hbox{ \tt ID id-GPS-ReferenceLocation} \quad \hbox{\tt CRITICALITY ignore} \quad \hbox{\tt EXTENSION GPS-ReferenceLocation} \quad \hbox{\tt PRESENCE} \\
optional }|
   PRESENCE optional } |
   { ID id-GANSS-GenericAssistanceDataList CRITICALITY ignore EXTENSION GANSS-
GenericAssistanceDataList PRESENCE optional },
__ **********************************
-- Requested Data Value Information
__ *********************************
RequestedDataValueInformation ::= CHOICE {
   informationAvailable InformationAvailable, informationNotAvailable InformationNotAvailable
}
InformationAvailable::= SEQUENCE {
   requestedDataValue RequestedDataValue,
```

```
ProtocolExtensionContainer { { InformationAvailable-ExtIEs} }
   iE-Extensions
   OPTIONAL,
}
InformationAvailable-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
InformationNotAvailable ::= NULL
__ *********************************
__ ********************
RequestType ::= SEQUENCE \{
   event RequestTypeEvent, reportArea RequestTypeReportArea,
   horizontalaccuracyCode RequestTypeAccuracyCode
                                                  OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { { RequestType-ExtIEs} } OPTIONAL,
}
RequestType-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RequestTypeEvent ::= ENUMERATED {
   stop-change-of-service-area,
   direct,
   change-of-service-area,
   stop-direct,
   periodic,
   stop-periodic
}
RequestTypeReportArea ::= ENUMERATED {
   service-area,
   geographical-area,
}
RequestTypeAccuracyCode ::= INTEGER (0..127)
__ *********************************
-- Response Time
__ ********************************
ResponseTime ::= ENUMERATED {
  low-delay,
   delay-tolerant,
}
__ ********************************
-- Horizontal Accuracy Code
__ **********************
                             ::= INTEGER (0..127)
HorizontalAccuracyCode
__ *******************
-- UE Positioning Capability
__ *********************************
UE-PositioningCapability ::= SEQUENCE {
   standAloneLocationMethodsSupported
ueBasedOTDOASupported
networkAssistedGPSSupport
supportGPSTimingOfCellFrame
supportForIPDL
supportForIPDL
BOOLEAN,
BOOLEAN,
BOOLEAN,
BOOLEAN,
                                   BOOLEAN,
BOOLEAN,
   supportForRxTxTimeDiff
   supportForUEAGPSinCellPCH
```

```
supportForSFNSFNTimeDiff
                                  BOOLEAN,
                                    ProtocolExtensionContainer { {UE-PositioningCapability-
   iE-Extensions
ExtIEs }   OPTIONAL,
UE-PositioningCapability-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   { ID id-NetworkAssistedGANSSSuport CRITICALITY ignore EXTENSION
                            PRESENCE optional },
NetworkAssistedGANSSSupport
}
NetworkAssistedGANSSSupport ::= SEQUENCE (SIZE (1..maxGANSS)) OF SEQUENCE {
                                    INTEGER(0..7)
   ganssMode
                                    ENUMERATED {
      networkBased,
       ue-Based,
       both,
       none
       },
                                    INTEGER(0..3,...) OPTIONAL,
   ganssSignalID
   supportGANSSTimingOfCellFrame
                                   BOOLEAN,
   supportGANSSCarrierPhaseMeasurement BOOLEAN,
   iE-Extensions ProtocolExtensionContainer { { NetworkAssistedGANSSSuport-ExtIEs} } OPTIONAL,
}
NetworkAssistedGANSSSuport-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
NetworkAssistedGPSSuport ::= ENUMERATED {
   network-based,
   ue-based,
   both,
   none,
}
__ **********************
-- UTDOA Positioning (Position Activation Request Message)
__ *******************
UTDOAPositioning ::= SEQUENCE {
   utdoa-BitCount UTDOA-BitCount, utdoa-timeInterval UTDOA-TimeInterval,
   iE-Extensions ProtocolExtensionContainer { { UTDOAPositioning-ExtIEs } } OPTIONAL,
   . . .
}
UTDOAPositioning-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
UTDOA-BitCount ::= INTEGER (0..5000)
UTDOA-TimeInterval ::= INTEGER (0..3000)
EnvironmentCharacterisation ::= ENUMERATED { heavyMultipathandNLOSconditions,
              noOrLightMultipathAndUsuallyLOSconditions,
              notDefinedOrMixedEnvironment,
              } . . .
__ *********************************
-- GPS and GANSS Positioning (Position Activation Request Message)
__ *********************************
GPSPositioning ::= SEQUENCE {
   gpsPositioningInstructions
                               GPSPositioningInstructions,
   requestedDataValue
                               RequestedDataValue
                                                          OPTIONAL,
```

```
ProtocolExtensionContainer { GPSPositioning-ExtIEs } }
   iE-Extensions
OPTIONAL,
}
GPSPositioning-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
GPSPositioningInstructions ::= SEQUENCE {
   horizontalAccuracyCode HorizontalAccuracyCode OPTIONAL,
   verticalAccuracyCode
                                        VerticalAccuracyCode
                                                                         OPTIONAL.
   gpsTimingOfCellWanted
                                       BOOLEAN,
   additionalAssistanceDataRequest BOOLEAN,
    iE-Extensions
                                       ProtocolExtensionContainer { { GPSPositioningInstructions-
ExtIEs } } OPTIONAL,
}
GPSPositioningInstructions-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   {ID id-MeasurementValidity CRITICALITY ignore EXTENSION
                                                                MeasurementValidity PRESENCE
optional },
   . . .
GANSSPositioning ::= SEQUENCE {
   ganssPositioningInstructions GANSS-PositioningInstructions,
   requestedDataValue RequestedDataValue iE-Extensions ProtocolExtensionCo
                                                                     OPTIONAL,
                                   ProtocolExtensionContainer { { GANSSPositioning-ExtIEs } }
    iE-Extensions
OPTIONAL,
GANSSPositioning-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSS-PositioningInstructions ::= SEQUENCE {
   horizontalAccuracyCode HorizontalAccuracyCode verticalAccuracyCode GanssTimingOfCellWanted HorizontalAccuracyCode BIT STRING (SIZE (16)),
                                                                     OPTIONAL,
                                                                         OPTIONAL,
   ganssTimingOfCellWanted BIT STRING (SIZE (16)), additionalAssistanceDataRequest measurementValidity GANSSMeasurementValidity iE-Extensions
                                                                        OPTIONAL.
                                        ProtocolExtensionContainer { { GANSS-
PositioningInstructions-ExtIEs } } OPTIONAL,
}
GANSS-PositioningInstructions-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
GANSSMeasurementValidity ::= ENUMERATED {
    allStatesExceptDCH,
   allStates,
}
__ ********************************
-- OTDOA Assistance Data
__ ********************
OTDOAAssistanceData ::= SEQUENCE {
    uE-Positioning-OTDOA-AssistanceData UE-Positioning-OTDOA-AssistanceData,
    iE-Extensions
                                        ProtocolExtensionContainer { { OTDOAAssistanceData-ExtIEs }
} OPTIONAL,
OTDOAAssistanceData-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__ ******************
-- UE Positioning OTDOA Assistance Data
```

__ ******************

```
OPTIONAL,
   ue-positioning-OTDOA-NeighbourCellList
                                              UE-Positioning-OTDOA-NeighbourCellList
      OPTIONAL,
                                 ProtocolExtensionContainer { { UE-Positioning-
   iE-Extensions
OTDOAAssistanceData-ExtIEs \} OPTIONAL,
}
UE-Positioning-OTDOAAssistanceData-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
UE-Positioning-OTDOA-ReferenceCellInfo ::= SEQUENCE {
                                  SFN
                                                               OPTIONAL,
   modeSpecificInfo CHOICE {
                                        SEQUENCE {
      fdd
        primaryCPICH-Info
                                        PrimaryScramblingCode,
      },
                                        SEQUENCE {
       tdd
       --- coding is FFS
      },
       . . .
   },
                                FrequencyInfo
                                                               OPTIONAL.
   frequencyInfo
   positioningMode CHOICE {
                                        SEQUENCE {
      ueBased
         cellPosition
                                               ReferenceCellPosition OPTIONAL,
          -- actual value roundTripTime = (IE value * 0.0625) + 876
                                        INTEGER (0..32766)
                                                                  OPTIONAL,
         roundTripTime
       },
       ueAssisted
                                        SEQUENCE {
       },
       . . .
   UE-Positioning-IPDL-Parameters OPTIONAL,
OTDOAReferenceCellInfo-ExtIEs } } OPTIONAL,
}
UE-Positioning-OTDOAReferenceCellInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional }, -- FDD only
}
ReferenceCellPosition ::= CHOICE {
   ellipsoidPoint Geogram
   ellipsoidPointWithAltitude GA-Po
                              GeographicalCoordinates,
                                 GA-PointWithAltitude,
}
UE-Positioning-IPDL-Parameters ::=
                                    SEQUENCE {
   modeSpecificInfo
                                  CHOICE {
                                     SEQUENCE {
      fdd
         ip-Spacing
                                        IP-Spacing,
          ip-Length
                                        IP-Length,
          ip-Offset
                                        INTEGER (0..9),
                                        INTEGER (0..63),
          seed
                                    SEQUENCE {
          -- coding is FFS
       },
                                 BurstModeParameters
                                                            OPTIONAL,
   burstModeParameters
```

```
iE-Extensions
                                     ProtocolExtensionContainer { { UE-Positioning-IPDL-
Parameters-ExtIEs } } OPTIONAL,
}
UE-Positioning-IPDL-Parameters-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
IP-Spacing ::=
                                  ENUMERATED {
                                     e5, e7, e10, e15, e20,
                                     e30, e40, e50, ... }
IP-Length ::=
                                 ENUMERATED {
                                     ipl5, ipl10, ... }
                                 SEQUENCE {
BurstModeParameters ::=
                                     INTEGER (0..15),
   burstStart
                                     INTEGER (10..25),
   burstLength
   burstFreq
                                     INTEGER (1..16),
                                     ProtocolExtensionContainer { { BurstModeParameters-ExtIEs }
   iE-Extensions
} OPTIONAL,
}
BurstModeParameters-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
UE-Positioning-OTDOA-NeighbourCellList ::= SEQUENCE (SIZE (1..maxCellMeas)) OF
                                         UE-Positioning-OTDOA-NeighbourCellInfo
UE-Positioning-OTDOA-NeighbourCellInfo ::= SEQUENCE {
   modeSpecificInfo CHOICE {
       fdd
                                     SEOUENCE {
           primaryCPICH-Info
                                             PrimaryScramblingCode,
       },
                                     SEOUENCE {
       t.dd
           -- coding is FFS
           . . .
       },
   frequencyInfo
                                     FrequencyInfo
                                                                       OPTIONAL,
   ue-positioning-IPDL-Paremeters UE-Positioning-IPDL-Parameters
                                                                       OPTIONAL,
   sfn-SFN-RelTimeDifference
                                     SFN-SFN-RelTimeDifferencel,
   sfn-Offset-Validity
                                     SFN-Offset-Validity
                                                                       OPTIONAL.
   sfn-SFN-Drift
                                     SFN-SFN-Drift
                                                                       OPTIONAL,
   searchWindowSize
                                     OTDOA-SearchWindowSize,
                    CHOICE {
   positioningMode
                                             SEQUENCE {
       ueBased
          relativeNorth
                                             INTEGER (-20000..20000)
                                                                               OPTIONAL,
           relativeEast
                                             INTEGER (-20000..20000)
                                                                               OPTIONAL,
           relativeAltitude
                                             INTEGER (-4000..4000)
                                                                               OPTIONAL,
                                             FineSFNSFN
                                                                              OPTIONAL.
           -- actual value roundTripTime = (IE value * 0.0625) + 876
           roundTripTime
                                             INTEGER (0.. 32766)
                                                                               OPTIONAL,
       },
                                             SEQUENCE {
       ueAssisted
          . . .
       },
       . . .
                                     ProtocolExtensionContainer { { UE-Positioning-
   iE-Extensions
OTDOANeighbourCellInfo-ExtIEs } } OPTIONAL,
}
UE-Positioning-OTDOANeighbourCellInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   PRESENCE optional }, -- FDD only
```

```
}
{\tt SFN-SFN-RelTimeDifference1} ::= \\ {\tt SEQUENCE} \ \{
  sin-offset INTEGER (0 .. 4095), sfn-sfn-Reltimedifference INTEGER (0.. 38399), iE-Extensions
                               ProtocolExtensionContainer { { SFN-SFN-RelTimeDifference1-
ExtIEs } } OPTIONAL,
SFN-SFN-RelTimeDifferencel-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
SFN-Offset-Validity ::=
                          ENUMERATED { false }
OTDOA-SearchWindowSize ::=
                              ENUMERATED {
                                 c20, c40, c80, c160, c320,
                                  c640, c1280, moreThan1280, ... }
                              ENUMERATED {
SFN-SFN-Drift ::=
                                  sfnsfndrift0, sfnsfndrift1, sfnsfndrift2,
                                  sfnsfndrift3, sfnsfndrift4, sfnsfndrift5,
                                  sfnsfndrift8, sfnsfndrift10, sfnsfndrift15,
                                  sfnsfndrift25, sfnsfndrift35, sfnsfndrift50,
                                  sfnsfndrift65, sfnsfndrift80, sfnsfndrift100,
                                  sfnsfndrift-1, sfnsfndrift-2, sfnsfndrift-3,
                                  sfnsfndrift-4, sfnsfndrift-5, sfnsfndrift-8,
                                  sfnsfndrift-10, sfnsfndrift-15, sfnsfndrift-25,
                                  sfnsfndrift-35, sfnsfndrift-50, sfnsfndrift-65,
                                  sfnsfndrift-80, sfnsfndrift-100, ...}
FineSFNSFN ::= INTEGER (0..15)
-- Range 0..0.9375 step size 0.0625
__ *********************
-- Vertical Accuracy Code
__ *****************
VerticalAccuracyCode
                          ::= INTEGER (0..127)
-- UTDOA Group
UTDOA-Group ::= SEQUENCE {
                                 UC-ID,
  uC-ID
                                 FrequencyInfo,
   frequencyInfo
   Trequency into
uTDOA-ChannelSettings
UTDOA-RRCState,
ProtocolExtensionContainer { { UTDOA-Group-ExtIEs } }
   OPTIONAL,
}
UTDOA-Group-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
FrequencyInfo ::=
                              SEQUENCE {
   modeSpecificInfo
                                  CHOICE {
      fdd
                                     FrequencyInfoFDD,
      tdd
                                     FrequencyInfoTDD,
      . . .
     },
   OPTIONAL,
   . . .
}
```

```
FrequencyInfo-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
FrequencyInfoFDD ::=
                                    SEQUENCE {
                                       UARFCN
                                                           OPTIONAL,
   uarfcn-UL
                                        UARFCN,
   uarfcn-DL
   iE-Extensions
                        ProtocolExtensionContainer { { FrequencyInfoFDD-ExtIEs } }
    OPTIONAL,
}
FrequencyInfoFDD-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
FrequencyInfoTDD ::=
                                    SEQUENCE {
   uarfcn
                                        UARFCN,
    iE-Extensions ProtocolExtensionContainer { {FrequencyInfoTDD-ExtIEs} }
    OPTIONAL,
}
FrequencyInfoTDD-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
UTDOA-RRCState ::= CHOICE {
    uTDOA-CELLDCH UTDOA-CELLDCH,
    uTDOA-CELLFACH UTDOA-CELLFACH,
}
__ ******************
-- UTDOA Cell DCH Information
__ ***********
                      SEQUENCE {
UTDOA-CELLDCH ::=
   uL-DPCHInfo
                                                UL-DPCHInfo.
                                                Compressed-Mode-Assistance-Data OPTIONAL,
    compressedModeAssistanceData
                                                DCH-Information OPTIONAL,
E-DPCH-Information OPTIONAL,
   dCH-Information
    e-DPCH-Information
                                    ProtocolExtensionContainer { { UTDOA-CELLDCH-ExtIEs} },
    iE-Extensions
}
UTDOA-CELLDCH-ExtIES PCAP-PROTOCOL-EXTENSION ::= {
UL-DPCHInfo ::=
                                    CHOICE {
                                            SEQUENCE {
            scramblingCodeType
                                                ScramblingCodeType,
            scramblingCode
                                                UL-ScramblingCode,
            tfci-Existence
                                                BOOLEAN,
           numberOfFBI-Bits NumberOfFBI-Bits,
iE-Extensions ProtocolExtensionContainer { { UL-DPCHInfoFDD-ExtIEs} },
        },
        tdd
                                            SEQUENCE {
            cellParameterID
                                                CellParameterID,
            tFCI-Coding
                                                TFCI-Coding,
            punctureLimit
                                                PuncturingLimit,
            repetitionPeriod
                                                RepetitionPeriod,
                                                RepetitionLength,
            repetitionLength
            tdd-DPCHOffset
                                                TDD-DPCHOffset,
            UL-Timeslot-:

remeOffset FrameOffset,

specialBurstScheduling

iE-Extensions
                                               UL-Timeslot-Information,
                                                SpecialBurstScheduling,
            iE-Extensions ProtocolExtensionContainer { { UL-DPCHInfoTDD-ExtIEs} },
        },
        . . .
```

```
UL-DPCHInfoFDD-ExtIES PCAP-PROTOCOL-EXTENSION ::= {
UL-DPCHInfoTDD-ExtIES PCAP-PROTOCOL-EXTENSION ::= {
}
Compressed-Mode-Assistance-Data ::= SEQUENCE {
           dl-information
ul-information
                                          DL-InformationFDD,
                                          UL-InformationFDD,
           iE-Extensions
                                          ProtocolExtensionContainer { { Compressed-Mode-
Assistance-DataFDD-ExtIEs} },
}
Compressed-Mode-Assistance-DataFDD-ExtIEs
                                            PCAP-PROTOCOL-EXTENSION ::= {
                                  SEQUENCE {
DL-InformationFDD ::=
                                                  PrimaryScramblingCode,
           primaryScramblingCode
           primaryScramblingCode
chipOffset
frameOffset
                                          ChipOffset,
           frameOffset
                                          FrameOffset,
           iE-Extensions ProtocolExtensionContainer { { DL-InformationFDD-ExtIEs} } ,
       }
DL-InformationFDD-ExtIEs
                             PCAP-PROTOCOL-EXTENSION ::= {
UL-InformationFDD ::=
                                   SEQUENCE {
          transmissionGapPatternSequenceInfo
                                                     Transmission-Gap-Pattern-Sequence-
Information,
           activePatternSequenceInfo
                                                      Active-Pattern-Sequence-Information,
           cFN
                                                      CFN,
           iE-Extensions
                                         ProtocolExtensionContainer { { UL-InformationFDD-ExtIEs}
},
           . . .
UL-InformationFDD-ExtIEs
                             PCAP-PROTOCOL-EXTENSION ::= {
}
Transmission-Gap-Pattern-Sequence-Information ::= SEQUENCE (SIZE (1..maxTGPS)) OF
   SEOUENCE {
                                           TGPSID.
       +GPSTD
       tGSN
                                           TGSN,
       tGL1
                                           GapLength,
                                           GapLength OPTIONAL,
       tGL2
       t.GD
                                           TGD,
       tGPL1
                                           GapDuration,
       uplink-Compressed-Mode-Method Uplink-Compressed-Mode-Method,
       iE-Extensions
                       ProtocolExtensionContainer { {Transmission-Gap-Pattern-Sequence-
Information-ExtIEs} } OPTIONAL,
Transmission-Gap-Pattern-Sequence-Information-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
TGD
                   ::= INTEGER (0|15..269)
-- 0 = Undefined, only one transmission gap in the transmission gap pattern sequence
                  ::= INTEGER (0..511)
-- 0 = infinity
TGPSID
                   ::= INTEGER (1.. maxTGPS)
TGSN
                  ::= INTEGER (0..14)
```

```
Uplink-Compressed-Mode-Method ::= ENUMERATED {
   sFdiv2.
   higher-layer-scheduling,
}
GapDuration
                      ::= INTEGER (1..144,...)
-- Unit frame
GapLength
                      ::= INTEGER (1..14)
-- Unit slot
Active-Pattern-Sequence-Information ::= SEQUENCE {
   cMConfigurationChangeCFN
                                                CFN.
    {\tt transmission-Gap-Pattern-Sequence-Status}
                                               Transmission-Gap-Pattern-Sequence-Status-List
   OPTIONAL,
   iE-Extensions
                                               ProtocolExtensionContainer { {Active-Pattern-
Sequence-Information-ExtIEs} } OPTIONAL,
}
Active-Pattern-Sequence-Information-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
Transmission-Gap-Pattern-Sequence-Status-List ::= SEQUENCE (SIZE (1..maxTGPS)) OF
   SEOUENCE {
       tGPSID
                           TGPSID,
                           TGPRC.
        t.GPRC
        tGCFN
                            CFN,
                           ProtocolExtensionContainer { { Transmission-Gap-Pattern-Sequence-Status-
       iE-Extensions
List-ExtIEs \} \} OPTIONAL,
}
Transmission-Gap-Pattern-Sequence-Status-List-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
DCH-Information ::= SEQUENCE {
   tFCS
                                                TFCS,
    trChInfo
                                               TrChInfoList.
   iE-Extensions
                                   ProtocolExtensionContainer { { DCH-Information-ExtIEs} },
}
                          PCAP-PROTOCOL-EXTENSION ::= {
DCH-Information-ExtIEs
TrChInfoList ::= SEQUENCE (SIZE(1..maxTrCH)) OF
       UL-TrCHInfo
                   SEQUENCE {
UL-TrCHInfo ::=
                                       UL-TrCHType,
   uL-TrCHtype
    t.fs
                                        TransportFormatSet,
    iE-Extensions
                                       ProtocolExtensionContainer { { UL-TrCHInfo-ExtIEs} },
}
UL-TrCHInfo-ExtIEs
                     PCAP-PROTOCOL-EXTENSION ::= {
UL-TrCHType ::= ENUMERATED {dch, usch, ...}
E-DPCH-Information ::= SEQUENCE {
   maxSet-E-DPDCHs
                                               Max-Set-E-DPDCHs,
   ul-PunctureLimit
                                               PuncturingLimit,
   e-TFCS-Information
                                               E-TFCS-Information,
   e-TTI
                                               E-TTI,
                                               E-DPCCH-PO
   e-DPCCH-PO
                                                                   OPTIONAL,
                                               ProtocolExtensionContainer { { E-DPCH-Information-
   iE-Extensions
          OPTIONAL,
ExtIEs } }
```

```
E-DPCH-Information-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
Max-Set-E-DPDCHs ::= ENUMERATED {
   vN64, vN32, vN16, vN8, v2xN4, v2xN2, v2xN2plus2xN4,
-- Values related to [16]
E-TFCS-Information ::= SEQUENCE {
   e-DCH-TFCS-Index
                                                   E-DCH-TFCS-Index,
   reference-E-TFCI-Information
                                                    Reference-E-TFCI-Information
                                                                                       OPTIONAL,
                                                   ProtocolExtensionContainer { {E-TFCS-
   iE-Extensions
Information-ExtIEs} }
                           OPTIONAL,
E-TFCS-Information-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
E-DCH-TFCS-Index ::= INTEGER (1..4,...)
Reference-E-TFCI-Information ::= SEQUENCE (SIZE (1..maxNrOfRefETFCIs)) OF Reference-E-TFCI-
Information-Item
Reference-E-TFCI-Information-Item ::= SEQUENCE {
                       E-TFCI,

Reference-E-TFCI-PO,

ProtocolExtensionContainer { { Reference-E-TFCI-Information-
  reference-E-TFCI
   reference-E-TFCI-PO
   iE-Extensions
Item-ExtIEs} } OPTIONAL,
Reference-E-TFCI-Information-Item-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
Reference-E-TFCI-PO ::= INTEGER (0.. maxNrOfRefETFCI-PO-QUANTSTEPs)
    -- FFS according to mapping in [17]
E-TFCI ::= INTEGER (0..127)
E-TTI ::= ENUMERATED {
   e-TTI-2ms,
   e-TTI-10ms,
}
E-DPCCH-PO ::= INTEGER (0..maxNrOfEDPCCH-PO-QUANTSTEPs)
CellParameterID ::= INTEGER (0..127,...)
TFCI-Coding ::= ENUMERATED {
   v4,
   ₹8.
   v16,
   v32,
    . . .
}
RepetitionLength ::= INTEGER (1..63)
RepetitionPeriod ::= ENUMERATED {
   v1,
   v2,
   v4,
   v8,
   v16,
   v32,
   v64,
    . . .
}
```

```
TDD-DPCHOffset ::= CHOICE {
   initialOffset INTEGER (0..255),
noinitialOffset INTEGER (0..63)
}
UL-Timeslot-Information ::= SEQUENCE (SIZE (1..maxNrOfULTSs)) OF UL-Timeslot-InformationItem
maxNrOfULTSs
                        INTEGER ::= 15
UL-Timeslot-InformationItem ::= SEQUENCE {
   timeSlot
                                        TimeSlot,
   midambleShiftAndBurstType
                                       MidambleShiftAndBurstType,
   tFCI-Presence
                                       BOOLEAN.
   uL-Code-InformationList
                                       TDD-UL-Code-Information,
   iE-Extensions
                                       ProtocolExtensionContainer { { UL-Timeslot-
InformationItem-ExtIEs} }
OPTIONAL,
UL-Timeslot-InformationItem-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
TimeSlot ::= INTEGER (0..14)
                               CHOICE {
MidambleShiftAndBurstType ::=
                                   SEQUENCE {
       midambleAllocationMode CHOICE {
          defaultMidamble
                                           NULL.
          commonMidamble
                                           NULL,
          ueSpecificMidamble
                                           MidambleShiftLong,
       },
   . . .
   type2
                                    SEQUENCE {
                                    MidambleConfigurationBurstType2,
       midambleConfigurationBurstType2
       midambleAllocationMode
                                       CHOICE {
          defaultMidamble
                                           NULL,
          commonMidamble
                                           NULL,
          ueSpecificMidamble
                                           MidambleShiftShort.
       },
       . . .
   },
                                   SEQUENCE {
   type3
       \verb| midambleAllocationMode| \\ \verb| CHOICE| \{
        defaultMidamble
          ueSpecificMidamble
                                           MidambleShiftLong,
       },
       . . .
   },
MidambleShiftLong ::=
                               INTEGER (0..15)
MidambleShiftShort ::=
                                INTEGER (0..5)
MidambleConfigurationBurstType1And3 ::= ENUMERATED {v4, v8, v16}
MidambleConfigurationBurstType2 ::= ENUMERATED {v3, v6}
TDD-UL-Code-Information ::= SEQUENCE (SIZE (1..maxNrOfDPCHs)) OF TDD-UL-Code-InformationItem
                         INTEGER ::= 240
maxNrOfDPCHs
TDD-UL-Code-InformationItem ::= SEQUENCE {
   tdd-ChannelisationCode
                                       TDD-ChannelisationCode,
                                       ProtocolExtensionContainer { { TDD-UL-Code-
   iE-Extensions
InformationItem-ExtIEs} }
OPTIONAL,
TDD-UL-Code-InformationItem-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
}
TDD-ChannelisationCode ::= ENUMERATED {
   chCodeldiv1,
   chCode2div1,
   chCode2div2,
   chCode4div1,
   chCode4div2,
   chCode4div3,
   chCode4div4,
   chCode8div1,
   chCode8div2,
   chCode8div3,
   chCode8div4,
   chCode8div5,
   chCode8div6,
   chCode8div7,
   chCode8div8,
   chCode16div1,
   chCode16div2,
   chCode16div3,
   chCode16div4,
   chCode16div5,
   chCode16div6.
   chCode16div7,
   chCode16div8,
   chCode16div9,
   chCode16div10,
   chCode16div11,
    chCode16div12,
   chCode16div13,
   chCode16div14,
   chCode16div15,
   chCode16div16,
}
SpecialBurstScheduling ::= INTEGER (1..256) -- Number of frames between special burst transmission
during DTX
__ ****************
-- UTDOA Cell Fach Information
__ ***************
UTDOA-CELLFACH ::= SEQUENCE {
   pRACHparameters
                                            PRACHparameters,
   cRNTI
                                            C-RNTI,
   uschParameters
                                            UschParameters
                                                                   OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { { UTDOA-CELLFACH-ExtIEs} },
{\tt UTDOA-CELLFACH-ExtIEs} \qquad \qquad {\tt PCAP-PROTOCOL-EXTENSION} \; ::= \; \big\{
PRACHparameters ::= SEQUENCE (SIZE (1..maxPRACH)) OF
   PRACH-ChannelInfo
PRACH-ChannelInfo ::= SEQUENCE {
                               PRACH-Info,
  pRACH-Info
   tFS
                               TransportFormatSet,
    tFCS
                               TFCS,
   \verb|iE-Extensions| & ProtocolExtensionContainer { { PRACH-ChannelInfo-ExtIEs} } |,
}
PRACH-ChannelInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
                                   CHOICE {
PRACH-Info ::=
```

```
SEQUENCE {
        fdd
            availableSignatures
                                                  AvailableSignatures,
            availableSF
                                                  SF-PRACH,
            preambleScramblingCodeWordNumber
puncturingLimit PuncturingLimit,
availableSubChannelNumbers AvailableSubChannelNumbers,
                            ProtocolExtensionContainer { { PRACH-Info-FDD-ExtIEs} },
            iE-Extensions
        },
        tdd
                                         SEQUENCE {
                    timeSlot
                                                              TimeSlot,
            tdd-ChannelisationCode
                                                      TDD-ChannelisationCode,
            maxPRACH-MidambleShifts
                                                      MaxPRACH-MidambleShifts,
            pRACH-Midamble
                                                      PRACH-Midamble,
            iE-Extensions ProtocolExtensionContainer { { PRACH-Info-TDD-ExtIEs} },
        },
}
PRACH-Info-FDD-ExtIEs
                           PCAP-PROTOCOL-EXTENSION ::= {
{\tt PRACH-Info-TDD-ExtIEs} \qquad \qquad {\tt PCAP-PROTOCOL-EXTENSION} \; ::= \; \big\{
SF-PRACH ::=
                                      ENUMERATED {
                                         sfpr32, sfpr64, sfpr128, sfpr256, ... }
AvailableSignatures ::=
                                 BIT STRING {
                                      signature15(0),
                                      signature14(1),
                                      signature13(2),
                                      signature12(3),
                                      signature11(4),
                                      signature10(5),
                                      signature9(6),
                                      signature8(7),
                                      signature7(8),
                                      signature6(9).
                                      signature5(10),
                                      signature4(11),
                                      signature3(12),
                                      signature2(13),
                                      signature1(14),
                                      signature0(15)
                                          (SIZE(16))
                                      }
PreambleScramblingCodeWordNumber ::=
                                        INTEGER (0..15)
PuncturingLimit ::=
                        INTEGER (0..15)
-- 0: 40%; 1: 44%; ... 14: 96%; 15: 100%
AvailableSubChannelNumbers ::=
                                      BIT STRING {
                                         subCh11(0),
                                          subCh10(1),
                                          subCh9(2),
                                          subCh8(3),
                                          subCh7(4),
                                          subCh6(5),
                                          subCh5(6),
                                          subCh4(7),
                                          subCh3(8),
                                          subCh2(9),
                                          subCh1(10),
                                          subCh0(11)
                                               (SIZE(12))
                                     ENUMERATED {
ScramblingCodeType ::=
                                          shortSC,
                                          longSC }
UL-ScramblingCode ::=
                                     INTEGER (0..16777215)
```

```
NumberOfFBI-Bits ::=
                               INTEGER (0..2)
TransportFormatSet ::=
                                              SEQUENCE {
   OPTIONAL,
}
TransportFormatSet-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
TransportFormatSet-DynamicPartList ::= SEQUENCE (SIZE (1..maxNrOfTFs)) OF
   SEOUENCE {
      DynamicPartList-ExtIEs} } OPTIONAL,
TransportFormatSet-DynamicPartList-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
TbsTTIInfo ::= SEQUENCE {
   tTIInfo
                     TransportFormatSet-TransmissionTimeIntervalDynamic
                                                                       OPTIONAL,
   tTIInfo
numberOfTbs
                     TransportFormatSet-NrOfTransportBlocks,
   iE-Extensions
                     ProtocolExtensionContainer { { TbsTTIInfo-ExtIEs} },
}
TbsTTIInfo-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
RLC-Size ::= INTEGER (129..5055)
{\tt TransportFormatSet-NrOfTransportBlocks} \ ::= \ {\tt INTEGER} \ (0..512)
TransportFormatSet-Semi-staticPart ::= SEQUENCE {
   transmissionTimeInterval
                                TransportFormatSet-TransmissionTimeIntervalSemiStatic,
   channelCoding
                                TransportFormatSet-ChannelCodingType,
   codingRate
                                TransportFormatSet-CodingRate
                                                                        OPTIONAL.
   -- This IE shall be present if the Type of channel coding IE is set to 'convolutional' or
   rbo'
rateMatchingAttribute
cRC-Size
                                TransportFormatSet-RateMatchingAttribute,
                                TransportFormatSet-CRC-Size,
   iE-Extensions
                                ProtocolExtensionContainer { { TransportFormatSet-Semi-
staticPart-ExtIEs} } OPTIONAL,
}
TransportFormatSet-Semi-staticPart-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
}
TransportFormatSet-TransmissionTimeIntervalSemiStatic ::= ENUMERATED {
   msec-5,
   msec-10,
   msec-20,
   msec-40,
   msec-80,
   dynamic,
}
TransportFormatSet-ChannelCodingType ::= ENUMERATED {
   no-codingTDD,
   convolutional-coding,
   turbo-coding,
   . . .
}
```

```
TransportFormatSet-CodingRate ::= ENUMERATED {
   third,
TransportFormatSet-RateMatchingAttribute ::= INTEGER (1..maxRateMatching)
TransportFormatSet-CRC-Size ::= ENUMERATED {
   v8,
   v12.
   v16,
   v24,
   . . .
}
TransportFormatSet-TransmissionTimeIntervalDynamic ::= ENUMERATED {
   msec-10,
   msec-20,
   msec-40,
   msec-80,
   dynamic,
}
TFCS ::=
             SEQUENCE (SIZE (1..maxTFC)) OF CTFC
CTFC ::=
                               CHOICE {
       ctfc2Bit
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..3),
       ctfc4Bit
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..15),
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..63),
       ctfc6Bit
       ctfc8Bit
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..255),
       ctfc12Bit
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..4095),
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..65535),
       ctfc16Bit
                                          SEQUENCE (SIZE (1..maxTFC)) OF INTEGER (0..16777215),
       ctfc24Bit
       }
C-RNTI ::=
                                  BIT STRING (SIZE (16))
UARFCN ::=
                             INTEGER (0..16383)
CFN ::= INTEGER (0..255)
ChipOffset ::= INTEGER (0..38399)
-- Unit Chip
FrameOffset ::= INTEGER (0..255)
PrimaryScramblingCode ::= INTEGER (0..511)
UschParameters ::= SEQUENCE {
   cellParameterID
                                      CellParameterID,
   tFCI-Coding
                                      TFCI-Coding,
   punctureLimit
                                      PuncturingLimit,
   repetitionPeriod
                                      RepetitionPeriod,
   uSCH-SchedulingOffset
                                      USCH-SchedulingOffset,
   uL-Timeslot-Information
                                      UL-Timeslot-Information,
   tFCS
                                      TFCS,
   trChInfo
                                       TrChInfoList,
   iE-Extensions ProtocolExtensionContainer { { UschParameters-ExtIEs} } ,
}
}
USCH-SchedulingOffset ::= INTEGER (0..255)
MaxPRACH-MidambleShifts ::= ENUMERATED {
   shift4,
```

```
shift8,
        . . .
}
PRACH-Midamble ::= ENUMERATED {
      inverted,
        direct.
}
 __**************
-- Positioning Response Time
 __**************
                                                                                                ENUMERATED { ms250, ms500, s1, s2, s3, s4, s6,
Positioning-ResponseTime ::=
                                                                     s8, s12, s16, s20, s24, s28, s32, s64,
                                                                       . . .
                                                                }
__************
-- Amount of Reporting
AmountOfReporting ::= ENUMERATED { ra2, ra4, ra8, ra16, ra32,
                                                                                 ra64, ra-Infinity, ... }
 __ **********************
-- Include Velocity
__ *******************
                                      ::= ENUMERATED {
IncludeVelocity
      requested
__ ********************
-- VelocityEstimate
__ ***********************************
-- VelocityEstimate is based on Description of Velocity in 23.032
VelocityEstimate ::= CHOICE {
       horizontalVelocity
                                                                                                                HorizontalVelocity,
        horizontalWithVerticalVelocity
                                                                                                                  HorizontalWithVerticalVelocity,
                                                                                                                 HorizontalVelocityWithUncertainty,
        horizontalVelocityWithUncertainty
        horizontal \verb|WithVerticalVelocity| And \verb|Uncertainty| Morizontal \verb|WithVerticalVelocity| And \verb|Uncertainty|, and \verb|Uncertain
}
HorizontalVelocity ::= SEQUENCE {
                                                                              HorizontalSpeedAndBearing,
        horizontalSpeedAndBearing
         iE-Extensions ProtocolExtensionContainer { { HorizontalVelocity-ExtIEs} } OPTIONAL,
HorizontalVelocity-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
HorizontalWithVerticalVelocity ::= SEQUENCE {
       horizontalSpeedAndBearing
                                                                                                                  HorizontalSpeedAndBearing,
        verticalVelocity
                                                                                                                            VerticalVelocity,
                                                  ProtocolExtensionContainer { { HorizontalWithVerticalVelocity-ExtIEs} }
        iE-Extensions
OPTIONAL,
HorizontalWithVerticalVelocity-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
```

```
}
HorizontalVelocityWithUncertainty ::= SEQUENCE {
                                                HorizontalSpeedAndBearing,
   horizontalSpeedAndBearing
   uncertaintySpeed
                                                    INTEGER (0..255),
                    ProtocolExtensionContainer { { HorizontalVelocityWithUncertainty-ExtIEs} }
   iE-Extensions
OPTIONAL,
   . . .
HorizontalVelocityWithUncertainty-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
HorizontalWithVerticalVelocityAndUncertainty ::= SEQUENCE {
   horizontalSpeedAndBearing
                                                HorizontalSpeedAndBearing,
   verticalVelocity
                                                Vertical Velocity,
                                                INTEGER (0..255),
   horizontalUncertaintySpeed
   verticalUncertaintySpeed
                                                    INTEGER (0..255),
                     ProtocolExtensionContainer { { HorizontalWithVerticalVelocityAndUncertainty-
   iE-Extensions
ExtIEs } OPTIONAL,
}
HorizontalWithVerticalVelocityAndUncertainty-ExtlEs PCAP-PROTOCOL-EXTENSION ::= {
}
HorizontalSpeedAndBearing ::= SEQUENCE {
                                                INTEGER (0..359),
   bearing
   horizontalSpeed
                                                INTEGER (0..2047)
}
VerticalVelocity ::= SEQUENCE {
                                                INTEGER (0..255),
   verticalSpeed
   {\tt verticalSpeedDirection}
                                                VerticalSpeedDirection
}
VerticalSpeedDirection ::= ENUMERATED {
   upward,
   downward
}
__*************
-- UTRAN-GPS Reference Time
__*************
UTRAN-GPSReferenceTime ::= SEQUENCE {
                                     INTEGER (0..2322431999999, ...),
   utran-GPSTimingOfCell
   uC-ID
                                     UC-ID
                                                                      OPTIONAL,
   sfn
                                    INTEGER (0..4095),
   iE-Extensions
                                    ProtocolExtensionContainer { { UTRAN-GPSReferenceTime-ExtIEs
} } OPTIONAL,
UTRAN-GPSReferenceTime-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
__*************
-- UTRAN-GPS Reference Time Result
__**************
UTRAN-GPSReferenceTimeResult ::= SEQUENCE {
   ue-GPSTimingOfCell INTEGER (0..37158911999999, ...),
   uC-ID
                             UC-ID,
   sfn
                             INTEGER (0..4095),
```

9.3.5 Common Definitions

```
-- Common definitions
__ ********************
PCAP-CommonDataTypes {
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
umts-Access (20) modules (3) pcap(4) version1 (1) pcap-CommonDataTypes (3) }
DEFINITIONS AUTOMATIC TAGS ::=
BEGIN
__ ********************
__ *********************
maxPrivateIEs
                                     INTEGER ::= 65535
                                     INTEGER ::= 65535
maxProtocolExtensions
maxProtocolIEs
                                     INTEGER ::= 65535
__ *********************************
-- Common Data Types
__ *********************************
Criticality ::= ENUMERATED { reject, ignore, notify }
           ::= ENUMERATED { optional, conditional, mandatory }
Presence
PrivateIE-ID ::= CHOICE {
            INTEGER (0..65535),
  local
                  OBJECT IDENTIFIER
  global
}
ProcedureCode
              ::= INTEGER (0..255)
ProtocolIE-ID
              ::= INTEGER (0..maxProtocolIEs)
              ::= CHOICE {
TransactionID
                 INTEGER (0..127),
   shortTID
                  INTEGER (0..32767)
   longTID
TriggeringMessage ::= ENUMERATED { initiating-message, successful-outcome, unsuccessful-outcome,
outcome }
```

9.3.6 Constant Definitions

```
-- Constant definitions
 __ *********************
 PCAP-Constants {
 itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
 umts-Access (20) modules (3) pcap(4) version1 (1) pcap-Constants (4) }
 DEFINITIONS AUTOMATIC TAGS ::=
 BEGIN
 TMPORTS
        ProcedureCode,
         ProtocolIE-ID
 FROM PCAP-CommonDataTypes;
 __ **********************
 -- Elementary Procedures
 __ *********************
id-PositionCalculation ProcedureCode ::= 1
id-InformationExchangeInitiation id-InformationExchangeTermination ProcedureCode ::= 3
id-InformationExchangeTermination ProcedureCode ::= 4
id-InformationExchangeFailure ProcedureCode ::= 5
id-ErrorIndication ProcedureCode ::= 6
id-privateMessage ProcedureCode ::= 6
 id-PositionParameterModification ProcedureCode ::= 8
__ *********************
 -- Lists
 __ *******************
maxNrOfErrors
                                                                                  INTEGER ::= 256
                                                                                    INTEGER ::= 16
maxSat
                                                                                   INTEGER ::= 32
maxSatAlmanac
                                                                                  INTEGER ::= 256
 maxNrOfLevels
                                                                                   INTEGER ::= 15
maxNrOfPoints
                                                                                  INTEGER ::= 32
maxNrOfExpInfo
                                                                                  INTEGER ::= 32
INTEGER ::= 16
maxNrOfMeasNCell
maxNrOfMeasurements
 maxNrOfSets
                                                                                 INTEGER ::= 3
                                                                                 INTEGER ::= 256
INTEGER ::= 32
maxRateMatching
maxNrOfTFs
                                                                                  INTEGER ::= 4
maxTTI-count
 maxTS-1
                                                                                   INTEGER ::= 13
                                                                                  INTEGER ::= 8
maxCCTrCH
                                                                                    INTEGER ::= 32
maxTF
                                                                                   INTEGER ::= 1024
maxTFC
 maxPRACH
                                                                                   INTEGER ::= 16
                                                                                    INTEGER ::= 32
 maxTrCH
                                                                                   INTEGER ::= 6
maxTGPS
                                                                                  INTEGER ::= 16
INTEGER ::= 32
 maxNoOfMeasurements
maxNrOfRefETFCIs

INTEGER ::= 32

INTEGER ::= 8 -- FFS

mixed integer ::= 8 -- FFS

mixed integer inte
 maxCellMeas
                                                                                  INTEGER ::= 8
                                                                                   INTEGER ::= 9
maxSet
 maxGANSSSat
                                                                                    INTEGER ::= 32
                                                                                   INTEGER ::= 4
 maxSgnType
 maxGANSS
                                                                                    INTEGER ::= 8
                                                                                    INTEGER ::= 32
 maxGANSSSet.
```

```
__ *********************
__
-- IEs
__ **********************
id-Cause
                                              ProtocolIE-ID ::= 1
id-CriticalityDiagnostics
                                              ProtocolIE-ID ::= 2
id-GPS-UTRAN-TRU
                                             ProtocolIE-ID ::= 3
id-InformationExchangeID
                                             ProtocolIE-ID ::= 4
                                             ProtocolIE-ID ::= 9
id-InformationType
id-GPS-MeasuredResultsList
                                             ProtocolIE-ID ::= 10
id-MethodType
                                            ProtocolIE-ID ::= 11
                                             ProtocolIE-ID ::= 12
id-RefPosition-InfEx-Rgst
                                            ProtocolIE-ID ::= 13
id-RefPosition-InfEx-Rsp
                                            ProtocolIE-ID ::= 14
id-RefPosition-Inf-Rprt
id-RequestedDataValue
                                             ProtocolIE-ID ::= 15
id-RequestedDataValueInformation
                                            ProtocolIE-ID ::= 16
                                             ProtocolIE-ID ::= 17
ProtocolIE-ID ::= 18
id-TransactionID
id-UE-PositionEstimate
id-CellId-MeasuredResultsSets
                                            ProtocolIE-ID ::= 20
id-OTDOA-MeasurementGroup
                                             ProtocolIE-ID ::= 22
                                            ProtocolIE-ID ::= 23
id-AccuracyFulfilmentIndicator
                                             ProtocolIE-ID ::= 24
id-HorizontalAccuracyCode
id-VerticalAccuracyCode
                                             ProtocolIE-ID ::= 25
                                             ProtocolIE-ID ::= 26
id-UTDOA-Group
id-RequestType
                                              ProtocolIE-ID ::= 28
id-UE-PositioningCapability
                                             ProtocolIE-ID ::= 29
                                             ProtocolIE-ID ::= 30
id-UC-id
id-ResponseTime
                                              ProtocolIE-ID ::= 31
id-PositioningPriority
                                             ProtocolIE-ID ::= 32
id-ClientType
                                             ProtocolIE-ID ::= 33
                                             ProtocolIE-ID ::= 34
id-PositioningMethod
id-UTDOAPositioning
                                             ProtocolIE-ID ::= 35
id-GPSPositioning
                                              ProtocolIE-ID ::= 36
                                             ProtocolIE-ID ::= 37
id-OTDOAAssistanceData
                                             ProtocolIE-ID ::= 38
id-Positioning-ResponseTime
id-EnvironmentCharacterisation
                                             ProtocolIE-ID ::= 39
id-PositionData
                                             ProtocolIE-ID ::= 40
id-IncludeVelocity
                                              ProtocolIE-ID ::= 41
                                             ProtocolIE-ID ::= 42
id-VelocityEstimate
                                             ProtocolIE-ID ::= 43
id-rxTimingDeviation768Info
id-UC-ID-InfEx-Rqst
                                             ProtocolIE-ID ::= 44
id-UE-PositionEstimateInfo
                                            ProtocolIE-ID ::= 45
id-UTRAN-GPSReferenceTime
                                             ProtocolIE-ID ::= 46
                                             ProtocolIE-ID ::= 47
id-UTRAN-GPSReferenceTimeResult
id-UTRAN-GPS-DriftRate
                                            ProtocolIE-ID ::= 48
id-OTDOA-AddMeasuredResultsInfo
                                             ProtocolIE-ID ::= 49
id-GPS-ReferenceLocation
                                            ProtocolIE-ID ::= 50
                                            ProtocolIE-ID ::= 51
id-OTDOA-MeasuredResultsSets
id-rxTimingDeviation384extInfo
                                             ProtocolIE-ID ::= 55
id-ExtendedRoundTripTime
                                            ProtocolIE-ID ::= 56
id-PeriodicPosCalcInfo
                                              ProtocolIE-ID ::= 57
                                             ProtocolIE-ID ::= 58
id-PeriodicLocationInfo
                                             ProtocolIE-ID ::= 59
id-AmountOfReporting
id-MeasInstructionsUsed
                                             ProtocolIE-ID ::= 60
                                             ProtocolIE-ID ::= 61
id-RRCstateChange
                                             ProtocolIE-ID ::= 62
id-PeriodicTerminationCause
                                             ProtocolIE-ID ::= 63
id-MeasurementValidity
id-roundTripTimeInfoWithType1
                                             ProtocolIE-ID ::= 64
                                              ProtocolIE-ID ::= 66
id-CellIDPositioning
                                             ProtocolIE-ID ::= 67
id-AddMeasurementInfo
                                             ProtocolIE-ID ::= 68
id-Extended-RNC-ID
                                             ProtocolIE-ID ::= 69
id-GANSS-CommonAssistanceData
                                            ProtocolIE-ID ::= 70
id-GANSS-GenericAssistanceDataList
id-GANSS-MeasuredResultsList
                                             ProtocolIE-ID ::= 71
                                            ProtocolIE-ID ::= 72
id-GANSS-UTRAN-TRU
                                            ProtocolIE-ID ::= 73
ProtocolIE-ID ::= 74
id-GANSSPositioning
id-GANSS-PositioningDataSet
id-GNSS-PositioningMethod
id-NetworkAssistedGANSSSuport
                                            ProtocolIE-ID ::= 75
id-TUTRANGANSSMeasurementValueInfo
                                             ProtocolIE-ID ::= 76
                                             ProtocolIE-ID ::= 77
```

END

9.3.7 Container Definitions

```
-- Container definitions
PCAP-Containers
itu-t (0) identified-organization (4) etsi (0) mobileDomain (0)
umts-Access (20) modules (3) pcap(4) version1 (1) pcap-Containers (5) }
DEFINITIONS AUTOMATIC TAGS ::=
__ *********************************
-- IE parameter types from other modules.
__ *********************
IMPORTS
  Criticality,
  Presence.
  PrivateIE-ID.
  ProtocolIE-ID,
  maxPrivateIEs,
  maxProtocolExtensions,
  maxProtocolIEs
FROM PCAP-CommonDataTypes;
__ ********************
-- Class Definition for Protocol IEs
__ *********************
PCAP-PROTOCOL-IES ::= CLASS {
  &id ProtocolIE-ID UNIQUE, &criticality Criticality,
  &id
  &Value,
  &presence
                 Presence
WITH SYNTAX {
  ID
                  &id
   CRITICALITY
                  &criticality
  TYPE
                  &Value
   PRESENCE
                  &presence
}
__ **********************************
-- Class Definition for Protocol Extensions
__ ******************************
PCAP-PROTOCOL-EXTENSION ::= CLASS {
             ProtocolIE-ID UNIQUE,
Criticality,
   &criticality
   &Extension,
                 Presence
   &presence
WITH SYNTAX {
                 &id
  CRITICALITY &criticality
EXTENSION &Extension
  PRESENCE
                  &presence
}
__ **********************
```

```
-- Class Definition for Private IEs
PCAP-PRIVATE-IES ::= CLASS {
   &id PrivateIE-ID, &criticality Criticality, &Value
   &Value,
   &presence
                   Presence
WITH SYNTAX {
   ID
                   &id
   CRITICALITY &criticality
TYPE &Value
   PRESENCE
                    &presence
}
__ *********************
-- Container for Protocol IEs
__ *********************
ProtocolIE-Container {PCAP-PROTOCOL-IES : IEsSetParam} ::=
   SEQUENCE (SIZE (0..maxProtocolIEs)) OF
      ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-Single-Container {PCAP-PROTOCOL-IES : IEsSetParam} ::=
   ProtocolIE-Field {{IEsSetParam}}
ProtocolIE-Field {PCAP-PROTOCOL-IES : IEsSetParam} ::= SEQUENCE {
   id PCAP-PROTOCOL-IES.&id ({IESSetParam}), criticality PCAP-PROTOCOL-IES.&criticality ({IESSetParam}{@id}),
                   PCAP-PROTOCOL-IES.&Value
   value
                                                   ({IEsSetParam}{@id})
__ *******************
-- Container Lists for Protocol IE Containers
__ **********************
ProtocolIE-ContainerList {INTEGER : lowerBound, INTEGER : upperBound, PCAP-PROTOCOL-IES :
IEsSetParam} ::=
  SEQUENCE (SIZE (lowerBound..upperBound)) OF
      ProtocolIE-Container {{IEsSetParam}}
-- Container for Protocol Extensions
__ **********************
ProtocolExtensionContainer {PCAP-PROTOCOL-EXTENSION : ExtensionSetParam} ::=
   {\tt SEQUENCE~(SIZE~(1..maxProtocolExtensions))~OF}
      ProtocolExtensionField {{ExtensionSetParam}}
ProtocolExtensionField {PCAP-PROTOCOL-EXTENSION : ExtensionSetParam} ::= SEQUENCE {
   }
__ *********************************
-- Container for Private IEs
__ *********************************
PrivateIE-Container {PCAP-PRIVATE-IES : IEsSetParam } ::=
   SEQUENCE (SIZE (1.. maxPrivateIEs)) OF
      PrivateIE-Field {{IEsSetParam}}
PrivateIE-Field {PCAP-PRIVATE-IES : IEsSetParam} ::= SEQUENCE {
   id PCAP-PRIVATE-IES.&id
criticality PCAP-PRIVATE-IES.&criticality
value PCAP-PRIVATE-IES.&Value
                                           ({IEsSetParam}),
                                                 ({IEsSetParam}{@id}),
({IEsSetParam}{@id})
```

} END

9.4 Message Transfer Syntax

PCAP shall use the ASN.1 Basic Packed Encoding Rules (BASIC-PER) Aligned Variant as transfer syntax, as specified in [9].

Handling of Unknown, Unforeseen and Erroneous Protocol Data

10.1 General

Protocol Error cases can be divided into three classes:

- Transfer Syntax Error.
- Abstract Syntax Error.
- Logical Error.

Protocol errors can occur in the following functions within a receiving node.




Figure 10: Protocol Errors in PCAP

The information stated in subclauses 10.2, 10.3 and 10.4, to be included in the message used when reporting an error, is what at minimum shall be included. Other optional information elements within the message may also be included, if available. This is also valid for the case when the reporting is done with a response message. The latter is an exception to what is stated in subclause 4.1.

10.2 Transfer Syntax Error

A Transfer Syntax Error occurs when the receiver is not able to decode the received physical message. Transfer syntax errors are always detected in the process of ASN.1 decoding. If a Transfer Syntax Error occurs, the receiver should initiate Error Indication procedure with appropriate cause value for the Transfer Syntax protocol error.

Examples for Transfer Syntax Errors are:

- Violation of value ranges in ASN.1 definition of messages. e.g.: If an IE has a defined value range of 0 to 10 (ASN.1: INTEGER (0..10)), and 12 will be received, then this will be treated as a transfer syntax error.
- Violation in list element constraints. e.g.: If a list is defined as containing 1 to 10 elements, and 12 elements will be received, than this case will be handled as a transfer syntax error.
- Missing mandatory elements in ASN.1 SEQUENCE definitions (as sent by the originator of the message).
- Wrong order of elements in ASN.1 SEQUENCE definitions (as sent by the originator of the message).

10.3 Abstract Syntax Error

10.3.1 General

An Abstract Syntax Error occurs when the receiving functional PCAP entity:

- 1) receives IEs or IE groups that cannot be understood (unknown IE id);
- 2) receives IEs for which the logical range is violated (e.g.: ASN.1 definition: 0 to 15, the logical range is 0 to 10 (values 11 to 15 are undefined), and 12 will be received; this case will be handled as an abstract syntax error using criticality information sent by the originator of the message);
- 3) does not receive IEs or IE groups but according to the specified presence of the concerning object, the IEs or IE groups should have been present in the received message;
- 4) receives IEs or IE groups that are defined to be part of that message in wrong order or with too many occurrences of the same IE or IE group;
- 5) receives IEs or IE groups but according to the conditional presence of the concerning object and the specified condition, the IEs or IE groups should not have been present in the received message.

Cases 1 and 2 (not comprehended IE/IE group) are handled based on received Criticality information. Case 3 (missing IE/IE group) is handled based on Criticality information and Presence information for the missing IE/IE group specified in the version of the specification used by the receiver. Case 4 (IEs or IE groups in wrong order or with too many occurrences) and Case 5 (erroneously present conditional IEs or IE groups) result in rejecting the procedure.

If an Abstract Syntax Error occurs, the receiver shall read the remaining message and shall then for each detected Abstract Syntax Error that belong to cases 1-3 act according to the Criticality Information and Presence Information for the IE/IE group due to which Abstract Syntax Error occurred in accordance with subclauses 10.3.4 and 10.3.5. The handling of cases 4 and 5 is specified in subclause 10.3.6.

10.3.2 Criticality Information

In the PCAP messages there is criticality information set for individual IEs and/or IE groups. This criticality information instructs the receiver how to act when receiving an IE or an IE group that is not comprehended, i.e. the entire item (IE or IE group) which is not (fully or partially) comprehended shall be treated in accordance with its own criticality information as specified in subclause 10.3.4.

In addition, the criticality information is used in case of the missing IE/IE group abstract syntax error (see subclause 10.3.5).

The receiving node shall take different actions depending on the value of the Criticality Information. The three possible values of the Criticality Information for an IE/IE group are:

- Reject IE.
- Ignore IE and Notify Sender.
- Ignore IE.

The following rules restrict when a receiving entity may consider an IE, an IE group, or an EP not comprehended (not implemented), and when action based on criticality information is applicable:

- 1. IE or IE group: When one new or modified IE or IE group is implemented for one EP from a standard version, then other new or modified IEs or IE groups specified for that EP in that standard version shall be considered comprehended by a receiving entity (some may still remain unsupported).
- 2. EP: The comprehension of different EPs within a standard version or between different standard versions is not mandated. Any EP that is not supported may be considered not comprehended, even if another EP from that standard version is comprehended, and action based on criticality shall be applied.

10.3.3 Presence Information

For many IEs/IE groups which are optional according to the ASN.1 transfer syntax, PCAP specifies separately if the presence of these IEs/IE groups is optional or mandatory with respect to RNS application by means of the presence field of the concerning object of class PCAP-PROTOCOL-IES, PCAP -PROTOCOL-IES-PAIR, PCAP -PROTOCOL-EXTENSION or PCAP -PRIVATE-IES.

The presence field of the indicated classes supports three values:

- 1. Optional;
- 2. Conditional;
- Mandatory.

If an IE/IE group is not included in a received message and the presence of the IE/IE group is mandatory or the presence is conditional and the condition is true according to the version of the specification used by the receiver, an abstract syntax error occurs due to a missing IE/IE group.

If an IE/IE group is included in a received message and the presence of the IE/IE group is conditional and the condition is false according to the version of the specification used by the receiver, an abstract syntax error occurs due to this erroneously present conditional IE/IE group.

10.3.4 Not comprehended IE/IE group

10.3.4.1 Procedure Code

The receiving node shall treat the different types of received criticality information of the *Procedure Code* IE according to the following:

Reject IE:

- If a message is received with a *Procedure Code* IE marked with "*Reject IE*" which the receiving node does not comprehend, the receiving node shall reject the procedure using the Error Indication procedure.

Ignore IE and Notify Sender:

- If a message is received with a *Procedure Code* IE marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the procedure and initiate the Error Indication procedure.

Ignore IE:

- If a message is received with a *Procedure Code* IE marked with "*Ignore IE*" which the receiving node does not comprehend, the receiving node shall ignore the procedure.

When using the Error Indication procedure to reject a procedure or to report an ignored procedure it shall include the *Procedure Code* IE, the *Triggering Message* IE, and the *Procedure Criticality* IE in the *Criticality Diagnostics* IE.

10.3.4.1A Type of Message

When the receiving node cannot decode the *Type of Message* IE, the Error Indication procedure shall be initiated with an appropriate cause value.

10.3.4.2 IEs other than the Procedure Code and Type of Message

The receiving node shall treat the different types of received criticality information of an IE/IE group other than the *Procedure Code* IE and *Type of Message* IE according to the following:

Reject IE:

If a message *initiating* a procedure is received containing one or more IEs/IE groups marked with "*Reject IE*" which the receiving node does not comprehend; none of the functional requests of the message shall be executed.

The receiving node shall reject the procedure and report the rejection of one or more IEs/IE groups using the message normally used to report unsuccessful outcome of the procedure. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.

- If a message *initiating* a procedure that does not have a message to report unsuccessful outcome is received containing one or more IEs/IE groups marked with "*Reject IE*" which the receiving node does not comprehend, the receiving node shall terminate the procedure and initiate the Error Indication procedure.
- If a *response* message is received containing one or more IEs/IE groups marked with "*Reject IE*", that the receiving node does not comprehend, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

Ignore IE and Notify Sender:

- If a message *initiating* a procedure is received containing one or more IEs/IE groups marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups, and report in the response message of the procedure that one or more IEs/IE groups have been ignored. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the response message, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- If a message *initiating* a procedure that does not have a message to report the outcome of the procedure is received containing one or more IEs/IE groups marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups, and initiate the Error Indication procedure to report that one or more IEs/IE groups have been ignored.
- If a *response* message is received containing one or more IEs/IE groups marked with "*Ignore IE and Notify Sender*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups, continue with the procedure as if the not comprehended IEs/IE groups were not received (except for the reporting) using the understood IEs/IE groups and initiate the Error Indication procedure.

Ignore IE:

- If a message *initiating* a procedure is received containing one or more IEs/IE groups marked with "*Ignore IE*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups and continue with the procedure as if the not comprehended IEs/IE groups were not received using the understood IEs/IE groups.
- If a *response* message is received containing one or more IEs/IE groups marked with "*Ignore IE*" which the receiving node does not comprehend, the receiving node shall ignore the content of the not comprehended IEs/IE groups.

When reporting not comprehended IEs/IE groups marked with "Reject IE" or "Ignore IE and Notify Sender" using a response message defined for the procedure, the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group. The Repetition Number IE shall be included in the Information Element Criticality Diagnostics IE if the reported IE/IE group was part of a "SEQUENCE OF" definition.

When reporting not comprehended IEs/IE groups marked with "Reject IE" or "Ignore IE and Notify Sender" using the Error Indication procedure, the Procedure Code IE, the Triggering Message IE, Procedure Criticality IE, the Transaction Id IE, and the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group. The Repetition Number IE shall be included in the Information Element Criticality Diagnostics IE if the reported IE/IE group was part of a "SEQUENCE OF" definition.

10.3.5 Missing IE or IE group

The receiving node shall treat the missing IE/IE group according to the criticality information for the missing IE/IE group in the received message specified in the version of the present document used by the receiver:

Reject IE:

- If a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "Reject IE"; none of the functional requests of the message shall be executed. The receiving node shall reject the procedure and report the missing IEs/IE groups using the message normally used to report unsuccessful outcome of the procedure. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- If a received message *initiating* a procedure that does not have a message to report unsuccessful outcome is missing one or more IEs/IE groups with specified criticality "*Reject IE*", the receiving node shall initiate the Error Indication procedure.
- If a received *response* message is missing one or more IEs/IE groups with specified criticality "*Reject IE*, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

Ignore IE and Notify Sender:

- If a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "Ignore IE and Notify Sender", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and report in the response message of the procedure that one or more IEs/IE groups were missing. In case the information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the response message, the receiving node shall instead terminate the procedure and initiate the Error Indication procedure.
- If a received message *initiating* a procedure that does not have a message to report the outcome of the procedure is missing one or more IEs/IE groups with specified criticality "*Ignore IE and Notify Sender*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and initiate the Error Indication procedure to report that one or more IEs/IE groups were missing.
- If a received *response* message is missing one or more IEs/IE groups with specified criticality "*Ignore IE and Notify Sender*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message and initiate the Error Indication procedure to report that one or more IEs/IE groups were missing.

Ignore IE:

- If a received message *initiating* a procedure is missing one or more IEs/IE groups with specified criticality "*Ignore IE*", the receiving node shall ignore that those IEs are missing and continue with the procedure based on the other IEs/IE groups present in the message.
- If a received *response* message is missing one or more IEs/IE groups with specified criticality "*Ignore IE*", the receiving node shall ignore that those IEs/IE groups are missing.

When reporting missing IEs/IE groups with specified criticality "Reject IE" or "Ignore IE and Notify Sender" using a response message defined for the procedure, the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

When reporting missing IEs/IE groups with specified criticality "Reject IE" or "Ignore IE and Notify Sender" using the Error Indication procedure, the Procedure Code IE, the Triggering Message IE, Procedure Criticality IE, the Transaction Id IE, and the Information Element Criticality Diagnostics IE shall be included in the Criticality Diagnostics IE for each reported IE/IE group.

10.3.6 IEs or IE groups received in wrong order or with too many occurrences or erroneously present

If a message with IEs or IE groups in wrong order or with too many occurrences is received or if IEs or IE groups with a conditional presence are present when the condition is not met (i.e. erroneously present), the receiving node shall behave according to the following:

- If a message *initiating* a procedure is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, none of the functional requests of the message shall be executed. The receiving node shall reject the procedure and report the cause value "Abstract Syntax Error (Falsely Constructed Message)" using the message normally used to report unsuccessful outcome of the procedure. In case the

information received in the initiating message was insufficient to determine a value for all IEs that are required to be present in the message used to report the unsuccessful outcome of the procedure, the receiving node shall instead terminate the procedure and initiate the Error Indication.

- If a message *initiating* a procedure that does not have a message to report unsuccessful outcome is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, the receiving node shall terminate the procedure and initiate the Error Indication procedure, and use cause value "Abstract Syntax Error (Falsely Constructed Message)".
- If a *response* message is received containing IEs or IE groups in wrong order or with too many occurrences or erroneously present, the receiving node shall consider the procedure as unsuccessfully terminated and initiate local error handling.

10.4 Logical Error

Logical error situations occur when a message is comprehended correctly, but the information contained within the message is not valid (i.e. semantic error), or describes a procedure which is not compatible with the state of the receiver. In these conditions, the following behaviour shall be performed (unless otherwise specified) as defined by the class of the elementary procedure, irrespective of the criticality of the IEs/IE groups containing the erroneous values.

Class 1:

Protocol Causes:

Where the logical error occurs in a request message of a class 1 procedure, and the procedure has a message to report this unsuccessful outcome, this message shall be sent with an appropriate cause value. Typical cause values are:

- 1. Semantic Error.
- 2. Message not compatible with receiver state.

Where the logical error is contained in a request message of a class 1 procedure, and the procedure does not have a message to report this unsuccessful outcome, the procedure shall be terminated and the Error Indication procedure shall be initiated with an appropriate cause value.

Where the logical error exists in a response message of a class 1 procedure, the procedure shall be considered as unsuccessfully terminated and local error handling shall be initiated.

Class 2:

Where the logical error occurs in a message of a class 2 procedure, the procedure shall be terminated and the Error Indication procedure shall be initiated with an appropriate cause value.

10.5 Exceptions

The error handling for all the cases described hereafter shall take precedence over any other error handling described in the other subclauses of clause 10.

- If any type of error (Transfer Syntax Error, Abstract Syntax Error or Logical Error) is detected in the ERROR INDICATION message, it shall not trigger the Error Indication procedure in the receiving Node but local error handling.
- In case a response message or Error Indication message needs to be returned, but the information necessary to determine the receiver of that message is missing, the procedure shall be considered as unsuccessfully terminated and local error handling shall be initiated.
- If an error that terminates a procedure occurs, the returned cause value shall reflect the error that caused the termination of the procedure even if one or more abstract syntax errors with criticality "ignore and notify" have earlier occurred within the same procedure.

Annex A (informative): Guidelines for Usage of the Criticality Diagnostics IE

A.1 EXAMPLE MESSAGE Layout

Assume the following message format:

Table A.1

IE/Group Name	Presence	Range	IE type and reference	Semantics description	Criticality	Assigned Criticality
Message Type	M				YES	Reject
Transaction ID	M				_	
Α	M				YES	reject
В	M				YES	reject
>E		1 <maxe></maxe>			EACH	ignore
>>F		1 <maxf></maxf>			-	
>>>G		03,			EACH	ignore
>>H		1 <maxh></maxh>			EACH	ignore
>>>G		03,			EACH	ignore and notify
>>G	M				YES	reject
>>J		1 <maxj></maxj>			-	
>>>G		03,			EACH	reject
С	M				YES	reject
>K		1 <maxk></maxk>			EACH	ignore and notify
>>L		1 <maxl></maxl>			-	
>>>M	0				-	
D	M				YES	reject

NOTE: The IEs F, J, and L do not have assigned criticality. The IEs F, J, and L are consequently realised as the ASN.1 type SEQUENCE OF of "ordinary" ASN.1 type, e.g. INTEGER. On the other hand, the repeatable IEs with assigned criticality are realised as the ASN.1 type SEQUENCE OF of an IE object, e.g. ProtocolIE-Single-Container.

For the corresponding ASN.1 layout, see clause A.4.

A.2 Example on a Received EXAMPLE MESSAGE

Assume further more that a received message based on the above tabular format is according to figure A₂1.





Figure A.1: Example of content of a received PCAP message based on the EXAMPLE MESSAGE

A.3 Content of Criticality Diagnostics

A.3.1 Example 1



- a) IE ID IE
- b) Repetition Number IE

Figure A.2: Example of a received PCAP message containing a not comprehended IE

If there is an error within the instance marked as grey in the IE G in the IE J shown in the figure A.2, this will be reported within the *Information Element Criticality Diagnostics* IE within the *Criticality Diagnostics* IEas in table A.2.


Table A.2

IE name	Value	Comment		
IE Criticality	Reject	Criticality for IE on the reported level, i.e. level 4.		
IE ID	id-G	IE ID from the reported level, i.e. level 4.		
Repetition	11	Repetition number on the reported level, i.e. level 4.		
Number		(Since the IE E (level 2) is the lowest level included in the Message Structure		
		IE this is the eleventh occurrence of IE G within the IE E (level 2).		
Type of Error	not			
	underst			
	ood			
Message Structur	e, first repe	etition		
>IE ID	id-B	IE ID from level 1.		
Message Structure, second repetition				
>IE ID	id-E	IE ID from the lowest level above the reported level, i.e. level 2.		
>Repetition	3	Repetition number from the lowest level above the reported level, i.e. level 2.		
Number				

NOTE 1: The IE J on level 3 cannot be included in the *Message Structure* IE since they have no criticality of their own.

NOTE 2: The repetition number of the reported IE indicates the number of repetitions of IE G received up to the detected erroneous repetition, counting all occurrences of the IE G below the same instance of the previous level with assigned criticality (instance 3 of IE E on level 2).

A.3.2 Example 2



- a) IE ID IE
- b) Repetition Number IE

Figure A.3: Example of a received PCAP message containing a not comprehended IE


If there is an error within the second instance (marked as grey) in the sequence (IE L in the tabular format) on level 3 below IE K in the structure shown in the figure A.3, this will be reported within the *Information Element Criticality Diagnostics* IE within the *Criticality Diagnostics* IEas in table A.3.

Table A.3

IE name	Value	Comment		
IE Criticality	ignore	Criticality for IE on the reported level, i.e. level 2.		
	and			
	notify			
IE ID	id-K	IE ID from the reported level, i.e. level 2.		
Repetition	3	Repetition number on the reported level, i.e. level 2.		
Number				
Type of Error	not			
	underst			
	ood			
Message Structur	Message Structure, first repetition			
>IE ID	id-C	IE ID from the lowest level above the reported level, i.e. level 1.		

NOTE: The IE L on level 3 cannot be reported individually included in the *Message Structure* IE since it has no criticality of its own.

A.3.3 Example 3



Included in the Information Element Criticality Diagnostics IE:

- a) IE ID IE
- b) Repetition Number IE

Figure A.4: Example of a received PCAP message containing a not comprehended IE


If there is an error within the instance marked as grey in the IE G in the IE H shown in the figure A.4, this will be reported within the *Information Element Criticality Diagnostics* IE within the *Criticality Diagnostics* IEas in table A.4.

Table A.4

IE name	Value	Comment
IE Criticality	ignore and notify	Criticality for IE on the reported level, i.e. level 4.
IE ID	id-G	IE ID from the reported level, i.e. level 4.
Repetition Number	2	Repetition number on the reported level, i.e. level 4.
Type of Error	not underst ood	
Message Structur	e, first repe	etition
>IE ID	id-B	IE ID from level 1.
Message Structur	e, second	repetition
>IE ID	id-E	IE ID from level 2.
>Repetition Number	3	Repetition number from level 2.
Message Structure, third repetition		
>IE ID	id-H	IE ID from the lowest level above the reported level, i.e. level 3.
>Repetition Number	1	Repetition number from the lowest level above the reported level, i.e. level 3.

NOTE: The repetition number of level 4 indicates the number of repetitions of IE G received up to the detected erroneous repetition, counted below the same instance of the previous level with assigned criticality (instance 1 of IE H on level 3).

A.3.4 Example 4



Included in the Information Element Criticality Diagnostics IE:

- a) IE ID IE
- b) Repetition Number IE

Figure A.5: Example of a received PCAP message containing a not comprehended IE


If there is an error within the instance marked as grey in the IE G in the IE E shown in the figure A.5, this will be reported within the *Information Element Criticality Diagnostics* IE within the *Criticality Diagnostics* IE, as in table A.5.

Table A.5

IE name	Value	Comment		
IE Criticality	Reject	Criticality for IE on the reported level, i.e. level 3.		
IE ID	id-G	IE ID from the reported level, i.e. level 3.		
Repetition	5	Repetition number on the reported level, i.e. level 3.		
Number		(Since the IE E (level 2) is the lowest level included in the Message Structure		
		IE this is the fifth occurrence of IE G within the IE E (level 2).		
Type of Error	not			
	underst			
	ood			
Message Structu	re, first rep	etition		
>IE ID	id-B	IE ID from level 1.		
Message Structure, second repetition				
>IE ID	id-E	IE ID from the lowest level above the reported level, i.e. level 2.		
>Repetition Number	3	Repetition number from the lowest level above the reported level, i.e. level 2.		

NOTE: The repetition number of the reported IE indicates the number of repetitions of IE G received up to the detected erroneous repetition, counting all occurrences of the IE G below the same instance of the previous level with assigned criticality (instance 3 of IE E on level 2).

A.3.5 Example 5



Included in the Information Element Criticality Diagnostics IE:

- a) IE ID IE
- b) Repetition Number IE

Figure A.6: Example of a received PCAP message with a missing IE

If the instance marked as grey in the IE G in the IE E shown in the figure A.6, is missing this will be reported within the *Information Element Criticality Diagnostics* IE within the *Criticality Diagnostics* IE, as in table A.6.

Table A.6

IE name	Value	Comment		
IE Criticality	reject	Criticality for IE on the reported level, i.e. level 3.		
IE ID	id-G	IE ID from the reported level, i.e. level 3.		
Repetition Number	4	Repetition number up to the missing IE on the reported level, i.e. level 3. (Since the IE E (level 2) is the lowest level included in the <i>Message Structure</i> IE there have been four occurrences of IE G within the IE E (level 2) up to the missing occurrence.		
Type of Error	missing			
Message Structur	e, first repe	etition		
>IE ID	id-B	IE ID from level 1.		
Message Structur	Message Structure, second repetition			
>IE ID	id-E	IE ID from the lowest level above the reported level, i.e. level 2.		
>Repetition Number	3	Repetition number from the lowest level above the reported level, i.e. level 2.		

NOTE: The repetition number of the reported IE indicates the number of repetitions of IE G received up to but not including the missing occurrence, counting all occurrences of the IE G below the same instance of the previous level with assigned criticality (instance 3 of IE E on level 2).

A.4 ASN.1 of EXAMPLE MESSAGE

```
ExampleMessage ::= SEQUENCE {
                        ProtocolIE-Container
                                                     {{ExampleMessage-IEs}},
    ProtocolIEs
    ProtocolExtensions ProtocolExtensionContainer {{ExampleMessage-Extensions}}
                                                                                    OPTIONAL.
}
ExampleMessage-IEs PCAP-PROTOCOL-IES ::= {
    { ID id-A CRITICALITY reject TYPE A PRESENCE mandatory} { ID id-B CRITICALITY reject TYPE B PRESENCE mandatory}
    { ID id-C CRITICALITY reject TYPE C PRESENCE mandatory} | 
{ ID id-D CRITICALITY reject TYPE D PRESENCE mandatory} ,
B ::= SEQUENCE {
                   E-List,
    iE-Extensions ProtocolExtensionContainer { {B-ExtIEs} } OPTIONAL,
}
B-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
E-List ::= SEQUENCE (SIZE (1..maxE)) OF ProtocolIE-Single-Container { {E-IEs} }
E-IES PCAP-PROTOCOL-IES ::= {
    { ID id-E CRITICALITY ignore TYPE E PRESENCE mandatory }
E ::= SEQUENCE {
                    F-List,
   h
                    H-List.
                    G-List1
    g
                    J-List,
    iE-Extensions ProtocolExtensionContainer { {E-ExtIEs} } OPTIONAL,
}
E-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
F-List ::= SEQUENCE (SIZE (1..maxF)) OF F
F ::= SEQUENCE {
                    G-List2 OPTIONAL,
    iE-Extensions ProtocolExtensionContainer { {F-ExtIEs} } OPTIONAL,
F-ExtIEs
         PCAP-PROTOCOL-EXTENSION ::= {
G-List2 ::= SEQUENCE (SIZE (1..3, ...)) OF ProtocolIE-Single-Container { {G2-IEs} }
G2-IES PCAP-PROTOCOL-IES ::= {
    H-List ::= SEQUENCE (SIZE (1..maxH)) OF ProtocolIE-Single-Container { {H-IEs} }
H-IES PCAP-PROTOCOL-IES ::= {
    { ID id-H CRITICALITY ignore TYPE H PRESENCE mandatory }
H ::= SEQUENCE {
                    G-List3 OPTIONAL,
                                    ProtocolExtensionContainer { {H-ExtIEs} } OPTIONAL,
    iE-Extensions
}
H-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
   . . .
```

```
}
G-List3 ::= SEQUENCE (SIZE (1..3, ...)) OF ProtocolIE-Single-Container { {G3-IEs} }
G3-IES PCAP-PROTOCOL-IES ::= {
  { ID id-G CRITICALITY notify TYPE G PRESENCE mandatory }
G-List1 ::= ProtocolIE-Single-Container { G1-IEs} }
G1-IES PCAP-PROTOCOL-IES ::= {
   { ID id-G CRITICALITY reject TYPE G PRESENCE mandatory }
J-List ::= SEQUENCE (SIZE (1..maxJ)) OF J
J ::= SEQUENCE {
                    G-List4 OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { {J-ExtIEs} } OPTIONAL,
}
J-ExtIES PCAP-PROTOCOL-EXTENSION ::= {
 \texttt{G-List4} ::= \texttt{SEQUENCE} \ (\texttt{SIZE} \ (1...3, \ \ldots)) \ \texttt{OF} \ \texttt{ProtocolIE-Single-Container} \ \left\{ \ \texttt{G4-IEs} \ \right\} \ 
G4-IES PCAP-PROTOCOL-IES ::= {
   { ID id-G CRITICALITY reject TYPE G PRESENCE mandatory }
C ::= SEQUENCE {
                    K-List.
    iE-Extensions ProtocolExtensionContainer { {C-ExtIEs} } OPTIONAL,
}
C-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
K-List ::= SEQUENCE (SIZE (1..maxK)) OF ProtocolIE-Single-Container { {K-IEs} }
K-IES PCAP-PROTOCOL-IES ::= {
   { ID id-K CRITICALITY notify TYPE K PRESENCE mandatory }
K ::= SEQUENCE {
                    L-List,
    iE-Extensions ProtocolExtensionContainer { {K-ExtIEs} } OPTIONAL,
K-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
L-List ::= SEQUENCE (SIZE (1..maxL)) OF L
L ::= SEQUENCE {
                    M OPTIONAL,
   iE-Extensions ProtocolExtensionContainer { {L-ExtIEs} } OPTIONAL,
L-ExtIEs PCAP-PROTOCOL-EXTENSION ::= {
ExampleMessage-Extensions PCAP-PROTOCOL-EXTENSION ::= {
```

Annex B (informative): Change history

_	1			-	Change history		1
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
06/2001	12	RP-010402			Approved at TSG RAN #12 and placed under Change Control	-	5.0.0
09/2001	13	RP-010603	002	1	Correction to the Error handling of the ERROR INDICATION message	5.0.0	5.1.0
09/2001	13	RP-010603	002		Proposed CR to 25.453 on Semantics Description of C/No	5.0.0	5.1.0
09/2001	13	RP-010603				5.0.0	5.1.0
	_				Proposed CR to 25.453 on Clause 10		
09/2001	13	RP-010603		1	Error handling of the Erroneously Present Conditional les	5.0.0	5.1.0
09/2001	13	RP-010603		1	Clarification of chapter 10	5.0.0	5.1.0
09/2001	13	RP-010603			PCAP Criticality	5.0.0	5.1.0
12/2001	14	RP-010875		1	Bitstrings ordering	5.1.0	5.2.0
12/2001	14	RP-010875		1	Reference corrections	5.1.0	5.2.0
12/2001	14	RP-010875		1	Clarification for the definition of the ASN.1 constants	5.1.0	5.2.0
12/2001	14	RP-010875		1	Procedure Code Criticality in Error Indication	5.1.0	5.2.0
12/2001	14	RP-010875		2	Addition of amendment to clarify the PER encoding of bitstrings	5.1.0	5.2.0
12/2001	14	RP-010875		1	Clarification of the Transaction ID	5.1.0	5.2.0
12/2001	14	RP-010875			Correction the Clause 10 Error Handling	5.1.0	5.2.0
-3/2002	15	RP-020211		_	Modification on the Object Identifier	5.2.0	5.3.0
06/2002	16	RP-020432		2	Criticality Information Decoding Failure Handling	5.3.0	5.4.0
06/2002	16	RP-020432		1	Clarification for the usage of the cause value	5.3.0	5.4.0
03/2003	19	RP-030065			CR on GPS Almanac and Satellite Health	5.4.0	5.5.0
03/2003	19	RP-030065	_		CR on GPS Measured Results	5.4.0	5.5.0
03/2003	19	RP-030067			Alignment of "Uncertainty Ellipse" with RRC	5.4.0	5.5.0
03/2003	19	RP-030070		2	Correction for the Information Exchange Initiation procedure	5.4.0	5.5.0
03/2003	19	RP-030084	022	2	CR on revising the position calculation function and definition of SAS to support all REL-4 UE positioning methods	5.5.0	6.0.0
06/2003	20	RP-030324	033	1	Alignment of the Requested Data Value Information IE description	6.0.0.	6.1.0
06/2003	20	RP-030325		'	GPS trigger condition	6.0.0.	6.1.0
06/2003	20	RP-030341			Position Calculation Extension for TDD	6.0.0.	6.1.0
06/2003	20	RP-030322		1	"On Modification" and "Periodic" reporting alignment for Information	6.0.0.	6.1.0
00/2003	20	111 030322	001	'	Exchange procedures	0.0.0.	0.1.0
06/2003	20	RP-030322	044		CR on Criticality Aspects	6.0.0.	6.1.0
06/2003	20	RP-030322			CR on Information Exchange Initiation Request for GPS Navigation	6.0.0.	6.1.0
00/2000	_~	000022	0.0		Model	0.0.0.	00
06/2003	20	RP-030322	046		CR on DGPS Parameters	6.0.0.	6.1.0
06/2003	20	RP-030322	047		CR on Removal of Information Exchange Object Type	6.0.0.	6.1.0
06/2003	20	RP-030322	048		CR on Information Report of GPS Almanac and Satellite Health	6.0.0.	6.1.0
06/2003	20	RP-030326	050		Correction of Failure message used for logical errors	6.0.0.	6.1.0
09/2003	21	RP-030442	052		Correction to an incorrect implementation in the Requested Data Value Information IE	6.1.0	6.2.0
09/2003	21	RP-030445	054		Alignment of title and sub-clause text of chapter 10.3.4.2	6.1.0	6.2.0
09/2003	21	RP-030446			Removal of the note in chapter 10	6.1.0	6.2.0
09/2003	21	RP-030454	060		Improvement of position calculation with pathloss	6.1.0	6.2.0
12/2003	22	RP-030697	061		Improvement of position calculation through set enlargement	6.2.0	6.3.0
12/2003	22	RP-030683	064		Information Exchange Initiation behavior correction	6.2.0	6.3.0
03/2004	23	RP-040053	068		Alignment with 23.032 correction of Included Angle for Ellipsoid Arc	6.3.0	6.4.0
03/2004	23	RP-040075			Initial UE Position IE only mandatory necessary for GPS	6.3.0	6.4.0
03/2004	23	RP-040072	071		PCAP Review	6.3.0	6.4.0
06/2004	24	RP-040184		1	Correction to usage of INITIAL UE POSITION	6.4.0	6.5.0
09/2004	25	RP-040306	074	1	Introduction of the requested accuracy and an indication of	6.5.0	6.6.0
					achieved accuracy in Position Calculation procedure over lupc		
					interface		
12/2004	26	RP-040441			outdated ITU-T reference	6.6.0	6.7.0
03/2005	27	RP-050055		1	Corrections to descriptions of GPS Almanac and Ephemeris fields	6.7.0	6.8.0
06/2005	28	RP-050217		2	Correction of deletion of Information Exchange Context	6.8.0	6.9.0
09/2005	29	RP-050441		1	Addition of the U-TDOA positioning method to the UTRAN	6.9.0	7.0.0
12/2005	30	RP-050705		2	Addition of TDD aspects of the U-TDOA positioning method	7.0.0	7.1.0
12/2005	30	RP-050701			PCAP Review	7.0.0	7.1.0
12/2005	30	RP-050706			Wording Alignment for Procedure Text	7.0.0	7.1.0
03/2006	31			10	Enabling the Providing of Velocity	7.1.0	7.2.0
03/2006	31	RP-060071		1	Completion of SAS-centric mode	7.1.0	7.2.0
03/2006	31	RP-060073		1	Introduction of 7.68Mcps TDD option	7.1.0	7.2.0
06/2006	32	RP-060290		2	Release 7 Timing Advance (3.84 Mpcs and 7.68 Mcps TDD)	7.2.0	7.3.0
06/2006	32	RP-060386	094	1	Correction of positioning confidence reporting inconsistencies	7.2.0	7.3.0

	Change history						
Date	TSG #	TSG Doc.	CR	Rev	Subject/Comment	Old	New
09/2006	33	RP-060510	095	3	Addition of Periodic Location Procedures	7.3.0	7.4.0
09/2006	33	RP-060509	096	2	Extended WCDMA Cell Range	7.3.0	7.4.0
12/2006	34	RP-060705	097		Correction of Round Trip Time for Extended Cell Range	7.4.0	7.5.0
12/2006	34	RP-060837	098	1	Consistency of Specification Notations	7.4.0	7.5.0
03/2007	35	RP-070052	101	1	Presence inconsistency	7.5.0	7.6.0
03/2007	35	RP-070064	102	2	UE Rx-Tx Time Difference Type 1	7.5.0	7.6.0
06/2007	36	RP-070340	103	2	Support for additional measurements in Cell-ID positioning method and Information Exchange	7.6.0	7.7.0
06/2007	36	RP-070337	105	2	Introduction of GANSS (Galileo and Additional Navigation Systems) in PCAP	7.6.0	7.7.0
06/2007	36	RP-070474	106	2	Introduction of Extended RNC-ID	7.6.0	7.7.0

History

Document history					
V7.1.0	December 2005	Publication			
V7.2.0	March 2006	Publication			
V7.3.0	June 2006	Publication			
V7.4.0	September 2006	Publication			
V7.5.0	December 2006	Publication			
V7.6.0	March 2007	Publication			
V7.7.0	June 2007	Publication			